




Important: Read All Instructions Prior to Installation







Product Data


	DC Version	AC Version
Output Signal	RF signal	RF signal
Power Supply	12-24VDC	100-240VAC
Power consumption	< 20 mA	< 15 mA
Operating temperature	0-40°C	0-40°C
Relative humidity	8% to 80%	8% to 80%
Dimensions	75x120x29.1mm	75x120x29.1mm


- Touch sensitive
- · Glass interface(white & black)
- Compatible with all universal series RF receivers, radio frequency: 916.5MHz
- · Control CCT color
- · Control 4 zones synchronously and separately
- Waterproof grade: IP20

Safety & Warnings

- DO NOT install with power applied to device.
- DO NOT expose the device to moisture.

Wiring diagram










Operation

- 1. Do wiring the wall panel & RF receiver according to wiring diagram (please refer to the instruction of RF receiver that you would like to pair with)
- 2. Power on, then touch the button 🖐 to turn on the controller, indicator of the controller turned blue







Installation

