# Shark

# **ULTRACYCLONE**

#### WHAT'S INSIDE

(5) Vercum Body

(T) Set Cleaning

Crevice Tool


CHARGING YOUR SHARK! VACUUM

(iQ Scrubbling Brush

(F) Charging Adapter

Motorized Brush

- (A) Air-Intake Nozzle
- (f) Dust Cus
- Dust Out Release
  Button
- (f) Washable Filter
- (a) Charging indicator
- Light



**NOTE:** Accessories may vary depending on the model. Refer to quick guide, if available.

The images shown here are for illustrative purposes only and may be subject to change.

# IMPORTANT SAFETY INSTRUCTIONS - FOR HOUSEHOLD USE ONLY READ CAREFULLY BEFORE USE - SAVE THESE INSTRUCTIONS

# A WARNING

To reduce the risk of injury, fire, electric shock, and property damage resulting from improper use of the appliance, carefully observe the following instructions. This unit contains electrical connections and moving parts that potentially present risk to the user.

POWER SUPPLY CHARGING ADAPTER, AND VACUUM CONTAIN ELECTRICAL CONNECTIONS. WHEN USING AN ELECTRICAL APPLIANCE, BASIC PRECAUTIONS SHOULD ALWAYS BE POLLOWED, INCLUDING THE POLLOWING:

- There are NO be y peoble purity.
- 2 DONOT use to watch your ward DONOT
- 2 DONOT winerse in Nation of testings in a
- 4. Production amend, discording use
- 5. To wold fire to a comporting or injury inspect versus and description destricts any demand both class 00 MOT us correspond accounter class and description.
- 16 DO NOT use condense of an work adversion only on any outbree.
- Program change som weldig at 1 shallone bestern diapped, demand attitute pag, or honorise in water collectivities conte
- ILDG HOT hant in therefore sacial tric rations, thrown both
- \$ 05 YOU was earlier transport partnership sollenges on
- . To Keep tak a mindow from house is chose.
- A wave time off war aim before connecting cases agreeather.
- Se paly charge and her being provided. Other hopes of her believes a and loss signal as and starting.
- 17 . wichenber and an ibn word wide a show on y
- IV DO NOT inchnose and error extend in Assertate paregral, swiftly to an instructional region in a fire

#### GENERAL USE

- a DONOT very the charger to the contre surviva the contrel format and let, remembers the diagrams of its discontrect.
- It feedbage distance to characteristics.
- Cherry adecates a to night feet was not as well it.
- (2) page curation to a stating aboys a notified would place below plong tipe or anying type between adjugate pages and discounts. One of the or a vacationer.
- 12 DO NOTIce if my carning a bodyles keep heart dust mit higher eighting des mig recommends.
- 10 DO NOT use of two, pasticup and their place.
- Others and makeapig, at, a ray or make execution may be you be secured response represently individuous in a description of the content of the imaginal shadow or a the recommendation of the content of
- SACONOT as it in the a wascade the argulas are publicably unit if a variant carrier than all stated as a disposer orage of Subscripts arranging to the charge groups arrange had an base double.
- Soft injurar and distant in the manded class with a con-

- Sa 05407 diagonal to positions below \$1,7,00%; in deep 24% (20); it diagonal property of companies of condensation between Salarage representations acting the section of the section o
- 27 Stafe de apolición dos 90 x01 ao inspeció en la TAPATO de acide appareix or combinacione delegicación.

#### DUST CURFATERS ACCESSORES.

- Before a revenience according
- Richard and arrivations of volymbol and and contain
- 3), hallo subsect a send from an appare abordular mente know
- 20 history as a traction of some few of place improved description from the sign person.
- 2) the provided and accessories are ded.

#### GOMESAL CLEANING


- 2.00 NOT section appear of all associations ranging with previous choice of all each corrupt for accumulations.
- rs. DO NOT which up or yould do by replace of lone about
- 54 CONCT cases on above or a convertible for demanded or
- is DO NOT which is a first a facility of all section relies to a production, a matrix
- Statistical and application of the control of the con
- 57 00 901 cascardos ao escadar ste poderir ablacecem notas ar exendentese.
- 3. DONOT colo a sec exclusion visios secursos por contra complex at financial proving excursos. Turnot y cost o other pole, wormula recepita.
- 40 the course what did in points is:

#### LITERANCE BATTERY


- All The Estimates of Angrouse can see for Angrey across DC MOT complifie agriduates with your dispersion the power number DD MOT datapase prefer to with the provinces.
- 47. Lead the first stated of eight of totals storing the stiller short storing more and elected time.
- -1 the spokeron or years and dedicate metric between the other prior between the specifically and the
- 44. antimitative profit on, by a myther either from the better. We also and with lightly of my police in order with the field process her with sales the propriets new one majorithets.
- As the disruption of the Control of Interference of ACT as an developing of the original factor (ACT).
   Control of ACT (ACT).
- 76 COROT constraints on the relevant system of a service Service Corot in the province expression.
  70. The energia content of a period the sound of any DOME in only, or after onlying entire contents.
- (C.D.NOT) as a taylor or agree sales is to explore to sell to gifter a solitation of excidences of all our modes of the explorer provides.

#### A STATE OF S

## USING YOUR SHARK\* VACUUM



 lesert the charging adapter plug into the port on the handle.



Plug the charging adapter into a wall cutlet. The charging indicator light will blink. Light will go out when fully charged.







- 1. Press Power button
- 2. Run the riczzle over the surface to be cleaned.
- 3. To empty dust dup, hold your vacuum over the trash.
- Press the CleanTouch \* Dirt Eject butten to open and emoty the dust curs.


## **ACCESSORIES**


## INSERTION AND REMOVAL

- To install an accessory, align it with the nozzle, then slide it on
- 2. To remove an accessory, slide it straight off the nazzle.

## MAINTENANCE

# CLEANING THE DUST CUP







- 1. Press the dust cup release button and pull out the dust cup.
- 2. Carefully remove the dust cup filter
- To open and empty the dust cup, hold it ever the tresh, then
  press the Clean fouch? Dirt Eject botton (Complete
  Instructions on reverse side.)

80410648

#### MAINTENANCE - Cont.







- 4. Hand-rinse the filter in cold water and let it air-dry for at least. 24 hours before reinstalling, Air-dry only, DO NOT use a hair. dryer or lothes dryer.
- To clean the interior of the dust cup, rinse it with water. Place it. on its side with the lid open to air-dry for at least 24 hours. before reinstelling.
- 6. When the filter is dry, reinstall it in the dust oup, then reattach. the dust cup.

DO NOT wash any parts or accessories in a dishwasher. NOTE: For best results, replace the filter every 6 to 9 months.

TROUBLESHOOTING		
Problem	Solution	
The vacuum will not operate	Buttery needs to be recharged.  Try using a different electrical outlet to charge.	
Motorized brish will not work	The metal contact pins on the motor and brush are not in contact with the connector slots on the vacuum. Remove the motorized brush and reinsert finally into the air intake neare.  The motorized brush is blocked. Carefully remove all lint, hair, or other debris from the motorized brush.	
Vacuum will not pick up or suction is weak	Dust cop is full. Empty the dust due.  Tithe needs cleaning or replacement. Clean or replace the dust due filter.  Vacuum needs to be recharged.	
Dust is escaping from the vacuum	Empty the dust cup. The filter is not installed correctly. Remove it and retreat it. The filter has a here or a buncture and needs to be replaced. An obstruction may be blocking the door from closing correctly. Clear any obstructions and ensure the dust cup door is completely a cised.	

BATTERY INDICATOR			
No Light	Low Battery	Press the power botton: if the unit doesn't turn on then the bottony power is too low. Please charge belone use.	
Slow Flashing Light (while plugged in)	Vectorin Charging	To change the vacuum connect charging condition that and plug into wall butlet. The light will face in and out slowly as the vacuum charges.	
Fast Flashing Light (in use)	Low Battery	If the light riashes quickly while the unit is in use, the bettery power is low. Recharge the unit.	
Solid Light	Fully Charged	When the vacuum is fully charged, the indicator light will III minate steadily, then turn off (it takes approximately 5 hours for a full charge).	
Five Flashes (after plugging in)	No: Charging	If the wrong charger is used, the light will blink five time, and then stop, use the included charger.	

# BATTERY REMOVAL AND DISPOSAL

This product uses a rechargeable and reusable lithium-ion battery. When the battery no longer holds a charge, it should be removed. from the vacuum and recycled. Incinerate or compost the battery.

When your lithium ion battery needs to be replaced, dispose of it. or recycle it in accordance with local ordinances or regulations. In some areas, it is illegal to place sport I thium-ion batteries in the I trash or in a municipal solid waste stream. Return spent battery to an authorized recycling center or to retailer for recycling. Contact your local recycling center for information on where to propleff the spent battery.

For more information on battery removal for disposal, please visit sharkclean.com/battervsupport



LITHIUM-ION BATTERY MUST BE RECYCLED OR DISPOSED OF PROPERLY



The RBRC1" (Rechargeable Battery Recycling Corporation) seal on the lithium-ion battery indicates that the costs to recycle the battery at the end of its useful life have already been paid by SharkNin a. In some areas, it is ilegal to place spent lithium-ion. batteries in the trash or municipal solid waste stream and the RBRC program provides an environmentally conscious alternative. RBRC, in cooperation with SharkNinja and other battery users, has established programs in the United States and Canada to facilitate. the collection of spent lithium-ion batteries. Help protect our environment and conserve natural resources by returning the spent lith um-ion battery to an authorized SharkNinia service. center or to your local retailer for recycling. You may also contact. your local recycling center for information on where to drop off the spent battery, or call 1-800-798-7308.



Elbrd: Y.T. PRINTED IN MEXICO OBPN: CH900\_SERIES\_IB\_REV\_Mv2\_200819 MODEL: CH951 B SC: 05-11-2021 2P

