

尺寸:100x130mm

材质:120g书写纸+凤琴折(页双面印刷)

工艺:单黑双面印刷








2.4GHz wireless/BT3.0 or BT5.0. Save up to 5 devices at the same time 99 Key Layout: The Ki99 PRO is a 99-key mechanical keyboard featuring

an intuitive knob design. It adopts a gasket-mounted structure and PCB single-key socket technology, paired with durable PBT keycaps and a hot-swappable switch system. Both the keycaps and switches are user-replaceable, empowering you to effortlessly customize your typing experience and build a truly personalized keyboard through


FN Key Combination Function: Support the powerful and convenient FN key combination function, it allows you to easily access various shortcut operations in the proces of using, which greatly improves your using experience and working efficiency.

**RGB Lighting:** Support RGB lighting, easily switch between 15 RGB lighting effects or turn them off via FN+\, offer a total of 16 lighting options.

Software Driver: Compatible with drivers for music rhythm RGB effects, providing 10



**Ki99 PRO Features** 



Long press the combination key "FN+` " for about 3 seconds. The green light will flash and enter the

code pairing state. At this point, insert the receiver into the USB port of the computer

**Software Download** 

The SOLAKAKA Ki99 PRO driver is Microsoft-certified,

FCC Statement
This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may


cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not This equipment generates uses and can radiate radio frequency energy and, if no installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Recrient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.


ceiver is connected. Consult the dealer or an experienced radio/TV technician for help.

**Connection Method Wired Mode** ③Simply insert one end of the port of the Type-C keyboard computer's USB port **Quick BT Device Switching** Key combination for quick device switching: 2@ Fn 1! • Short press the combination key Fn+1/2/3 and the blue light will flash, indicating that the keyboard has entered pairing search mo Pairing and connection can be initiated on the device. In reconnection state the blue light will light up for 2 seconds. • Press En+ 1/2/3 to switch devices. Restore Factory Settings: FN+ESC **Keyboard Battery Status** Press Fn + B to check the battery level. • Please switch to BT or 2.4G mode to check the battery level. (Note: Battery status cannot be checked while the keyboard is connected via cable.) • Keys 1-0 indicate battery level (10 bars) Red: 3 bars or below Low battery: Fn key flashes red



and you can now use the numeric keys (1, 2, 3, 4). (Note: When the red light is off, numeric input is active.)

**Knob Function** 



FN+\ I Lighting Effect Cycle Switch

Wave Follow (Default)/Shadow Follows/Sine Wave

Ripple Effect/Twinkling Stars/Stream Flow

FN+F1	Homepage
FN+F2	Mail
FN+F3	Convert Window
FN+F4	Explorer
FN+F5	Brightness-
FN+F6	Brightness+
FN+F7	Previous song
FN+F8	Play/Pause
FN+F9	Next song
FN+F10	Mute
FN+F11	Volume-
FN+F12	Volume+
Mac S	System
Mac S	<u> </u>
	<u> </u>
Turn the Mode Switch in t	he upper-left corner to Ma
Turn the Mode Switch in t	he upper-left corner to Ma
Turn the Mode Switch in t	he upper-left corner to Ma Screen brightness- Screen Brightness-
Turn the Mode Switch in t  F1  F2  F3	he upper-left corner to Ma Screen brightness- Screen Brightness- Convert Window
Turn the Mode Switch in t  F1  F2  F3  F4	he upper-left corner to Ma Screen brightness- Screen Brightness- Convert Window Return to desktop
Turn the Mode Switch in t  F1  F2  F3  F4  F5	he upper-left corner to Ma Screen brightness- Screen Brightness- Convert Window Return to desktop Keyboard Brightness
Turn the Mode Switch in t  F1  F2  F3  F4  F5  F6	he upper-left corner to Ma Screen brightness- Screen Brightness- Convert Window Return to desktop Keyboard Brightness Keyboard Brightness
Turn the Mode Switch in t  F1  F2  F3  F4  F5  F6  F7	he upper-left corner to Ma Screen brightness- Screen Brightness- Convert Window Return to desktop Keyboard Brightness Keyboard Brightness Previous song
Turn the Mode Switch in t  F1  F2  F3  F4  F5  F6  F7  F8	Screen brightness- Screen Brightness- Screen Brightness- Convert Window Return to desktop Keyboard Brightness Keyboard Brightness Previous song Play/Pause
Turn the Mode Switch in t  F1  F2  F3  F4  F5  F6  F7  F8  F9	Screen Brightness- Screen Brightness- Convert Window Return to desktop Keyboard Brightness Keyboard Brightness Previous song Play/Pause Next song

Windows System

Turn the Mode Switch in the upper-left corner to Win

07

ensuring security and reliability.
If your device blocks the installation, please contact our support team for assistance.
The mouse driver is only supported on Windows.
Installation Instructions:
1.Access the Download Page: Visit the software download page at: bit.ly/m/solakaka
2.Download the Software: Click the "Download" button.
3.Complete Installation: Follow the on-screen instructions

to complete the installation process.

