

AYEF

Weathe Flashlight

Records Music Timer Stopwatch

- **Getting Started**
- Unboxing and Package Contents

Care Instructions

- Keep the device dry and avoid submerging it in salt water.
- ean the watch with a soft, dry cloth. Avoid exposing the smartwatch to extre temperatures.
- <u>Safety Warnings</u> This device is not a medical device and should not be used to diagnose or treat health conditions.

Warranty And Support

Charging the Device

I charging,&

nty information and product s intact our customer service at Dayers.shop or click here.

The Anarc Smartwatch must be charged before its initial use. It typically takes up to "2.5 hours" to fully charge. When the watch is fully discharged, it take few minutes to charge from 0% to 1%. Charging from 90% to 100% takes 30-40 minutes. Use a 5V/2A adapter for optimal charging, refer to the image below for proper connection and setup. Ensure correct alignment with the charging dock to avoid any interruptions during the process.

To Power Off: Press and hold the Crown for 5 seconds, then select the power-off option on the screen.

To Power On: Press and hold the Crown for 10-15 seconds.

- Connect with Layer's Watch App Download the Layers Watch App. You can either use the QR code displaye the watch screen or the one located on t backside of the box to get the "Layers W mobile app. (Available on both App Store Google Play Store)



Functional Crown with haptics Anarc is equipped with a functional crown that allows you to easily navigate Main menus, scroll settings with precision.

- Navigating The Interfac Display, Crown And Button
- **Touch Screen:** Swipe Right, Left a Down to navigate. Side Crown: Press to enter the Main Menu. Press once to return to the home screen. Hold for power options. Rotate the crown to scroll through the screen.





Use this feature to turn off media audio on the watch

- **Change Watch Faces** From the home s face. creen, long-press the watch Swipe to select from the available faces or download additional watch faces from the app.
- itness & Activity Tracking Sleep Tracking Wear the watch during sleep to track sleep stages (Awake, REM, light, deep) and total sleep time.
 - View detailed sleep reports in the Layers watch app. Wear your watch snugly for accurate data; improper fit may affect sleep detection. **8**h **05**m
 - Activity, Workout Modes And Records Activity: Steps, Distance And Calories
 - Starting A Workout Open the Workout app. Select your preferred workout m Walking, Running, Cycling, etc.).
 - 20 May 534 kcal 20 May 230 kcal 120 k Call, Contacts, Notification

6 Cycling
20 May 2024 • 08:25pm

1h 20m 33s

Contacts: Add up to 20 contacts on your smartwatch for quick access and easy calling

Stay updated with real-time notifications for calls, messages, and social media apps right on your smartwatch.

Customize the notifications from the Layers watch App to choose which ones you want to receive or not.

Pair your watch with your smartphone to receive notifications for calls, messages, emails, and apps

Stay prepared with real-time weather updat on your smartwatch, providing temperature, conditions, and forecasts for your location.

alls, Messages, And

12' 23" Avg Pace

- <u>Alarm</u>

Set countdowns for specific tasks, workouts or reminders with the Timer feature, helping you stay on track with precise time management.

00:04.00

24°C ▼4°C 15 mins ago

- 00:00.00 00:01.22
 - Phone Music : Control your phone's n directly from your smartwatch

"Display" > "Brightness

ı

-48:12

to adjust the

- Do Not Disturb Mode*
- Enable "Do Not Disturb" from the quick access and settings menu to silence notifications during specific hours.
- Access and adjust all smartwatch settings, including Bluetooth, display & theme*, customised screen*, sound* & vibration*, password*, notifications, side button, download App, system, and About settings of watch

 - Check the FW version
- - Restart, Power Off and Reset the watch
 - Firmware updates are available. Follow these steps:
- System
 - a. Open the Layers Watch App.b. Go to "Device" > "Update."
- About

- - Experience excellent haptic feedback with every touch and interaction, enhancing the user experience with responsive haptics. Modify Haptic Settings via Layers watch App: Off, Gentle, Normal, and Intense.
 - Side Crov

- Note: Sleep data will take s the watch.

- Press "Start" to begin tracking.

 Choose from over 100 workout modes to track your activities and optimize your fitness routine.
- Call: Tap on the call to view recent calls and access the dial pad.
- lotifications For C locial Media Apps
- Receiving Notifications Note: Notification permissions need to be granted through the Layers Watch app.

Smart Features Weather Updates

- <u>Timer</u>
 - Music

- - - <u>Flashlight</u> Illuminate your surroundings in low-light situations by using your smartwatch screen as a flashlight.

1 2 mins

Stopwatch

- Settings Display And Theme Go to "Settings" on the watch. Select level.
- Note: Features marked with an asterisk (*) will be included in a future OTA update.

- Long Press the crown to turn on the watch. Enable Bluetooth on your smartphone. Open the App and follow the on-screen instructions to pair your watch.

- - Note: Features marked with an a ncluded in a future OTA update.

- Note: Fully charge the smartwatch before its first use for optimal performance.

- Powering On/Off



