



APP Instruction

Your Life, Your Canvas


CONTENTS

1. APP Download and Installation	01
2. Registration and Login	02
3. Network Setup & Creating Screen Groups	03
3.1 Bluetooth Network Setup	03
3.2 Creating Screen Groups	05
4. Uploading Pictures	06
4.1 Upload Pictures	06
4.2 Picture Cropping - Full-screen Display	07
5. Uploading Videos	09
5.1 Uploading Videos	09
5.2 Video Cropping - Full-screen Display	10
6. Using the Cloud Album	12
6.1 Creating a Cloud Album	12
6.2 Uploading Picture	13
6.3 Sharing Picture	13
6.4 Multi-screen Upload	14
7. Screen Control	15
7.1 Screen Group Settings	16
7.2 Screen Settings	17
7.3 Screen Mapping	18
7.4 Multi-screen Puzzle	19
8. Media Library	22
9. Settings Center	23
10. Friends	24
10.1 Adding Friends	24
10.2 Sharing Screens	24
10.3 Sharing Picture	25
10.4 Deleting Friends	25
11. Personal Center (My Profile)	26

1. APP Download and Installation

Downloading the APP from the APP Store

To download and install the latest version of the Pintura Life APP, users can simply search for "Pintura Life" in their APP store.



2. Registration and Login

a. Switch Language: Select your preferred language.

b. Select Region: Choose the region where you purchased the product.

c. Register: Enter your registration information as prompted on the screen.

d. Login

Note: The selected region must be consistent with the product version (for example, if purchased in the United States, then the United States needs to be selected, and other regions are inferred by analogy).

The screenshot shows a login interface with three tabs: 'Phone', 'E-mail' (selected), and 'Code'. Below the tabs are input fields for 'Please enter your e-mail' and 'Please enter your password.' with a right arrow. There are links for 'Remember me' (checked) and 'Forgot Password?'. Below these is a 'Country: China' field and a 'Language' field. A large blue 'Sign In' button is at the bottom. At the very bottom, there is a checkbox 'I have read and agree to the following terms.' with links to 'Privacy Policy' and 'Service Agreement'. An orange line points from the text 'b. Select Region' to the 'Country: China' field. Another orange line points from the text 'a. Switch Language' to the 'Language' field. A third orange line points from the text 'c. Register' to the 'Sign In' button.

The screenshot shows a registration interface titled 'E-mail registration'. At the top, there are links for 'E-mail registration' and 'Phone Registration'. Below are input fields for 'E-mail address', 'The nickname is up to 16 characters long', 'Pwd: 6-12 chars long, no special chars', and 'Confirm password'. Below these is a 'Country: China' field, which is highlighted with an orange rectangle. Below that is a 'Verification code' field with a 'Send Verification Code' link. A large blue 'Register' button is at the bottom. At the very bottom, there is a checkbox 'I have read and agree to the following terms.' with links to 'Privacy Policy' and 'Service Agreement', followed by a disclaimer: 'Messages&Data rates may apply. Message frequency may vary. Reply HELP for help, reply STOP to stop.'

3. Network Setup & Creating Screen Groups

3.1 Bluetooth Network Setup

a. Phone Settings:


Turn on your phone's **Bluetooth**, **WiFi**, and **Location services**.




b. APP Network Setup:

On the **Screen** page, click the  button in the top right corner.

1




2




Once the screen turns on and displays the default image, you can proceed with the network setup.

1




2



3



4



Manually Enabling Bluetooth

Hold 2s to turn on the Bluetooth. If you hold more than 10s, the screen will reset




If some screens fail to connect to the network and multiple attempts have been unsuccessful or the APP cannot detect the device's Bluetooth, please try manually turning on Bluetooth and then clicking reconnect.

- If all screens fail to connect, please go back and check if the WiFi password is entered correctly.
- During network setup, keep your phone close to the screen device.
- If iPhone users encounter repeated network setup failures despite having the correct password, please restart your phone and try again.
- The WiFi password must not exceed 17 characters.

3.2 Creating Screen Groups

For convenient management and operation, it is necessary to create screen groups. Screens can either be allocated to the same group or different groups, such as "Bedroom," "Living Room," etc.

When using the APP for the first time, you must create a new screen group. If a screen group already exists, you can choose to add screens to the existing group. (*Note: A screen can only be assigned to one screen group at a time.)




4. Uploading Pictures

4.1 Uploading Pictures


Currently, only jpg, png, and bmp files are supported. Click on the screen to enter the picture upload interface.

(*After uploading, switch the display mode to "picture" mode by clicking the gear icon in the top right corner.)

1




2




3




4



5



6



Upload Methods:


- a. Camera:** Share beautiful scenes and moments around you anytime, anywhere.
- b. Local Camera Roll:** Select and upload picture from your local phone album.
- c. Cloud Album:** Choose and upload previously uploaded picture from the cloud album.

4.2 Picture Cropping - Full-screen Display


If the aspect ratio of the picture does not match the screen size, the screen will not display the picture in full screen, and borders may appear on the sides. To display the picture in full screen, you need to crop the picture.

For a 10.1-inch screen: Select 16:10 for horizontal picture, and 10:16 for vertical picture.

For a 13.3-inch screen: Select 16:9 for horizontal picture, and 9:16 for vertical picture.



Click the  button in the top right corner to toggle the screen orientation.



Horizontal Display



Vertical Display




5. Uploading Videos

5.1 Uploading Videos


Currently, only H.264 encoded mp4 and mov formats are supported.

(*After uploading the video, you need to switch the playback mode to "Video" for the screen to play the video.)


1



2




3




4



5



6




5.2 Video Cropping - Full-screen Display

If the aspect ratio of the video does not match the screen size, the screen will not display the video in full screen, and borders may appear on the sides. To display the video in full screen, you need to crop the video.


For a 10.1-inch screen: Select 16:10 for horizontal video, and 10:16 for vertical video.

For a 13.3-inch screen: Select 16:9 for horizontal video, and 9:16 for vertical video.

Note: This function is not enabled on iOS



Click the  button in the top right corner to toggle the screen orientation.



Horizontal Display





Vertical Display





6. Using the Cloud Album



6.1 Creating an Album

a. Add an Album: Go to the **Canvas** page, click **+** button in the top right corner, enter the album name, and confirm.




b. Deleting Picture: After entering the album, click  button in the top right corner to enter selection mode and select all. Click again to deselect all. Long-pressing a picture also enters selection mode. After selecting picture, you can perform actions such as " **Download** " " **Multi-Screen Upload** " " **Share** " and " **Delete** . "


c. Editing an Album: After entering the album, click  button in the top right corner to delete the entire album or modify the album name.




6.2 Uploading Picture

A single album can contain up to 500 picture, but there is no limit on the number of albums. Click  button to upload picture. There are three upload methods: **Camera** **Local Camera Roll** and **Cloud Album** .

1




2




6.3 Sharing Picture

Picture in the cloud album can be shared with friends by clicking the **Share** button. Friends can save the shared picture or transfer them to their own cloud album.

1



2




3



6.4 Multi-Screen Upload

For users with multiple screens, the **Multi-screen Upload** feature allows selected picture to be uploaded to multiple screens at once. (Note: This function will clear the current picture on the screens.)


1




2




3




4



5



6




7. Screen Control

7.1 Screen Group Settings

Settings in this interface will be applied to all screens within the selected screen group. For example, if the "Bedroom" screen group contains screens a, b, c, and d, clicking **Clear All Data** will remove all picture and videos from these four screens.

Modify Screen Group Name Click on the current screen group name to edit it.



Access From the home page, click on the screen group, then click the top right corner  button to enter the **Screen Group Settings** interface.

Sync Playback After clicking, all screens in the group will start playing the same content after ten seconds, ensuring synchronized display across the group.

Clear All Data Remove all content from all screens in the group.

Screen No. Display numbers on both the screen and the APP (used for matching screens).

Clock Display the clock on the screen.

Calendar Display the calendar on the screen.

Picture Display picture on the screen. If there are no picture, the screen will display the logo image.

Videos Display videos on the screen. If there are no videos, the screen will display the logo image.

Playback Mode Choose from three playback modes: **Solo** **Slideshow** and **Shuffle** .

Solo Play a user-specified picture or video without playing other content or scrolling.

Slideshow Continuously play picture or videos in a loop.

Shuffle After specifying an album, the screen will randomly select picture from the "**Cloud Album**" to display at set intervals.

Playback Interval Set the time interval for switching picture, currently supporting 1-60 seconds.

Brightness Choose from three modes: Standard, Night, and Day.



Color Temperature There are three modes: Standard, Warm, and Cool.

Screen on/off Remotely turn the screen backlight on and off.

Timer on/off Set daily times to turn the backlight on and off.

Cloud Sync Enabled by default. When this feature is on, you can view the picture and videos uploaded to the current screen on the APP and use the **Sync** feature. If this feature is turned off, the APP cannot display the content uploaded to the current screen, delete individual media files, or use the **Sync** feature. Turning off this feature is equivalent to enabling "**Incognito Mode**." User data will no longer be stored on the server, and some corresponding features will be unavailable, which may affect the user experience.

Delete Screen Group Enter the verification code to delete the current screen group and all screens under it. To reconnect the screens to the network, you need to manually enable Bluetooth.



7.2 Screen Settings


Settings in this interface apply to individual screens.

Access: Click  button

This interface does not include the **Sync Play** and **Clear All Data** options but has a screen orientation switch  button.

Functions already introduced in 7.1 will not be repeated here.

Capacity Usage Displays the current screen's capacity usage (Note: 1-2GB of capacity is reserved for the system).



Rotate Click  to switch the screen orientation. (Note: Occasionally, the icon's direction may not match the actual display orientation. In such cases, click the button twice).

Volume After switching the display mode to video, you can adjust the current video's volume by dragging the volume control slider (Note: Some versions of the screens do not have built-in speakers).

Reset If in the picture upload interface, clicking this button will clear the current picture on the screen. If in the video upload interface, it will clear the current videos but not the picture.

Reorde Long-press (0.5s) and drag picture or videos to reorder them.



Sync If the content playing on the screen is not consistent with the content displayed on the APP due to network or other factors, click this button to sync the screen with the APP. (Note: This button has a cooldown period of 30 seconds).



7.3 Screen Mapping

a. Select Screen Group: Choose the screen group you want to upload picture to from the **My Screen Groups** list. After selecting, enter the screen group.

b. One-Click Mapping: If you have multiple screens, you can use the **Show Screen Number** feature to match the screens on the APP with the physical screens.



c. Reorder Screens: You can also long-press a screen for 1-2 seconds and drag to reorder the screens for easier management.




7.4 Multi-screen Puzzle

Puzzle You can cut a 4K or higher resolution picture into multiple parts and assign them to different screens to combine and show the full picture.

Note: This function is applicable to Pintab or multi-screen users, iOS has not enabled this feature)


Operating steps

1. Show screen number for all screens to facilitate screen mapping on **My Screen Groups** list.
2. Click the  button in the top right corner to puzzle.

1





2





3. Click the box on the right to select or deselect the screen (optional).

3




4. Refer to the number on the corner of the "box" to correspond to the serial number displayed on the screen, move the "box" until it is in line with the actual position on the screen, and then click **Next** on the lower right corner. **Note:** Do not operate with more than one finger, otherwise you cannot drag the "box")

4




5. Click the **Add image** button on the right to select the image you want to crop. **Note:** It is recommended to select 4K or higher resolution of the picture, lower than the resolution will be blurred

5




6. Two-finger clicking on the non-" box "area can reduce and enlarge the picture, and single-finger clicking can move the picture. If the picture does not move to the appropriate position in the box, you can re-adjust the position of the box. **Note:** You can click the arrow ">" "<" in the lower right corner to hide and display the right menu

6





7. After the adjustment, click the button **Crop and Upload** on the right and upload the cropped picture to the corresponding screen.

7




8. If you want to upload multiple puzzles, you can click **Next Frame >**, then click **Add image** to select the picture again.

8




Note: In the current version, you must upload pictures of all screens under the screen group before you can continue to upload the second frame and subsequent puzzles (for example, there are 5 screens under the screen group, 4 screens are selected for the first frame to upload the puzzle, and the second frame pictures cannot be uploaded).





9. After the pictures are downloaded, click **Sync Play** to synchronize the pictures.



8. Media Library

Pintura Life offers a free media library that is updated daily. Users can choose to save media locally or transfer it to the cloud album.

To Transfer Media: Navigate to **Canvas** - Floating button **Media Library** - Click on a media item -  button - Select/Create an album and click **Confirm** .



9. Settings Center

Sign Out Navigate to My Profile - Settings Center - Sign Out

Account Setting Modify the login password, view the phone number and email linked to the account, and check the registration region of the current account.

Check for Upgrade Check for and update to the latest version of the APP.


Contact Us After-sales customer service phone number and email.

Time Zone The default is to automatically obtain the phone's time zone, but users can choose other time zones. After switching the time zone, the corresponding clock and perpetual calendar will change accordingly.

Language Switch between Chinese and English.


Privacy Policy View the privacy policy related to the use of the APP.

Service Agreement View the user agreement.



10. Friends


10.1 Adding Friends

Navigate to **My Profile** - **Friends** - Top right corner  button - Enter the friend's email or phone number in the input box.


**Note: If the friend is not registered, they will be notified via SMS or email (SMS notification is not supported in the US region).*

When adding a friend, you can choose to share a screen with them.


1



2



3




10.2 Sharing Screens

After sharing a screen with a friend, they can upload to and control the shared screen upon accepting the share. The screen owner can cancel the share at any time through the sharing interface.

Navigate to **My Profile** - **Friends** - Select a friend -  button - **Share Screen** - **Share Screen** - **Select Screen** - **Confirm**

1



2




3



10.3 Sharing Picture

Through the **Friends** feature, users can send their favorite picture to friends. Friends can save the shared picture and transfer them to their own cloud album. Navigate to **My Profile** - **Friends** - Select a friend - **Send Picture** - **Camera/Phone Album** - **Confirm**




10.4 Deleting Friends

Once a friend is deleted, any shared screens will disappear from the other person's account. There are two ways to delete a friend:

Navigate to **My Profile** - **Friends** - Top right corner  button -Select the friend you want to delete - **Delete Friend**

Or select and hold a friend's name, then swipe left. A delete button will appear; click the delete button to confirm.



11. Personal Center (My Profile)

Message Center View device messages, including system and version release notifications, as well as friend requests.

Friends Add friends and share device functionalities.

Firmware Update Update the screen's system firmware to the latest version.
-- If a new firmware version is available, it is highly recommended to upgrade. New firmware often fixes numerous issues and adds new features. It is also advisable to upgrade the APP simultaneously.

Edit Profile Edit personal information such as avatar, nickname, birthday, and personal signature.

FAQ & Feedback View FAQs for common issues and provide feedback on encountered problems.

Information & Manuals Download the latest product installation manual.

