
The Ria Coffee Table MAIDEN HOME


Assembly Instructions




Components & Hardware




Keeping the tabletop in its crate, place it on the floor with the underside facing up. Use the Allen wrench to remove the pan head screws on the bottom of the undermount, then separate the undermount from the tabletop.




Place the corner brackets over the pre-drilled holes on the legs, then insert two flat head screws into each corner bracket. Using the Allen wrench, tighten the screws to secure the brackets.




Rest the undermount on the ground with the underside facing up, then place the legs on top of it, ensuring the holes on the corner brackets align with the holes on the undermount. Insert two flat head screws into each corner bracket and tighten them using the Allen wrench.





1

Take a moment to confirm that the hardware is secured tightly at all connection points.



With the help of another person, carefully flip the attached undermount and legs over.

6

With three people holding the tabletop vertically, lift it on top of the undermount, aligning the pre-drilled holes on its underside with the pre-drilled holes on the undermount. From underneath the table, place the pan head screws into the pre-drilled holes and tighten them using the Allen wrench to secure the tabletop. Do not use power tools to tighten the screws.

