



violently dunk or hang on the

Please feel free to contact us

with your Order ID if you have problems with assembly or need replacement parts.

In order to be safe and save your time, please check all the accessories in the package before installation, read the instructions carefully, and then install it after mastering the installation steps.

2 adults are recommended for installation, 2 adjustable wrenches are

SAFETY INSTRUCTIONS (IMPORTANT!!!)

1. Due to the uncertainty of the weather (sudden gusts of wind, etc.), FOR EXTRA SAFE you can put a couple of bags of SAND LAYING ON THE BASE(we recommend you to do this whether your base has been

filled with water or sand), it will hold the basket more steady, safe and in place.

2.DO NOT PLACE HARD THINGS ON THE BASE (such as sharp stones, irregular bricks, etc.), and DO NOT STEP on the base, otherwise it will DAMAGE THE BASE.

3.YOU NEED TO MOVE THE BASKETBALL HOOP TO A SAFE PLACE DURING STRONG WINDS.

4.Please check the overall weight of the base (If the base is not heavy enough, the basketball hoop may fall over) and the fastening of the screws before use to avoid any damage to the product and users. 5.Two or more adults are recommended for installation, and children are prohibited from installing and

6.Please check whether the base is leaking before use, small flow of water leakage can cause the product to fall 7.The product is suitable for leisure and entertainment, not for fierce competition. Strong dunks and hangs are

8.After the installation is completed, the base must be filled with water or sand immediately to prevent it from falling over. The base must be placed on a level and flat ground before use to prevent it from falling over or

A Warning

climbing the basketball hoop.

being damaged by sharp objects.

1. It is forbidden to climb or hang on the hoop, backboard bracket and bead net. 2. It is forbidden to use products with potential safety

hazards. If there are parts that need to be repaired or replaced, please contact after-sales personnel or local

3. Special care must be taken when moving on uneven ground, which may cause side material of the product.

4. In order to avoid damage to the base due to freezing, when the temperature is lower than 0 degrees Celsius. the water in the base must be poured out or filled with

5. If the product is used outdoors for a long time, please ensure that the top of the main pole and the lifting pole are covered with plastic covers to prevent rainwater from affecting the product life.

6. Please do not wear watches, necklaces, earrings and other jewelry when in use, to prevent hanging up the

basket or losing it during exercise. 7. When adjusting the height, please leave your fingers away from the moving parts.

8. It is forbidden for children to move the product or adjust the height of the product.


Height adjustment


There are several holes of different heights on the top pole. Put the basket at the height you want and install the F screws.


Minimum Height: 4.4FT(without

























As shown in the figure, use screws F1,F2,F3 to fix top pole W in the middle of bracket K.



Insert the installed top pole W

into the middle pole X and fix it



If the product does not need to be moved frequently, we recommend putting sand in the base instead of water. Because water freezes below 0°C, it is easy to damage the base. But please note that the sand cannot be poured out after it is placed in the base.

It is recommended to use objects to support the basketball hoop for assembly