



FALCON RIDGE

2515 Bypass Rd. Flemingsburg, KY 41041
606-845-7439

Instructions for Installation and Care of
Kawasaki KRX1000
Windshield

KAW-KRX-WD02

Notice: Do not smoke inside the cab or expose the enclosure to direct flames. Cab Material is **Flammable**.

NOTICE: Please check contents of package for any damage and make sure all parts fit correctly and you are happy with the product before removing protective film. Once the film is removed you cannot return the product for a full refund.

1. Be sure to read these instructions thoroughly before opening and installing the Kawasaki KRX1000 - Windshield. Roof or other accessories may need to be loosened or removed in order install windshield.
2. Carefully open the carton and remove the windshield. Place windshield on large flat surface that is clean and free of dirt. Inspect the windshield prior to installation. If there are any concerns, please contact customer service. If the protective film has been removed the windshield is not eligible for a return.
3. Check the parts included in the carton with the parts list shown below:

Included Parts:

| | |
|-----------------------|------|
| Aero-Vent Windshield | 1pc |
| Strap Clamps | 2pcs |
| 1/4-20 x 1in SS Bolts | 3pcs |
| 1/4-20 Lock Nut | 3pcs |
| 1/4-20 Washer | 3pcs |
| Side Bulb Gasket | 42in |
| 1 1/2in Loom Clamp | 1pc |

If any parts are damaged or missing, please contact customer service at (606) 845-7439.

Tools Needed for Installation:

Adjustable Wrench or 7/16in wrench
Phillips Screwdriver

Windshield Installation

1. Be sure to read all instructions prior to starting the installation.
2. Begin by installing the bulb gasket along the bottom, curved edge of the windshield.
Press the gasket firmly into place and work your way along the edge in sections to make installation easier.
3. Use two ¼-20 x 1in bolts, two washers and two lock nuts to attach the windshield to the frame in the top corners.



4. Use the loom clamp along with bolt, washer and lock nut to secure the top center of the windshield to the frame.



5. Check all bolts and clamps to ensure they are tightened, and installation is complete.