


PRINT ARTWORK ON DIRECTLY ON PAPER.
DO NOT PRINT RED FOLD AND CUT LINES. OPEN USER MANUAL DIMENSIONS: 6.46"W x 5.5" H



FRONT

BACK

5000 MAH DUAL POWER BANK
iJOY MAGNETIC POWER BANK



USER
MANUAL



FCC ID: 2AJQ7POWERBANK

QUEST USA CORP.
495 Flatbush Ave Brooklyn, NY 11225

© GOIJOY & IJOY are registered trademarks of QUEST USA CORP.
All other trademarks and trade names are property of their
respective owners.
Designed by GOIJOY & IJOY in New York. All rights reserved QUEST USA
CORP.

One (1) year limited warranty. To activate your product warranty go to our
website www.goijoy.com & register this product.

Made in China.

•YOUR IJOY PRODUCT

Thank you for purchasing and using the 5000mAh "IJOY MAGNETIC
POWER BANK". This device can provide high quality charging for
any phone or usb charged multimedia device. Before using this
product, carefully read this manual to correctly operate this device.
Please ask your local dealer if you have any questions.

Magnetic Wireless Power Bank x 1
Charging Cable x 1
User Manual x 1
Warning Card x 1

•PRODUCT SPECIFICATIONS

- POWER INPUT: 5V-1.8-2A
- POWER OUTPUT: 5V-2A
- WIRELESS CHARGER OUTPUT: 5W

•BATTERY CAUTION

The battery used in this device may present a risk of fire, explosion
or chemical burn if used incorrectly. Never use or charge the
battery if it appears to be leaking, discolored, deformed or in any
way abnormal. Never disassemble the unit or attempt to remove
the battery as that could cause leakage of alkaline solution or
other electrolytic substances. Never expose the battery to any
liquid. Never expose the battery to excessive heat such as direct
light or fire. Always keep the battery out of the reach of infants
and small children.

•BATTERY DISPOSAL

Please do not attempt to change the battery yourself. If the battery
has died, you should follow the disposal instructions listed here.
Never dispose of used batteries/electronics with ordinary solid
wastes. Always dispose of used batteries/electronics in accordance
with the prevailing community regulations that apply to the disposal
of batteries/electronics. If there are no local regulations concerning
battery/electronics disposal, please dispose of the device in a waste
bin for electronic devices. Many electronics retailers now recycle
batteries and other electronic components at no charge.

•FEATURES

- Compatible with most phone devices and digital products with a
USB port.
- Built-in protection ICs.
- Intelligent power management solutions for steadiness and high
efficiency.

•TIPS

- Please make sure to charge the power bank once every 3 months.
- Please be aware when the power bank is used, it may feel
overheated. This production should not reach above 140°
Fahrenheit (60° Celsius).
- Keep power bank dry and away from water, do not wipe with
chemical cleaners.
- Please recycle the power when done using.

•IMPORTANT

- Keep away from children.
- Do not crush, self-dismantle, stab, wet, dampen or squeeze power
bank.
- Do not place power bank in high temperature environments.
- Do not charge a device that is not compatible with the power
bank, it may result in damage or fire.

•FCC ID STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the
following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference
that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party
responsible for compliance could void the user's authority to operate the
equipment.

NOTE: This equipment has been tested and found to comply with the limits for
a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are
designed to provide reasonable protection against harmful interference in a
residential installation. This equipment generates uses and can radiate radio
frequency energy and, if not installed and used in accordance with the
instructions, may cause harmful interference to radio communications. However,
there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television
reception, which can be determined by turning the equipment off and on, the
user is encouraged to try to correct the interference by one or more of the
following measures:


Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver. Connect the
equipment into an outlet on a circuit different from that to which the receiver is
connected.
Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The
device can be used in portable exposure condition without restriction.


•INSTRUCTIONS

CHARGING THE POWER BANK

- METHOD 1: Connect input of the power bank into outlet using Type-C
cable (see example 1).
- METHOD 2: Connect input of the power bank to a computer using
Type-C cable (see example 2).



example 1



example 2

CHARGING YOUR DEVICE

- Connect your device to the outlet of the power bank using a cable
that works for your device (see photo below).



•OTHER IMPORTANT SAFETY INFORMATION

Disposal of old electronic & electronic equipment (Applicable in the
European Union and other European Counties with separate collection
systems) The trash can symbol (seen on the bottom) on the
production indicates that this product shall not be treated as
household waste. Instead it shall be handed over to the applicable
collection point for recycling of electronic equipment. By ensuring this
product is disposed of correctly, you will help prevent potential
negative consequences for the environment and human health, which
could otherwise be caused by inappropriate waste handling. For more
detailed information about this product, please contact your local
household waste disposal service or the shop where you purchased
this item.



•ONE (1) YEAR LIMITED WARRANTY

Our product is warranted for a One (1) year limited warranty from
the date of purchase. The warranty is provided on all material defects
and workmanship. Guarantee of 12 months does not apply to decrease
in the accumulator's effective capacity caused by its use or age.
Effective capacity gradually decreases depending on the method of
use of the accumulator. **WE RESERVE THE RIGHT TO CHANGE
TECHNICAL SPECIFICATIONS.** For more information please visit,
www.goijoy.com