

MUNBYN

MUNBYN,

Focus on
Every Powerful
Moment

MUNBYN

User Manual



Version 1.00



iOS Android
work with
Print Master


Version 1.00

Content

1.0 Packing Introduction	1
2.0 Specification	2
3.0 Operation	3
4.0 Quick Connection	4
5.0 FAQ	5
6.0 Support	6

1.0 Packing Introduction


What's in the box?



2.0 Specification

Printing method	Thermal Direct
Resolution	203dpi, 8dots/mm
Print speed	20mm/s max
Interface	USB+Bluetooth
Lithium Battery	1200mAh Li-On rechargeable
Power Adaptor	DC 5V/2A
Label width	15mm max
Working Temperature(°C)	0°C ~ 50°C
Working Humidity	—10~50/ 10~90% (Non-condensing)
Storage Temperature(°C)	—20 ~ 70°C
Storage Humidity	—40~80/ 5~95% Non-condensing
Printing life	50km
Operating system	Android/iOS

3.0 Operation



Indicator light	Status	Situation
Green	Light	Fully charged/Normal use
Red	Light	Cover opened/Out of paper/Charging
Red	Flash	Low power
Blue	Light	Charging/Bluetooth connected

4.0 Quick Connection

1. Open the cover and load the paper.
2. Scan the QR code below to download the App or search for "Munbyn Print" in Google Play or App Store.



5.0 FAQ

Q1. Why do I need to open the geographic location and address book when using the App for android?

A1. It is Google's rule. Our App needs to abide by this rule on the Google platform. But please rest assured that we will firmly protect user privacy.

Q2. Why cannot the printer connect to Bluetooth and print?

A2. You first need to search for "Munbyn Print" through Google Play or scan the QR code to download the App, then open the App to connect to Bluetooth.

Q3. Why does it print blank labels?

A3. Please make sure the printing side of the label is facing up.

Q4. Why does the App crash?

A4. Please uninstall and reinstall the latest App.

Q5. Why is the print not clear?

A5. There are many factors that affect print clarity. First, please make sure that the battery is full. Second, adjust the font size, font type and concentration. If the above methods do not work, wipe the print head with an alcohol swab.

Q6. Why is printing response time sometimes long?

A6. The reason is that the Bluetooth transmission speed of the cell phone is slow. Please be patient.

Q7. Why does it show out of paper when printing? (The label paper is loaded correctly)

A7. Please disconnect Bluetooth, restart Bluetooth to reconnect App, or restart the App directly.

6.0 Support

MUNBYN provides 18 months' warranty and lifetime free service.

If you encounter any issues with the product, please contact the MUNBYN team to promptly receive troubleshooting tips or a replacement.

Email: support@munbyn.com (24-7 online support)

Website: www.munbyn.com (how-to videos)

WhatsApp: +8617817881067

Phone: +14034771911



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction