

DELLA™  
ICE MAKER

Instruction Manual  
item no. 048-GM-48222  
item no. 048-GM-48223



Thank you for purchasing our product  
Make sure you have read manual before using, properly use  
the appliance in accordance with the instructions.  
Please well keep this instruction manual



www.dellaproductsusa.com  
(949)344-2588

Directory

Basic Introduction -----	1
Product’s Features -----	1
Components’ Names -----	1
Safety Precautions -----	2
Place environment -----	2
Preparing before use -----	2
Begin to use-----	3
Operation Panel -----	3
Failure and treatment -----	4
Clean and stop use -----	5
Technical parameters -----	6

IX. Cleaning and Off Use.

1. Make sure to unplug the appliance before cleaning and long time off use.
2. Use a damp cloth to clean both the interior and exterior of the appliance.
3. Water tank cleaning.
  - 1). Unscrew the nut of water outlet, drain off the water.
  - 2). Pour clean water into the water tank, use a clean cloth to wipe water tank around. Pour clean water again until the flowing out water is clean, then drain off water and grip the nut.
  4. Do not use organic solvents, boiling water, cleaning agents, strong acids, strong acid and Alkali etc substances for cleaning.
  5. If ice machine will be off use for a long time, you should unplug the appliance, drain off the water and dry the appliance with a clean cloth, store the ice maker in a clean place.

X. Technical parameters






Model no.:	048-GM-48222/048-GM-48223
Power supply	refer to rating label
Refrigerant	refer to rating label
Ice making capacity	12kg
Max ice storage	1.0kg
Max water storage	2.8kg
Clock function	No
Time setting	No
Filling water alarm	yes
Ice full alarm	yes
Functions Achieve	Button
Display mode	LED
Outer sizes	297×360×337mm
Net weight	11.5kg

Kindly Reminder:

- 1, Above datum are for reference only. Please check the Rating Label as Standard datum.. We will advise you timely while our appliace are upgraded.
- 2, For the technical questions, please contact the after sale service departments.

3. Setting timing turn-off. Press the SET button five times, 88 hour flashes, press the ▲ button to set hours. Press the SET button one time, 88 minutes flashes, press the ▲ button to set minutes;
4. Start the Automatic timing work mode. Press ▲ button to choose Automatic timing work mode, the modes exchanges from Timing turn-on, Timing turn-off, Timing turn-on-off. Default Timing turn-on time is 8:00, Default Timing turn-off time is 12:00.

VIII. Faults and Treatment

Faults	Reason	Treatment
Power indicator not light or Without Display.	Power Source is not switched on.	1.Check the power supply matches 2.Check the power cord is connected correctly 3.Internal components is damaged. Maintenance in professional department.
ICE FULL indicator is light or  flashes.	1.Ice fullness. 2.low-temperature protection(temperature is lower than 5℃.).	1.Remove the full Ice cube. 2.Move the Ice maker to a warmer place, where the ambient tempature is higher than 5℃.
 flashes.	Ice Making box is homing in wrong position.	1.check whether any foreign body stuck the ice making box. 2. Internal components is damaged. Maintenance in professional department.
 in  flashes.	Water Shortage	1. Add drinking water into Ice maker, and press  Button.  2. Water supply system is damaged, Maintenance in professional department.
Ice making performance is not good.	1.Heat elimination is bad. 2. Water temperture is too high. 3.Ambient temperature is too high. 4. Refrigerant leaks.	1. Clean the dust on the cooling fan and air inlet/outlet part. 2. Fill normal temperature water. 3. Do not place the appliance in high temperature conditions. 4. Refrigerating system is damaged. Maintenance in professional department.
Abnormal noise	Fan or pump is damaged.	1.Set up the appliance in right location. 2. Maintenance in professional department.

Basic Introduction


Ice maker is a professional product used to make ice cubes. With a luxurious appearance, Antiseptic internal material, it is suitable for long-term use. Automatically ice-making system work in ghih speed, and it always process the ice cubes in standard shape stabl. The ice cubes will not agglomerate, it is always easy-working and in good looking. Three different modes of ice cubes could be processed according to your personal setting.  
In order to keep the ice maker working efficiently and smoothly, please always follow our instructions to operate ice maker.

I. Product Features

1. Adopting compressor refrigerating technology, the ice maker process ice cubes very efficiently.
2. This Ice maker is widely used in various places, household, saloon, restaurant, etc.
3. Specific item has timing setting function, this improves the hommization of Ice maker.
4. Ice making status is watched through the transparent
5. Push-button operation. LED indicator light or LCD screen indicates the working status dynamically
6. Automatically reminding for water shortage and ice cubes fullness, ice making status is always mastered

II. Components’ Names

- ① Transparent window
- ② Cover
- ③ Operation panel
- ④ Air outlet
- ⑤ Air inlet
- ⑥ Power cord
- ⑦ Water outlet
- ⑧ Ice storage box
- ⑨ Evaporator
- ⑩ Ice making box



III, Safety precautions

1. Power source must be suitbale for the standards of Ice mker. If the voltage fluctuation range is big (Out of the rated voltage ± 10%), the ice maker may not work smoothly. In such conditions, please use the ice maker with a voltage regulator.

2. Hazardous articles which are explosive and flammable are prohibited to put inside ice maker. as well as highly corrosive acid and alkali.
3. While the power cord is damaged or the plug is in fault, stop ue ice Maker. Cable and plug shold be replaced by professional pesple.
4. Catch the plug to unplug it from the socket, do not pull the cable for unplugging.
5. Do not use ice maker in a place with coal gas or other flammable gas leakage.
6. Before cleaning or maintenance e, remember to unplug.
7. Ice maker is special for making ice cubes, do not use it to refrigerate food or beverages, so as to avoid machine damage.
8. Do not use or store gasoline or other flammable materials besides Ice maker, so as avoid fire disaster.
9. Unplug the cable before moving Ice maker, so as to avoid the damage to refrigerating system.
10. Without professional pesple, do not break down Ice maker, so as to avoid human hurt.
11. Never let children operate the appliance alone.
12. Only use the appliance for its intended purpose. The Appliance is not intended for use by persons (including Children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instructions concerning the use of the appliance by a person responsible for their safety.


IV. operating environment

1. Place the Ice Maker securely onto a sturdy and even surface.
2. Away from heating source and avoid direct sunlight, so as not to impact the ice-making performance
3. Make sure that the ventilation openings are not obstructed. Ensure that a minimum distance of 20cm is allowed between other appliance and walls.
4. Ambient tempertaure for Ice maker could not be less than 5℃.
5. Ice maker should not be used outdoor.

















V. Preparation For Use.

1. Break down all the package components.
2. Make an inventory accessories and instructions.
3. Place the ice maker in a suitable position.
4. It is better to clean the machine before use.

VI. Start to use

1. Switch on the power source. Do not turn on the appliance for a period of 30 minutes after moving the ice maker.
2. Fill the water tank with drinking water.
3. Press the  key to start making ice.

VII. Operation Panel

Button and Icon	functions
 Button	Making Ice, Standby, Eliminating faults.
SELECT Button	Selecting Ice cube size.
▲ Button	Setting Automatic timing work mode: timing turn-on or time-off or time trun-on-off.
SET Button	Setting time for Automatic timing work mode.
 Icon	Indicate Ice dropping faults.  Normal working displays 
 Icon in  Icon	Indicate water shortage, need filling water.
 Icon  Icon  Icon	Three moulds of Ice cube size. Large, Middle, Small. Default Setting is 
 Icon	Indicate Ice cube fullness.  Normal working displays 
 Icon	Display Real-time.
 Icon	Indicate that timing turn-on is launched.
 Icon	Indicate that timing turn-off is launched.
<b>88:88</b> Icon	24 hour clock system. Setting the real time, setting the desired time, setting the hours, setting the minutes the display will flash for 5 seconds. After switching on the default time is set at 12:00.
 Icon in  Icon	Flashes when making ice cubes. Inactive when the machine is on stand-by.

SETTING OF TIMING AUTOMATIC TURNING-ON-OFF MODE.

1. Setting Real time. Press the SET button one time, 88 hour flashes, press the ▲ button to set hours. Press the SET button one time, 88 minute flashes, press the ▲ button to set minutes
2. Setting timing turn-on. Press the SET button three times, 88 hour flashes, press the ▲ button to set hours. Press the SET button one time, 88 minutes flashes, press the ▲ button to set minutes;

