

Manual




Important tips: When pairing a device with Find My® app, the phone will link to the Apple® Server . Pairing may fail because of network problems. The following actions are recommended: Change the phone's servery such as cuitables between Wife network, such as switching between WiFi and mobile network.

01. Turn on the devicePress and hold the button for 3 seconds, and the device will beep and turn on Double press the button, A chime will sound. Note: To turn off, double-click the device first, then quickly press the button 5 times within 2 seconds, a long beep will sound.



02. Pair the device



Open the Find My app Make sure the Bluetooth is enabled.

Tap Items --> Add Other item --> Other Supported Item >Name the Item-->Choose an Emoji-->Play and stop sound



03. Locate Your QCQ Tag

03.1 Find QCQ Tag When It's Nearby:

Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap on your QCQ Tag from the list. Tap "Play Sound" to make your QCQ Tag beep. Tap "Stop Sound" to stop the beeps once you find.

03.2 Find QCQ Tag's Location:Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap on your QCQ Tag from the list. Your QCQ Tag's location will appear on the Map with a time stamp of when the item was located. To navigate to the QCQ Tag's location, tap "Directions" to open Apple Maps.

04. Notifications

04.1 Enabling "Notify When Left Behind":

Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap on your QCQ Tag from the list.
Under "Notifications" enable the "Notify When Left Behind" toggle. You will receive a notification when you leave your QCQ Tag behind and it's no longer in range of your device.

O4.2 Enabling "Notify When Found":
Under "Notifications", enable the "Notify When Found" toggle.
When your QCQ Tag is seen by another Find My network
device, you will receive a notification of its location.
Note: "Notify When Found" can only be activated when your
QCQ Tag is out of range.

05. When Your QCQ Tag Is Lost

05.1 Enabling "Lost Mode":

Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap on your QCQ Tag from the list.

Under "Lost Mode" tap "Enable". A screen detailing Lost Mode will pop up, tap "Continue"Enter your phone number or email address and tap "Next".

You may enter a message that will be shared with the person that finds your item. Tap "Activate" to enable "Lost Mode" Note: When "Lost Mode" is enabled, "Notify When Found" is

automatically enabled.

Note: When" Lost Mode" is enabled, your QCQ Tag is locked and cannot be paired to a new device.

06. Resetting QCQ Tag

06.1 Remove The QCQ Tag From Find My App:

Open Find My app and select the "Items" tab.
Tap on your QCQ Tag from the list.
please ensure "Lost Mode" is disabled.
Scroll to the bottom of the screen and tap "Remove Item". A summary will open, tap "Remove" to confirm.

06.2 Connect Your QCQ Tag

After successfully removing the QCQ Tag from Find My app, Quickly press the button twice. A chime will sound. then, Press and hold the button for about 5 seconds after the second confirmation chime sound, Press and Hold again for another 3 seconds until you hear a prompt sound to reset the device.

The QCQ Tag is now reset and ready to be paired to a new Apple ID.

07. Extras

07.1 Replace The Battery:Carefully open the shell along the gap in the middle of the QCQ Tag Replace the battery with a new CR2032 battery, with the positive side facing up (with the text side facing up).

Carefully close the QCQ Tag by aligning the top holes on both sides




07.2 Unwanted tracking:

If any Find My network accessory separated from its owner is seen moving with you over time, you'll be notified in one of two ways:

- 1. If you have an iPhone, iPad®, Find My will send a notification to your Apple device. This feature is available on iOS or iPad OS 14.5 2. If you don't have an ios device or a smartphone, a Find My network
- accessory that is n't with its owner for a period of time will emit a sound when it's moved.

These features were created specifically to discourage people from trying to track you without your knowledge.



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular

installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected Apple Find My network product specifications and requirements. Apple

is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards. Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used

08. About Apple Find My

The Apple Find My network provides an easy, secure way to locate compatible personal items using the Find My app on your iPhone, iPad, Mac®, or the Find tems app on Apple Watch.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet.

09. The Fine Print

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. NOTE: The manufacturer is not responsible for any radio or TV interference

caused by unauthorized modifications or changes to this equipment. Such modifications or changes not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

The device has been evaluated to meet general RF exposure requirement, The device can be used inportable exposure conditions without restriction. Federal Communication Commission (FCC) Radiation Exposure Statement Power is so low that no RF exposure calculation is needed.

WARNING INGESTION HAZARD: This product contains a button cell or coin battery

- DEATH or serious injury can occur if ingested.
 A swallowed button cell or coin battery can cause Internal Cl
 Burns in as little as 2 hours.
 KEEP new and used batteries OUT OF REACH of CHILDREN
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.



- Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
 - Even used batteries may cause severe injury or death Call a local poison control center for treatment information.
- Compatible battery type: CR2032 Nominal battery voltage: 3V
- Non-rechargeablebatteries are not toberecharged
- Do not force discharge,recharge,disassemble,heat above 40°C or incinerate Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
- Ensure the batteries are installed correctly according to polarity(+ and -). • Do not mix old and new batteries, different brands or types of batteries, such as
- alkaline, carbon-zinc, or rechargeable batteries.

 Remove and immediately recycle or disposeof batteries from equipment not used for an extended period of time according to local regulations..
- Always completely secure the battery compartment if the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

under license.