


LUMBAR SUPPORT INSTALLATION INSTRUCTIONS.


LUMBAR SUPPORT PART LISTS



NO	PART NUMBER	DESCRIPTION	QTY
1	8858687352545	HUNG SEAT LUMBAR SUPPORT	1
2	3101040162000	LUMBAR TOP RAIL SLIDER CONNECTOR	1
3	2101080131000	LONG BUSH	2
4	50071	SCREW TH STL M4x15	2
5	50057	SCREW JT STL M6x40	2
6	50142	SCREW JT STL M6x60	2
7	2101080159000	SHORT BUSH	2


LUMBAR SUPPORT INSTALLATION MANNUAL

1.INSTALL LUMBAR BOTTOM FRAME WITH BACKREST FRAME.




NOTE:


1. ADD THE SHORT PLASTIC BUSH WHEN INSTALL WITH THE MOKEN 10 V.2 / MOKEN12.5 V.2 / SEASTREAM ANGLER 120 / SEASTREAM ANGLER 120 PD / BIGFISH 105 V.2 / FLASH PD BACKREST FRAME.
2. ADD THE LONG PLASTIC BUSH WHEN INSTALL WITH THE BIGFISH 103 / 108 / 120 V.2 / JONNY BACKREST FRAME.
3. FOR THE MOKEN 10 LITE V.2 / MOKEN 10 PDL NOT USE THE PLASTIC BUSH.




2.INSTALL LUMBAR TOP FRAME WITH LUMBAR BOTTOM FRAME.




NOTE 1: ADJUST LEVEL OF THE TOP FRAME FOR FIT WITH THE BACKREST FRAME BAR.





2.DRILL 3.0 MM HOLE AND SCREW THE LUMBAR BOTTOM FRAME TOGETHER WITH LUMBAR TOP FRAME.




3.TIGHTEN THE ADJUSTER CORD.




4.INSTALL THE BUNGEE.



4. HOW TO ADJUST THE LUMBAR SUPPORT TO UP AND DOWN POSITION.





- TURN THE ADJUST KNOB TO CLOCKWISE DIRECTION FOR ADJUST THE LUMBAR SUPPORT TO DOWN POSITION.




- TURN THE ADJUST KNOB TO COUNTERCLOCKWISE DIRECTION FOR ADJUST THE LUMBAR SUPPORT TO UP POSITION.


5. HOW TO ADJUST THE LUMBAR SUPPORT FRONT AND BACK POSITION.



- TURN THE LUMBAR PROTRUDE ADJUST KNOB TO CLOCKWISE DIRECTION FOR ADJUST THE LUMBAR SUPPORT TO FRONT DIRECTION.




- TURN THE LUMBAR PROTRUDE ADJUST KNOB TO COUNTERCLOCKWISE DIRECTION FOR ADJUST THE LUMBAR SUPPORT TO BACK DIRECTION.



LUMBAR SUPPORT TIPS

- 1.CHANGE THE BACKREST PAD WHEN INSTALL THE LUMBAR SUPPORT WITH OLD HUNGSEAT BACKREST FRAME.




- 2.TAKE OFF THE OLD BACKREST PAD FROM BACKREST FRAME.




- 3.PUT THE NEW BACKREST PAD COVER THE BACKREST FRAME.



4. TIGHTEN THE ROPE FOR MAKE THE BACKREST PAD FIT WITH THE BACKREST FRAME.



5. TIGHTEN THE STRAP FOR HOLD THE BACKREST PAD.



LUMBAR SUPPORT TIPS

1. MAKE SURE ALL NUTS AND BOLTS ARE TIGHT.
2. MAKE SURE UNIT IS RINSED WITH WATER AFTER USE DO NOT USE A PRESSURE WATER.
3. MAKE SURE THE UNIT IS COMPLETELY DRY BEFORE STORING.
4. ALWAYS STORE IN A DRY PLACE, PREFERABLY.