


# Manual

## G-TEK CYBORG 700 WIRELESS GAMING MOUSE

GK-CBMS3DURL



### USING THE MOUSE

- Wireless mode: connect the USB receiver to your PC and move the switch located under the mouse to the ON position.

- Wired mode: connect the mouse to your PC via the USB cable.

### CHARGING THE BATTERY

Use the supplied USB cable to charge the battery. Charging speed will depend on power output of the connected port. For quicker charges we recommend using a dedicated fast charger. The logo on the mouse indicates the battery status:

Low battery:  
logo turns red and  
blinks

Charging:  
logo turns yellow  
and blinks

Charge complete:  
logo turns  
green

### DPI CONTROLS:

5 DPI levels can be toggled by pressing the DPI button. The LED light will briefly illuminate to indicate the DPI value

Red: 800DPI

Green: 2400 DPI

Purple: 16000 DPI

Blue: 1200 DPI

Cyan: 6400 DPI

### SPECIFICATIONS:

Sensor Type: PixArt3335

IPS: 400

Acceleration: 40G

Operating Cycles: 20 million clicks

Latency: 1µs

Battery: 930mAh 3.7V

# WARRANTY AGAINST DEFECTS

Laser warrants your new product to be free from defects in materials and workmanship for 12 months, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. The benefit of this warranty is in addition to your rights under the Australian Consumer Law and to other rights and remedies of the consumer under a law in relation to the goods or services to which the warranty relates.

Through a network of retailers and resellers, Laser will provide you with your choice of a refund, repair, or exchange (where possible) for this product if it becomes defective within the warranty period. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse, normal wear and tear, neglect, or improper storage.

## **Please retain your receipt as proof of purchase**

How to make a product warranty claim:

1. Find your receipt with date of purchase. If this is not available, Laser will make an assessment based on the date of manufacture, condition of the product and type of defect.
2. Please contact your original place of purchase. They will assess the nature of the fault and refund or replace the product as per their store refund or warranty policy.
3. If your original place of purchase cannot be contacted, please contact Laser with a description of the fault. To assist our team in providing you with a quick resolution, please include any photos and/or a short video demonstrating the fault with your product.
  - Phone: (02) 9870 3355
  - Email: [support@laserco.com.au](mailto:support@laserco.com.au)
  - Online: [www.laserco.net/support/warranty](http://www.laserco.net/support/warranty) and follow the website instructions
  - Business Address: U1 6-8 Byfield Street, Macquarie Park, 2113, NSW, Australia
4. Laser will review your claim and in the first instance, attempt to troubleshoot and resolve the issue for you without the need to return the product.
5. If it is determined via troubleshooting that your product may be faulty, our team will provide instructions to have the product returned for assessment. If the product does need to be returned within the warranty period, Laser will arrange return shipping at no cost to you.
6. Once we receive the product, our experienced technicians will assess it and determine how best to resolve the issue.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For more  
helpful guides  
visit us at



**LASER**

[www.youtube.com/LasercoAu](http://www.youtube.com/LasercoAu)

[www.laserco.com.au](http://www.laserco.com.au)



SCAN ME