


oricom®



RVSL01

Smart RV Leveller

User Guide

For full product and warranty information, scan the QR code on the right.

For a complete list of instructions and FAQs, visit oricom.com.au



Introduction

The Oricom Smart RV Leveller is designed to simplify the process of levelling your recreational vehicle (RV) for a more comfortable and stable camping experience.

Please read this manual carefully before using the product.

Package Contents



RVSL01



3M Tape



2 x Screws



2 x AA Batteries



User Guide

Features

- **Wireless Operation:** Control your RV's levelling navigator wirelessly through an app.
- **Precise Levelling:** Utilises advanced sensors to ensure accurate levelling of your RV.
- **Easy Installation:** Mounting screws and 3M tape included for hassle-free setup.
- **User-Friendly Interface:** Intuitive app for effortless operation.
- **Durable Construction:** Designed to withstand the rigors of RV travel and outdoor use.

Installation



Connect Power

Insert the 2 x AA batteries provided into the navigator as shown. Your RV should be parked relatively flat and level for the initial setup to obtain your "set level" in the App.



Installation

Choose a convenient location inside your RV to mount the leveller using the provided screws and 3M tape. Don't forget to leave enough space to access the battery compartment for easy battery replacement when needed.

Note: Mount upright facing inwards, see image in App for location and orientation.



Wireless Control

Launch the app to seamlessly begin levelling your recreational vehicle.

Operation

Powering On

After installing the product, briefly press the power button to turn it on. The buzzer will emit one beep.

To turn off, press and hold power button until you hear two beeps.

App Control

Download the free Oricom app from Google Play or the iOS App Store.

Scan QR code on the right to download the app.



Troubleshooting

If you encounter any issues with the Oricom Smart RV Leveller, please refer to the following troubleshooting guide for possible solutions:

Issue: Navigator not powering on

- Ensure the two AA batteries are not damaged and still have power.
- Make sure to insert the AA batteries with correct polarity.
- Contact customer support if the issue persists.

Issue: Inaccurate measurements

- Make sure the surface where the RV is parked is relatively flat and stable.
- Check for any obstructions or debris preventing proper levelling.
- If the issue continues, reach out to customer support for guidance.

For any other concerns or technical assistance, reach out to our dedicated customer support team.

Oricom Support

E: support@oricom.com.au

P: (02) 4574 8888

Monday - Friday

8am-6pm AEST

Specifications

Item	Option	Specification
Voltage	Operating Voltage	2.09V~3V
Battery	Type	AA
Power Consumption	Average Working Current (phone connected)	Less than 800uA
	Standby Average Power (without connection)	Less than 50uA
Communication	Wideband Data Transmission	2.4Ghz GFSK AS/NZS 4268
Range	2.4Ghz	Less than 10m
App Name	Oricom Auto	
RV Types	Travel Trailer, Fifth Wheel, Popup/Hybrid Camper, Class B or Class C, Class A	
RV Size	Width	152cm-305cm
	Length	152cm-1676cm
Default Size	Width	244cm
	Length	1457cm
Installation Direction	Front/Back/Left/Right	
Angle	Front/Back/Left/Right	0°-30° (±0.6°)
Dimensions (RVSL01)	Length×Width×Height	92.4×66.45×25.45mm
Operating Environment	Temperature	0°C-40°C
	Humidity	5%-75%RH non-condensing
Storage Environment	Temperature	-10°C-70°C
	Humidity	5%~75%RH non-condensing

Express Warranty (Australia)

This Express Warranty is provided by Oricom International Pty Ltd ABN 46 086 116 369, Unit 1, 4 Sovereign Place, South Windsor NSW 2756, herein after referred to as "Oricom".

Oricom warrants that the product is free from defects in materials or workmanship during the Express Warranty Period. This Express Warranty does not extend to any product from which the serial number has been removed or was purchased outside of Australia.

The benefits of this Express Warranty are in addition to other rights and remedies you may have under the Australian Consumer Law. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. In the event of a minor failure, Oricom reserves the right to choose to repair or replace the product.

The Express Warranty Period will be a period of 2 years beginning on the date of purchase of the product evidenced by your dated sales receipt. You are required to provide proof of purchase as a condition of receiving Express Warranty services.

You are entitled to a replacement product or repair of the product at our discretion according to the terms and conditions of this document if your product is found to be faulty within the Express Warranty Period. This Express Warranty extends to the original purchaser only and is not transferable.

Products distributed by Oricom are manufactured using new materials or new and used materials equivalent to new in performance and reliability. Spare parts may be new or equivalent to new. Spare parts are warranted to be free from defects in material or workmanship for thirty (30) days or for the remainder of the Express Warranty Period of the Oricom branded product in which they are installed, whichever is longer. During the Express Warranty Period, Oricom will where possible repair and if not replace the faulty product or part thereof. All component parts removed under this Express Warranty become the property of Oricom. In the unlikely event that your Oricom product has a recurring failure, Oricom may always, subject to the Competition and Consumer Act 2010, at its discretion, elect to provide you with a replacement product of its choosing that is at least equivalent to your product in performance.

No change to the conditions of this Express Warranty is valid unless it is made in writing and signed by an authorised representative of Oricom.

Oricom will not be liable under this Express Warranty, and to the extent permitted by law will not be liable for any defect, loss, damage or injury arising out of or in connection with a:

1. Failure by you to adhere to the warnings and follow the instructions set out in this user guide for the proper installation and use of the product;
2. Willful misconduct or deliberate misuse by you of the product;
3. Any external cause beyond our control, including but not limited to power failure, lightning or over voltage; or
4. Modification to the product or services carried out on the product by anyone other than Oricom or Oricom's authorised service provider.

How to make a claim under your Express Warranty in Australia

Oricom has a simple warranty process for you to follow:

- Please call or email our Customer Support Team, 02 4574 8888 or support@oricom.com.au.
- A Customer Support Team member will verify after troubleshooting with you if your product qualifies under warranty. If so, they will give you a Product Return Authorisation number.
- We will then email a Return Authorisation form and a Repair Notice (if necessary), together with instructions on how to return the product for warranty service.

Please note that if a Customer Support Team member advises that your product does not qualify for return, this warranty does not apply to your product. Products that are authorised to be returned to Oricom in Australia must include all of the following:

- A completed Return Authorisation form
- A copy of your Proof of Purchase (please keep your original copy)
- The faulty product, including all accessories.

Send the approved returns to:

Oricom International Pty Ltd
Locked Bag 658
South Windsor NSW 2756 Australia

Please note that this Express Warranty excludes expenses incurred by you in returning any faulty product to us. You must arrange and pay any expenses incurred (including postage, delivery, freight, transportation or insurance of the product) to return the faulty product to us, however, we will arrange delivery of the repaired or replaced faulty product to you.

Important Information

Repair Notice

Please be aware that the repair of your products may result in the loss of any user-generated data (such as stored telephone numbers, text messages and contact information). Please ensure that you have made a copy of any data saved on your product before sending for repair. Please also be aware that products presented for repair may be replaced by refurbished products or parts of the same type rather than being repaired.