


PLATFORM C-KING BED

ASSEMBLY INSTRUCTIONS


BOX #1

- A. HEADBOARD PANEL 1 PC
- B. LEFT HEADBOARD LEG 1 PC
- C. RIGHT HEADBOARD LEG 1 PC
- D. FOOTBOARD 1 PC
- HEADBOARD HARDWARE BOX*




BOX #2

- E. LEFT SIDE RAIL 1 PC
- F. RIGHT SIDE RAIL 1 PC
- G. CENTER SLAT 1 PC
- H. SUPPORT LEG 4 PCS
- BED HARDWARE BOX*




BOX #3








- I. SLAT ROLL 1 SET



PLATFORM BED ASSEMBLED



BED HARDWARE PACKED IN BOX #2



| | | | | | | | | | | | |
|---|----------------------------|---|---|---|--------|---|------------------|-------|---|--------------------|-------|
| 1 | PHILLIPS HEAD BOLT(8x20mm) | 8 PCS | 2 | SPRING WASHER (M8) | 8 PCS | 3 | FLAT WASHER (M8) | 8 PCS | 4 | METAL PIN (8x40mm) | 2 PCS |
|  | |  | |  | |  | | | | | |
| 5 | WOOD SCREW (8x30mm) | 9 PCS | 6 | ALLEN BOLT (6x40mm) | 11 PCS | 7 | ALLEN KEY | | | 1 PC | |
|  | |  | |  | | | | | | | |

HEADBOARD HARDWARE PACKED IN BOX #1

| | | | | | | | | | | | |
|---|---------------------|-------|---|---------------------|-------|---|---------------------|-------|---|-----------|------|
| 1 | ALLEN BOLT (6x35mm) | 2 PCS | 2 | ALLEN BOLT (6x55mm) | 2 PCS | 3 | ALLEN BOLT (6x70mm) | 2 PCS | 4 | ALLEN KEY | 1 PC |
| | | | | | | | | | | | |


TOOL REQUIRED : PHILLIPS HEAD SCREWDRIVER (NOT PROVIDED)

YOUR BOX
MAY CONTAIN
EXTRA HARDWARE




STEP 1 :

*USE HEADBOARD HARDWARE FROM BOX #1 FOR STEP 1.




STEP 2 :


*USE BED HARDWARE FROM BOX #2 FOR THIS, AND ALL REMAINING STEPS.



STEP 3 :




STEP 4 :




STOP

- IF USING BED FRAME WITH ADJUSTABLE MATTRESS BASE, SKIP TO APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT.
- IF USING BED FRAME WITH STANDARD BOX SPRING OR FOUNDATION CONTINUE TO STEP 5.


STEP 5 :



STEP 6 :



STEP 7 :




INSTRUCTIONS FOR ADJUSTING LEVELERS:

POSITION THE BED IN YOUR ROOM. LOCATE LEVELERS UNDER EACH SUPPORT LEG (H).

TURN LEVELERS COUNTER-CLOCKWISE TO EXTEND, CLOCKWISE TO RETRACT.

ADJUST LEVELERS UNTIL EACH SUPPORT LEG IS APPLYING EQUAL UPWARD PRESSURE ON THE CENTER SLAT.



MAINTENANCE INSTRUCTIONS:

- REMOVE BOX SPRING AND MATTRESS BEFORE MOVING YOUR BED.
- LIFT YOUR BED WHEN MOVING IT. DRAGGING CAN DAMAGE THE SUPPORT LEG.
- READJUST LEVELERS AFTER MOVING YOUR BED.

PLATFORM C-KING BED

APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT

AN ADJUSTABLE MATTRESS BASE IS A FREESTANDING MATTRESS SUPPORT THAT SITS WITHIN THE PERIMETER OF THE BED FRAME.

IF USING THIS BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION THESE INSTRUCTIONS DO NOT APPLY.


PRE-ASSEMBLED SIDE RAIL CLEATS OBSTRUCT ADJUSTABLE BASE INSTALLATION AND OPERATION. FOLLOW THESE INSTRUCTIONS TO REMOVE THEM.

THE FOLLOWING PARTS ARE NOT REQUIRED FOR ADJUSTABLE MATTRESS BASE INSTALLATION:

| | | | |
|----------------|-------|------------------------|--------|
| G. CENTER SLAT | 1 PC | 5. WOOD SCREW (8x30mm) | 9 PCS |
| H. SUPPORT LEG | 4 PCS | 6. ALLEN BOLT (6x40mm) | 11 PCS |
| I. SLAT ROLL | 1 SET | | |

STEP 1 :

USE ALLEN KEY (7) TO UNSCREW ALLEN BOLTS AND REMOVE PRE-ASSEMBLED SIDE RAIL CLEATS.



NOTE: YOU MAY WISH TO RETAIN UNUSED PARTS IF IN THE FUTURE YOU INTEND TO USE THE BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION.