


WIRELESS CHARGE INSTRUCTION 1. When charging the product, connect the USB port of the USB data cable to the power adapter, The Type-C port is connected to the wireless charger, and there is a " 🕪 " indicator light in the clock display area. The suction flashes, and the " 💅 " indicator

Bluetooth-Funktion

light turns off after it is fully charged. 2. When charging the mobile phone, connect the product to the power supply, and place the mobile phone in the charging in dication area of the product.The charging indicator " 🗲 " above the clock display area is always on.



WIRELESS SPEAKER INSTRUCTIONS

In clock display mode, press 🛭 to turn on Bluetooth, and a prompt tone will appear The "BT" will be displayed in the clock display area, indicating that the speaker is searching for pairing status. At this time, turn on the Bluetooth function of your mobile phone the word " Sound Station " will appear when you search for the Bluetooth audio. Click and select the device name Sound Station Automatically enter the pairing. After the pairing connection is successful, there will be a prompt tone,BT steady on. After connecting Bluetooth successfully, you can synchronize the phone time.

When the stereo is playing

- . Long press (a) to turn on, short press once to enter Bluetooth mode, short press to to furn on, short press once to enter buteroon mode, short press for the second time to enter radio mode to enter radio mode. Long press to turn off the speaker.

 Short press to to play/pause.
 Short press to increase the volume.
 Short press to reduce the volume.



FM OPERATION MODE

In clock display mode, press M twice to turn on FM, and the clock display area will display FM steady on. When the FM is playing

- Long press
 auto search for radio stations.
- It will play automatically when finished. • Tap 📵 Play/Pause.
- Short press to increase the volume.
 Short press reduce the volume;
- Short press 🔇 to change the channel up. Short press 🦻 down to change the channel;

CLOCK SETTING

- Long press ⊚ to switch to 12/24 hour system. Short press (a) to switch 12/24 hours.
- Short pess 👀 again to enter the clock setting state, Short press 🕕 / 🖨 to adjust the hour.
- press • / • to adjust the minutes, and press • again to save the current Settings.

THE TEMPERATURE (° C / ° F) IS SWITCHED

Double press
 M to switch ° C / ° F

ALARM SETTING

1. Long press **③** setting Alarm 1, the hour will flash, press +/- to adjust the hoshort press **③**, minute will flash, press+/- to adjust the minute. Short press (a) to adjust the volume of Alarm 1, press +/- to adjust the volum Short press (b) to set Alarm 2, the hour flashes, press +/- to adjust the hour short press (a), the minute will flash, press+/- to adjust the minutes

Short press (1) to adjust the volume of Alarm 2, press+/- to adjust the volume short press to confirm the volume and alarm settings 2. Short press (1) to turn on alarm 1/Alarm 2/off alarm 1/alarm 2.

Adjust the alarm volume

• When the alarm goes off, press () to adjust the alarm tone; • When the alarm goes off, tap the side to touch the switch, you can snooze for 5 minutes, and enjoy snooze for 4 times in total; Long touch the side to stop the current alarm.



ADJUST SCREEN BRIGHTNESS

NIGHT LIGHT FUNCTION

Long touch side to turn on/off night light • Short touch side to turn on circulation mode successively: low light- high light-RGB colors cycle light

Bluetooth mode:

• Long touch side to turn on/off night light Short touch side to turn on circulation mode successively:
 low light- high light -RGB colors cycle light-The lights change with the rhythm of the music

• Use the audio connection cable, connect the external device, can control the stereo to play music.

APPLICABLE DEVICE

This product supports fast wireless charging, which complies with the QI wireless charging standard; it realizes short-distance wireless power transmission through magnetic induction. This device supports all wireless charging devices that meet the QI standard. When using a 5V output adapter, Wireless charging supports 5W load. When using an adapter that meets QC2.0 and above standards, the wireless charging supports 10W load; Support overcharge protection (9V) and overcurrent protection (2A).

ATTENTION POINTS

SPECIFICATIONS

Power Input: DC5V-9V=3A

Charging Efficiency: 75% Wireless Power: 15W (9V/1.67A)

Bluetooth ID: D064893

Speaker Power: 5WX2 Battery Capacity: 1200 mAh Product size: 235 x 115 x 92 mm

Play Time: 3 hours

 Do not use or store the product in direct sunlight or high temperature places for a long time. • Do not charge in places too close to magnetic cards, magnetic

• Product working environment temperature range: -20~45°C.

XOPOPPY[®] COPYRIGHT ALL RIGHTS RESERVED. XOPOPPY[®] is an innovative brand of Truststone Group LLC. No portion of this design may be reproduced without express written permission. Other trademarks and trade names are those of their respective owners. All rights reserved. Distributed by Truststone Group LLC. New York, NY 10018

recording media, and precision instruments. • Do not disassemble or modify this product. • Do not touch the AC adapter with wet hands.

Product Material: Imported ABS + Hardware

- Keep this product away from water or other liquids. • If you want to clean the product, please disconnect the power.
- may cause undesiredoperation.

 FCC Warning Statement
 Changes or modifications not expressly approved by the party responsible for compliance could
 void the user's authority to operate the equipment. This equipment has been tested and found to
 comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.
 These limits are designed to provide reasonable protection against harmful interference in a
 residential installation. This equipment generates uses and can radiate radio frequency energy
 and, if not installed and used in accordance with the instructions, may cause harmful interference
 to radio communications. However, there is no guarantee that interference will not occur in a
 particular installation. If this equipment does cause harmful interference to radio or television
 reception, which can be determined by turning the equipment off and on, the user is encouraged
 to try to correct the interference by one or more of the following measures:

 Reorient or relocate the receiving antenna.

 Increase the separation between the equipment and receiver.

 Connect the equipment into an outlet on a circuit different from that to which the
 receiver is connected.

 Consult the dealer or an experienced radio/TV technician for help.
 - RF Exposure Statement (Bluetooth)
 The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesiredoperation.

- RF Exposure Statement (Wireless Charger)
 To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum distance of 20cm the radiator your body.

CE 🗷 😂 🖐 Rohs FC