



**Green Lion**

## **10000mAh VOLT GAUGE Power Bank**


SKU: GNVLPX44P10

Model No: GL-PX44

## Table of Contents

Schematic View	2
Specifications	2
Important Safety Instructions	3
Low-Current Mode	4
Disposal	5
Warranty	5
Contact Us	5

## Schematic View



## Specifications

Model No.	GL-PX44
Material	ABS+PC
Battery	10000mAh
USB-C1 Input	5V/3A, 9V/2A, 12V/1.5A (18W Max)
USB-C2 Input	5V/3A, 9V/2A, 12V/1.5A (18W Max)
USB-C1 Output	5V/2.4A, 9V/2.22A, 12V/1.67A, 10V/2.25A (PD22.5W)
USB-C2 Output	5V/2.4A, 9V/2.22A, 12V/1.67A, 10V/2.25A (PD22.5W)
Wireless Output	15W Max
Product Weight	198 g
Product Dimensions	106*66*19.4 mm

## Important Safety Instructions

1. Inspect the product before first use. Immediately discontinue use if there are any signs of swelling, deformation, leakage, or other abnormalities.
2. Fully charge the product before its first use. If the product is not in use for an extended period, charge and discharge it at least once every three months.
3. Only use certified charging cables and chargers that meet the product's nominal specifications for charging and discharging.
4. Never leave the product unattended while charging. Always unplug it when leaving for extended periods.
5. The recommended operating ambient temperature is 0°C to 25°C for optimal performance. The recommended storage ambient temperature is 0°C to 40°C.
6. Do not leave the product inside a car, as high temperatures from sunlight may cause damage.
7. Keep the product out of the reach of children and prohibit them from using or playing with it to avoid accidents.
8. If the product shows signs of swelling, deformation, leakage, significant capacity reduction, or water immersion, stop using it immediately and dispose of it properly.
9. Never disassemble, crush, puncture, short-circuit, or throw the product into water or fire (including stoves, heaters, or other heat sources). Do not expose it to temperatures above 60°C (140°F).
10. The product contains a lithium polymer battery. Unauthorized disassembly is strictly prohibited to prevent battery damage or other hazards.
11. The battery may explode or leak flammable liquid/gas under extreme low pressure.
12. Dispose of the product properly when discarding.

## Low-Current Mode

Press and hold the power button for 3 seconds to activate Low-Current Mode (indicated by a chasing segment effect on the last digit). This mode is optimized for small devices such as watches, wristbands, earbuds, etc., while still supporting normal charging for phones and tablets. The mode will automatically turn off after 2 hours, or you can manually deactivate it by pressing and holding the power button for another 3 seconds.



## Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

## Warranty

Products that you buy directly from our **Green Lion** website or shop come with a 24-month warranty.

When you buy **Green Lion** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at <https://www.greenlion.net/warranty> and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:  
<https://www.greenlion.net/warranty>

## Contact Us

If you have any questions about this Privacy Policy, please contact us at:

Website: <https://www.greenlion.net/>

Sales: [sales@greenlion.net](mailto:sales@greenlion.net)

Service Support: [Support@greenlion.net](mailto:Support@greenlion.net)

Telegram: [@greenlion\\_global](https://t.me/greenlion_global)

Instagram: [@greenlion\\_global](https://www.instagram.com/greenlion_global)