




# LED Spot Light

SKU:HGSL10A  
[Instruction Manual]



Thank you for your purchase.  
Please contact us if you have any questions.  
We will get back to you within 24 hours.  
Please attach your Order ID so that  
we can serve you better.

## FCC Warning :


Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

## Product Layout




## Installation



**WARNING:** Never push the fixture into the ground by the lamp body (A) or use a hammer to insert the ground stake (C) into the ground.


### 1. Installing the light

- Prepare a hole in the installation location. Use a tool such as a screwdriver (sold separately) to prepare the installation hole to ensure the hole is not larger than the ground stake (C).
- Install the fixture in the ground by pushing on the foot step (1) on the ground stake (C). Do not push on the lamp body (A).
- The lamp body (A) can rotate up and down 90 degrees.




### 2. Connecting the power

- After the fixture is installed, insert the plug (D) into an outlet



### 3.Adjusting the illumination, brightness output of the light

- Choose your preferred lumen output from two options: High light or Low light.
- The light cycles from High light (552lm) → OFF → Low light (398lm) → OFF → High light (552lm) → OFF → Low light (398lm) , etc.
- Push the switch (B) to cycle through the above selections.



## Troubleshooting

Problem	Possible Cause	Solution
The fixture will not light	There is no power	<ul style="list-style-type: none"><li><input type="checkbox"/> Ensure the Plugged into the GFCI wall outlet</li><li><input type="checkbox"/> Ensure that a bresker or GFCI circuit has not been tripped</li></ul>

## Care and Cleaning

- Clean the fixture with a soft dry cloth.
- Do not use any cleaners with chemicals, solvents or harsh abrasives.

## Specifications

- Input Voltage: 120VAC, 60Hz
- Power Rating: 5.15W (398lm)  
7.84W (552lm)
- Luminance: 398lm (5.15W)  
552lm (7.84W)
- Color Temperature: 3000K
- Life span: 50000 hours
- CRI: 80+
- Warranty: 1 years

## One Year Limited Warranty

EDISHINE warrants this product to be free from defects in material and workmanship for a period of one year from the date of purchase. Warranty is void if damage is caused by misuse or improper installation. Our dedicated customer service team will get back to you within 24 hours.

