

57x68mm

Wi Fi network intelligent camera instruction manual




1. Download and install APP
1. Quickly download and install by scanning QR code
2. Search "V360 Pro" in App store or google play, download and install
3. Go to the official website www.cloudbirds.cn and scan the code to download



V360 Pro

2. Sign in
1. New users need to register their accounts. Click "Register Now" to enter the registration page
2. Select your country, enter the account name (phone number or email), and register according to the prompts through code verification
3. For an existing account, you can directly enter the account name and password to log in




3. Three methods for camera connection. When configuring Wi-Fi for the first time, please place the camera as close to the Wi-Fi router as possible, and then install it to the location you need to install after the configuration is completed. If the installation location is far from the router, please directly connect the camera with the network cable.


- 3-1 Add Device by AP hotspot: power up the camera and wait for the camera to start successfully after hearing the voice prompt from Camera, open the mobile phone APP - click the right "+" in the upper corner - select "hot spot adding" and follow the lead.




- 3-2 Add device by QR Code




3-4 Add Device By Network cable




4. Home Page




5. Real time screen



6. Sharing function



9. Cloud storage playback



FAQs:
1. What should I do if I can't connect to the network?
A. If the camera is 100% connected to the network when connected to the network cable, open "Network cable to add camera" on the add page in the APP.
B. If you use Wi-Fi, please ensure that the Wi-Fi password is correct, do not plug in the network cable, and listen to the camera. The camera sends out startup music, and after starting with the most pop, select the "network cable to add camera" next to the OK to operate according to the prompts. If there is a strong electricity interference around, or the Wi-Fi usage is peak, it is recommended to use the network cable to connect.
Note: It is preferred to ensure that the camera is powered on and can hear music from the camera during normal startup. The camera needs to use the standard power supply provided with the camera, and the power supply of the mobile phone cannot guarantee the normal operation of the camera.
2. What is the problem of image lagging?
The camera needs a certain optical bandwidth to maintain a stable connection. It is recommended that the upstream bandwidth of the network where the camera is located should be more than 2M, and the downstream bandwidth of the network where the mobile phone is located should be more than 2M. If the camera is connected to Wi-Fi, more people using Wi-Fi will also cause an image card. It is recommended that the camera plug in the network cable and try again.
3. Is it normal for the camera to enter slowly in the "connected" state when adding?
It is normal because the user information of the camera is being saved to the cloud service at this time, which requires time to communicate with each other. If the mobile phone is lost accidentally in the future, as long as the login account remains unchanged, all camera information does not need to be entered.



Câmara inteligente de rede Wi-Fi manual de instruções




1. Baixe e instale APP
1. Baixe e instale rapidamente digitalizando o código QR
2. Pesquise "V360 Pro" na App store ou google play, baixe e instale
3. Vá para o site oficial www.cloudbirds.cn e digitalize o código para baixar




V360 Pro

2. Login
1. Novos usuários precisam registrar suas contas. Clique em "Registrar-se agora" para entrar na página de registro
2. Selecione o seu país, digite o nome da conta (número de telefone ou e-mail), e registre-se de acordo com as solicitações através da verificação de código
3. Para uma conta existente, você pode inserir diretamente o nome da conta e senha para fazer login



3. Três métodos para conexão da câmera. Ao configurar Wi-Fi para o primeiro tempo, coloque a câmera o mais perto possível do roteador Wi-Fi, e então instale-o no local que você precisa instalar depois que a configuração for concluída. Se o local de instalação está longe do roteador, por favor conecte diretamente a câmera com o cabo de rede.

- 3-1 Adicionar dispositivo por ponto de acesso AP: ligue a câmera e espere que a câmera inicie com sucesso, depois de ouvir o prompt de voz da câmera, abra o celular APP de telefone - clique no "+" direito no canto superior - selecione "hot spot adding" e siga a liderança.



- 3-2 Adicionar dispositivo por QR Code



3-4 Adicionar dispositivo por cabo de rede




4. Página Inicial




5. Ecrã em tempo real



6. Função de partilha



9. Reprodução do armazenamento em nuvem



Perguntas frequentes:
1. O que devo fazer se não conseguir conectar-me à rede?
A. Se a câmera estiver 100% conectada à rede quando conectada ao cabo de rede, abra "Cabo de rede para adicionar câmera" na página de adição no APP.
B. Se você usar Wi-Fi, certifique-se de que a senha Wi-Fi está correta, não conecte o cabo de rede e clique a câmera a câmera envia música de inicialização e, depois de receber com o grito de reprodução, selecione o "cabo de rede para adicionar câmera" next to the OK to operate according to the prompts. If there is a strong electricity interference around, or the Wi-Fi usage is peak, it is recommended to use the network cable to connect.
Note: It is preferred to ensure that the camera is powered on and can hear music from the camera during normal startup. The camera needs to use the standard power supply provided with the camera, and the power supply of the mobile phone cannot guarantee the normal operation of the camera.
2. Qual é o problema do bloqueio da imagem?
A câmera precisa de uma certa largura de banda de upload para manter uma conexão estável. Recomendamos que a largura de banda upstream da rede onde a câmera está localizada seja superior a 2M, e a largura de banda downstream da rede onde o celular está localizado deve ser superior a 2M. Se a câmera estiver conectada a Wi-Fi, mais pessoas usando Wi-Fi também causarão uma imagem de bloqueio. Recomendamos que a câmera conecte o cabo de rede e tente novamente.
3. É normal que a câmera entre lentamente no estado "conectado" ao adicionar?
É normal porque as informações do usuário da câmera estão sendo salvas no serviço de nuvem neste momento, o que requer tempo para se comunicar entre si. Se o telefone celular for perdido acidentalmente no futuro, desde que a conta de login permaneça inalterada, todas as informações da câmera não precisam ser digitadas novamente.



FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

*RF warning

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.