

15HP Gas Engine Stump Grinder 13" Cutting Depth Model:AGT-SGR1500

Ver.1.1.3

TABLE OF CONTENTS

TABLE OF CONTENTS	2/6
TO THE OWNERS	
TO THE OWNERS	3/6
TO THE OWNERS	3/6
TO THE OWNERS SAFETY PRECAUTIONS	3/6

TO THE OWNERS

GENERAL COMMENTS

Congratulations for having this Stump Grinder! Your Stump Grinder was carefully designed and manufactured to give you years of dependable service. Your Stump Grinder will require some minor maintenance to keep it in top working condition.

Please observe all safety precautions and maintenance procedures as described in this manual.

BEFORE OPERATION

Thoroughly read and understand the instructions given in this manual before operation. Refer to the "Safety Label" section, read all instructions noted on them.

Do not allow anyone to operate his equipment who has not fully read and comprehended this manual and who has not been properly trained in the safe operation of the equipment.

SERVICE

Please remember to use only manufacturer replacement parts. Substitute parts may not meet the standards required for safe, dependable operation.

SAFETY PRECAUTIONS

BEFORE OPERATION

- 1. The operator must read the operation manual carefully before installation, operation or maintenance. Improper operation will cause the machine damage or the operator death.
- 2. Read all the safe signs and safe declarations. Follow all the professional safe terms, local laws or the professional directions.
- 3. Familiar with the Stump Grinder about functions, specs and operation. Replace the to-be-damaged parts in time. Make sure all the hydraulic installations and couplings connect firmly, and all the safe signs stick on the suitable positions clearly.



IMPORTANT

- 1. Operator should be familiar with all functions of the unit.
- 2. Make sure all guards and shields are in place and secured before operating implement.
- 3. Keep all persons away from equipment and work area.
- 4. Dismounting from a moving unit can cause serious injury or death.
- 5. Keep hands, feet, and clothing away from power-driven parts.
- 6. Detach and store implement in an area where children normally do not play. Secure implement by using blocks and supports.

Always wear proper safety glasses, goggles, or a face shield when driving pins in or out, or when any operation causes dust, flying debris, or any other hazardous material.

SAFETY PRECAUTIONS

Operator Safety

- ► Wear protective clothing and equipment appropriate for the job. Clothing should be snug fitting without fringes and pull strings to avoid entanglement with moving parts.
- ▶ Prolonged exposure to loud noise can cause hearing impairment or hearing loss. Wear suitable hearing protection such as earmuffs or earplugs.
- ▶ Operating equipment safely requires the operators all attention, Avoid wearing radio headphones while operating machinery.

Tool Safety

- ► Inspect entire machine before each use. Replace damaged or worn parts.
- ► Check for fuel leaks and make sure all fasteners are in place and securely fastened.







SAFETY PRECAUTIONS

Wear Protective Equipment

- ► Escaping fluid under pressure can penetrate the skin causing serious injury.
- Avoid the hazard by relieving pressure before disconnecting hydraulic lines or performing work on the system.
- ► Make sure all hydraulic fluid connections are tight and all hydraulic hoses and lines are in good condition before applying pressure to the system.
- ► Use a piece of paper or cardboard, NOT BODY PARTS to check for suspected leaks.
- ► Wear protective gloves and safety glasses or goggles when working with hydraulic systems.
- ▶ DO NOT DELAY. If an accident occurs, see a doctor familiar with this type of injury immediately. Any fluid injected into the skin or eyes must be treated within a few hours or gangrene may result.

Transportation and Storing

- ► Store machine and fuel where fuel vapors cannot reach sour combustion like, water heaters, electric motors, switches, furnaces, etc.
- ► Always secure the machine with tie downs or similar restraints when transporting.
- ► The machine be stored in a manner that prevents it from falling, rolling or tipping.



