
GY-Z5S英文说明书,正反彩印





1.Smart Phone:

Apple: iPhone 1212 Pro 12 Pro Max 12 mini SE 1111 Pro 11 Pro Max Xs Xs Max XR x 8 8 Plus Apple: Infinite 12,12F10,12F10 Max, 12 Illini,5c,1,11 F10,11 F10 Max, As, As Max, As Samsung: Galaxy S: 21 5G, 21+5G, 21 Ultra 5G,FE 5G,20 5G, 20+5G, 20 Ultra 5G, 10,10+,10e,9,9+,8,8+,7,7 edge,6,6 edge,6 edge+, 6 G9209,6 Active; Galaxy Note: 10,10e,10+,9,8,7,6,5.

Huawei: P30 Pro,P40 Pro,P40 Pro+; Mate: 40E, 40 RS, 40 Pro+, 40 Pro, 40,30E Pro, 30 5G, 30 Pro

5G,30,30 Pro, 30 RS,20 Pro,20 RS, RS; Xiaomi: 10,10 Pro,9,9Pro,Mix 3, Mix 2s.Including other devices with wireless charging receiver built-in; (Note: All devices must meet the Qi standard).

2.Smart Watch:
Apple: iWatch S1,S2,S3,S4,S5,S6,SE.

3.Earbuds: Apple: AirPods 1, AirPods 2, AirPods Pro

Product Specification

Input: 9V/2A,9V/2.7A or 12V/2A Phone Output: 15W/10W/7.5W/5W

Watch Output: 2.5W (Apple iWatch S1, S2, S3.S4.S5.S6.SE)

Earbuds Output: 2.0W Lightning (Apple AirPods 1, 2, AirPods Pro) Input Socket: Type-C

Transmission Distance(Phone): ≤5mm

Conversion Rate(Phone): ≥73%

Product Size: 136X101X136mm Weight: 329g

Accessories List

Wireless Charger*1, Type-C quick charge cable*1, QC3.0 adapter*1, User manual*1

 $1. Please \ keep the charger away from water or other liquid; \\ 2. If you need to clean the charger, please make sure it is not connected power supply; \\$

Answer questions

1. If you're experiencing interrupted or slow charging, check the following:

- If you're experiencing interrupted or slow charging, check the following:

 (1) The back of your phone should not have any metal, pop sockets, or credit cards.

 (2) Put the phone in the center of the charging surface (this lets the charging coil in your phone line up with the one inside the wireless charger).

 (3) The wireless charging coil on Sony phones is located slightly below center

 (4) Phone cases should be no thicker than 5 mm for effective charging.

 (5) Check whether the adapter is QC3.0 fast charger.

- 2. If you're failing to charge your device, please try out the following:

- 2.If you're failing to charge you'r device, please try out the following:

 (1) Please restart your ceell phone and test with other USB cable.

 (2) Please check whether the indicator turns on or not.

 (3) Please check the Adapter is QC3.0 Quick Charger (Output:9V/2A) or not, iPhone original adapter does not match the wireless charger.

 (4) Please check your Phone case thickness (<=5mm). Metal ring or Magnetic Pad will not be
- 3. If you're using the recommended wireless charger with the QC3.0 Adapter and have removed any potential charging obstructions, but are still experiencing issues, try:
- (1) Replacing the cable connecting your wireless charger. (2) Rebooting your phone. (3) Unplug the adapter and reinsert.

After-sales service

If your problem has not been solved by following the above steps, please reach out to us via Amazon's message center or info@waitiee.com. In order to solve it for you faster, please have the following information at hand: your phone's model, the type of wall charger you are using (with a link if possible). Optionally, you may include a video to illustrate the problem you are having.

CE F© RoHS



FCC Statement

This device complies with part 15 FCC Rules. Operation is Subject To the following two conditions:

(1) This device may not cause harmful interference, and (2) this devicemust accept any

interference received, including interference that may cause undesired operation.

Changes or modifications not explicitly approved by the partyresponsible for compliance could void the user's authority tooperate this equipment.

Note: this equipment has been tested and found to comply with the limits for a Class B digital

device, pursuant to part 15 of the FCC Rules. These limits are designed to providereasonable protection against harmful interference in a residential installation. This equipment generates, uses and canradiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged totry to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- · Consult the dealer or an experienced radio/TV technician for help.

FCC radiation exposure

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.