

SMART WRISTRAND

Thank you for purchasing our wristband. Please read the instruction before use Devices require: support Android 4.3, iOS 7.0 or above, for BT version 4.0 or above Please fully charge the wristband before use.

### APP connection and functions =

- 1 Turn on: Long press the button for 3 seconds on the wristhand It would show a bluetooth pairing code when the first time to turn on the wristband, which is the ID code to be paired with the APP. This pairing code displays only one time each reboot.
- 2 Turn phone bluetooth on The Bluetooth name of the wristband is "smart watch "
- 3 Scan the OR code to install " wristband" app. Also could download the App through Google Play or app

system permissions, otherwise the

connection might fail. )

1.4 Connect to wristband: Enter the App. it would need to registe when the first time to use this App. users also could skip it to try later. Registered users could log in the app by entering the email and password. Please follow the tips to connect the phone to the wristband (The tips would show up for the first-time connection. please allow the App to obtain the





5 Delete wristband: After connecting to the ann if you want to delete the wristhand connection, please go to APP-setting-my wristband,and use oto delete the device On Apple devices, please enter the settings on the phone click the bluetooth and delete the wristband connect, so that the phone could completely forget this device. The wristhand would have vibration when disconnected.

# P functions and setting 1 User profile:

Users could set the user profile after entering the App. App-setting user profile: Nickname, Picture, Gender, Birthday, Height Weight Step stride Unit After setting, it would sync to band, and user also could change the password.



(Base)

2.3 Anti loet: Swith on/off the anti-loet function gray is off by default. After switching on the wristhand will vibrate to remind if the mobile phone is out of the wristband oluetooth range.

St. ton

St. Completone

Mr. Title Seven

SS menior

No. on owner that the let

& Manustrain

C) NaChe World

2.5. Camera remote: Control App on phone to take photo or video. 2.6 Incoming call notify: Support default system phone book. Not for third-party applications.

2.7 SMS notify: Support default system SMS. Not for third-party.

2.4 Music remote: Control, phone music through wristband: Play

2.8. Set Clock: Can set up four alarm clock. Click sync to band after

setting, it would support offline alarm. Sedentary notify: Set up reminder.

2.10. My wristband: Add wristband. 0 -

2.11. Find device: Click "Start", find the connected wristband, and it would vibrate.

2.12. Manage device

2.13.Clear data: The data of the wristband and app will be zero.

2.14 Device undate: Undate the software

2.15. About: Check the App version.

sync data and sharing.



many watered to

22 0.48

. . . . .

nee 'ind links for hers

EE derstook

D rather

S tempoters

O 100 664

"All Item Princers

44 Acres months

D. Some Stein Sen-

A Track between total

Display data of steps, calorie.KM, Sport goal,



Pause Next song Last song (Support system-provided music player)

After syncing, can check the history data, daily/month/year sport data. Steps. calories. KM and goal finished.

Jumping rope: Click the icon, then click

START, click FINISH after sports, it can record

6.2. Jumping jack: Click the icon.click START

6.3 Sit-up: Click the icon click START after

it can record numbers of treadmill.

. Wristband functions

ristband functions display

movement click FINISH it can record numbers of sit-up

6.4. Treadmill: Click the icon, click START, after that click FINISH

after sport click FINISH, it can record jumping

the number of jumping.

iack movements.

Turn on mobile GPS, it can record sport tracks and share to social

3 Functions Interface

## $-c \simeq 10$ didc

Long press button for 3 seconds to enter functions interface. Clic the button switch to sleep mode, music remote camera remote fin phone vibration switch power off, reset, back to interface.

7.2. Cycling mode: It displays consumed calories. Short press the

it would record riding time and calories Riding over long press the

button for 3 seconds to return to the menu mode. Record in hours

while riding; would not record without riding.

button twice to cycle function, then long press for 3 seconds to enter



In the time dispay interface, long press button for 3 seconds to enter 7 11 Rack function interface, selete the sleep icon, long press for 3 seconds to

enter sleep mode settings.

7.5.Music remote:

• Long press button for 3 seconds to enter music play mode, you can 7.12. Palming Bright Screen play music and select previous or next song. (Only supports system-

provided player.)

7.6. Camera remote

Turn on the camera remote on the App.Long press the button to excamera remote and prese button to take pictures. Turn on the video function on the App, then enter to the camera remote function again. short press the button, and it would take video, press the button again the swimming icon, long press for 3 seconds to enter the swimming

7.7 Find phone

Long press for 3 seconds to enter click "find your phone" icon, you phone will ring then, so you can find your phone.

7.8 Vibration settings

Long press the button for 3 seconds to enter vibration function to s

7.9 Power of

Long press the button for 3 seconds to enter short press the button choose off " then long press the button it would show 5.4.3.2.1 and

Long press the button for 3 seconds to enter, short press the button to choose on, then long press the button, the system will reset the



Press the button to chose back icon, presse for 3 seconds to back

time dispaly interface.

time and data will reset to the default value

Long press button for 3 seconds to enter the functions menu, cho

Flip your wrist to light up the wristband screen.

7.13 Swimming mode

Swimming mode status display

and Android 4.3 & above Also supports with bluetooh 4.0 and above

subject to the actual production. mode. Switch it to ON, back to the main interface and begin to swim. The item would record the data when swim for 1 minute or more.

would not record anything less than 1 minute.

10.3.No disassembling or reforming the machine, otherwise may cause problems or invalidate the warranty

10.7. Temperature range for using: 0 to 45 C: Charging temperature powered USB port. (5v 500 mAh) range: 0 to 45 C.

Swimming mode: Record the time and the calories burned. It shows

To charge use the power cable to connect the wristhand to a

calories burned if drop out of Swimming mode.

(connecting/re-connecting failed/re-connecting slow) A: If cannot get connected for long time, please follow the

the battery.

Notes

connection as well

or reboot the phone

log in again.

and above. BT4.0 and above.)

10.4. This wristband supports 5v 500 mAh. Over-voltage is strictly

10.6 The battery is built-in please do not disassemble or change

11.1.Q: Why the wristband cannot connect with Bluetooth?

11.1.2 BT wireless connection would have signal interference

problem, the time for each connection would not be the same.

11.1.4 Shut down the Bluetooth for 15 seconds, then turn it on again.

11.1.13 Turn off the Wifi. since it would have interference of

prohibited that will cause hardware damage.

10.5. Keep away from fire, to advoid an explosion.

Support Android 4.3 and above/ iOS 7.0 and above, BT4.0 and above methods to figure it out:

Reference model: Support more than 200 mainsteam mobile phones. 11.1.1 Please make sure that the devices you connect to wristband are under the requirement/Support Android 4.3 and above/ iOS 7.0

IOS: iPhone4s/5/5C/5S/6/6 PLUS/6S/6S PLUS Android: 4.3 blutooth.4.0 above Xiaomi: MI4.MI 3.NOTE LTE.

HM NOTE 2 HM NOTE1S 4C HM 2A HUAWEI: MT7 H60 P7

MEIZU: M1 NOTE MX4 MX4 PRO MX5 M2 NOTE SAMSUNG: S4 S5 S6 NOTE2 NOTE3 NOTE4 NOTE5 A7 OPPO: P7

VIVO: X5 PRO.X5S LG: NEXUS 5.D885 ONEPLUS: A0001

11.1.5 Turn off the background applications, or reboot the phone. 10.1. Theoretically, the wristband supports iOS 7.0 system & above. | 11.1.6 Uninstall the Smart Wristband App, and redownload it

but not support all moible phone models. Specific specifications are 11.1.7 Check that if the phone connect to other bluetooth device

11.1.8 Make sure the App run in the background. 10.2. No dropping or bumpping shot with hard object, otherwise may

cause the wristband surface whet flower or other hardwares damage. 11.1.9 Charge it for one hour.

11 1 11 Reset the wristhand

data to your phone in time.

11.2 Q: Can not search the wristband?

A:First, please make sure that the item is fully charged, and does not connect to other phones. Then, put the wristband near to your phone while searching, if the search still fails, please turn off the phone bluetooth, and reboot the wristband, and, the phone bluetooth after 20

11.3 O: Should the bluetooth be kent open? Would it still record data

if the bluetooth is turned off?

A: The data of sleeping and sport would be kept on the wristband before syncing to App. When the phone and wristband get connected successfully, the data on wristband will upload to your phone. The wristhand could keen the data for 1 week, when the storage get full new data will cover the old data. Therefore, please remember to sync be used normally while washing face or hands.

onnected. Support offline alarm. 11.4.Q: Why is the data on the App not as same as the data on the

wristhand such as distance calories etc? A: Due to the different bodily mechanisms, the relevant data are not

the same. So user should set the personal information up and sync to the wristband before using. 11.5.Q: Why the wristband can not be charged?

A: Please make sure to insert the power cable in correct orientation. When the battery falls below 3.6v, it will take times to pre-charged. Attention: Generally, it would take 3-5 minutes to enter charging

few minutes to get back to normal. Charging: battery icon on the

would show up while the item is fully charged. The item will take about

11.7. Q: Will the bluetooth radiation be harmful to person if keep

11.8. Q: Will the wristband record accumulatively if sleep several

A: Turn on the sleep mode manually before each sleep, it would record accumulatively.

when keep wearing

11 9 O: Abnormal vibration

A: This may caused by turning on the "anti-lost"function, so

please turn off this function when not needed. Moreover, due to the interference of the wireless the wristband would vibrate if the wristband loses connection or the signals are weak. If abnormal vibration last for a long time please turn off the wristband or phone for a while and reboot them to solve this problem.

11.10.Q: Is this wristband water-proof?

A: Use sealed structure, with the functions of strong water-proof Attention: If you set the reminding function you need to keep bluetooth and dust-proof. Its water proof level up to IP67. Usualiv it could

11.6.Q: What will display while charging? A: Pre-charging: when the wristband runs out of battery, it needs a

screen keeps moving. Charging state from zero to full Charged:

2 hours to be fully charged.

A: The bluetooth radiation value is far below the American FCC 11.1.10 Log out the account on the App and the wristband and ther

standard(usually negligible). It would not be harmful to our health