



DJ-10 Operation Manual

Powering On:

- 1) Press front knob/button.
- 2) Turn knob clockwise to power on the speaker
- 3) Speaker will default to pairing mode.

Volume Control:

- 1) Twist front knob clockwise to increase volume.
- 2) Twist front knob counter clockwise to decrease volume.
- 3) Changing the volume on the speaker will also change the volume on your phone.

Pairing Single Speaker Mode:

- 1) Power on speaker.
- 2) Press and release blue button on bottom of speaker
- 3) This will cause the speaker to enter pairing mode no matter what state it was in.
- 4) Select the DJ-10 from your bluetooth device list on your phone.
- 5) Blue light on bottom of speaker will blink while pairing.
- 6) An audio message will indicate when the speaker is paired.

Pairing Stereo Mode:

- 1) Power on both speakers
- 2) Long press blue button on both phones.
- 3) An audio prompt will indicate that the speakers are pairing in stereo mode.
- 4) Stereo pairing can take up to 45 seconds.
- 5) Audio prompt will indicate when the speakers are paired in stereo mode.

Charging:

- 1) Open bottom compartment and pull USB-A power cord out.
- 2) The lid can be closed with the power cord out using the 2 small cord cutouts at the bottom of the speaker.
- 3) Plug cord into USB-A jack.

For any questions contact us at support@desertfoxgolf.com



FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction