

INKBIRD

DUAL MODE WIRELESS **BBQ**
THERMOMETER USER MANUAL





Please keep this manual properly for reference. You can also scan the QR code below to visit our official website for product usage videos. For any usage issues, please feel free to contact us at **support@ink-bird.com**.

Wenn Sie eine Bedienungsanleitung in deutscher Sprache benötigen, scannen Sie bitte den QR-Code und besuchen Sie unsere Website, um sie zu erhalten und ein Video über die Verwendung des Produkts zu sehen.

Se avete bisogno di un manuale di istruzioni in italiano, scansionate il codice QR e visitate il nostro sito web per ottenerlo e vedere un video su come utilizzare il prodotto.

Si vous avez besoin d'un mode d'emploi en français, veuillez scanner le code QR pour visiter notre site officiel afin d'obtenir et de visionner la vidéo d'utilisation du produit!

Als je een Nederlandstalige handleiding nodig hebt, scan dan de QR-code om naar onze officiële website te gaan en bekijk de video over het gebruik van het product!

Si necesita el manual de instrucciones en español, escanee el código QR para ir a nuestro sitio web oficial y ver el vídeo sobre cómo utilizar el producto.



Warm tips

- To quickly jump to a specific chapter page, click on the relevant text on the contents page.
- You can also use the thumbnail or document outline in the top left corner to quickly find a specific page.

CATALOGUE

- 01 Overview 01
- 02 Technical Specifications 01
- 03 Introduction of Product Appearance/Screen/Indicator Light 04
- 04 Key Definitions 10
- 05 Battery Details & Maintenance 10
- 06 APP Installation & Connection 13
- 07 Cleaning and Maintenance 15
- 08 Important Notes/Warnings 16
- 09 Troubleshooting Guide 17
- 10 FCC Requirement 21
- 11 IC Warning 22
- 12 Customer Service..... 24



Overview

The INKBIRD INT-31-BW is a more intelligent, more accurate wireless BBQ thermometer tailored to BBQ enthusiasts who love life and pursue high-quality living. The professional-grade multi-sensor probes of the INT-31-BW have multiple high-precision temperature sensors that simultaneously monitor the temperatures of the food core and the cooking environment, mastering deliciousness every second with scientific technology. The device supports Bluetooth and WiFi dual-mode connection, realizing real-time remote control in different usage environments. Whether for family gatherings or private barbecues, the INKBIRD BBQ Thermometer serves not only as a temperature measuring tool, but also as a must-have in high-quality kitchen life, manifesting the balance between scientific technology and practicality in all aspects, accompanying you every tasty moment.



Technical Specifications

Brand	INKBIRD
Model	INT-31-BW

Connection Mode	Probe-to-Base	BLE
		Note: The distance between the probe and the base must not exceed 6 meters (19.68 feet). If there are obstacles in between, the distance should be shortened to maintain a stable connection. (The base serves as a signal repeater.)
	Base-to-Smartphone	BLE5.4
		Connection distance: 328ft/100m (the longest range in an unobstructed open area)
		WiFi 5GHz, compatible with 2.4GHz
		Connection distance: The device should be within 328 feet/100 meters of WiFi router; no distance limit for smartphones.
Probe Protection Rating		IP67(Dishwasher safe)
Sensor Quantity		5 sensors (4 high-precision food temperature sensors + 1 ambient temperature sensor)


Probe Measurement Accuracy	Food sensor: $\pm 0.5^{\circ}\text{F}/0.3^{\circ}\text{C}$ Ambient sensor: $\pm 9.0^{\circ}\text{F}/5.0^{\circ}\text{C}$
Temperature Measurement Range	Food temperature: $-10\text{--}100^{\circ}\text{C}/14\text{--}212^{\circ}\text{F}$ (For safe use, the probe will alert you when the temperature reaches $96^{\circ}\text{C}/205^{\circ}\text{F}$) Ambient temperature: $0\text{--}300^{\circ}\text{C}/32\text{--}572^{\circ}\text{F}$
Probe's Battery Life	25 hours of continuous cooking
Probe's Charging Time	25 minutes
Probe's Battery Voltage	3.8V
Base's Battery Capacity	1800mAh lithium battery
Base's Battery Voltage	3.7V
Base's Battery Life	BLE: 100 hours WiFi: 35 hours
Screen Type	Full-view HD LCD screen with backlight
Screen Size	45*22.5mm
Resolution	Food temperature: $0.1^{\circ}\text{C}/^{\circ}\text{F}$ Ambient temperature: $1^{\circ}\text{C}/^{\circ}\text{F}$

Offline Data Storage	The base stores cooking data for the last 120 min and automatically uploads it to your smartphone when connected.
Weight	164.5g
Package Contents	Device (Multi-sensor Probe + Base) USB-C Charging Cable User Manual Calibration Certificate
Size	140.5*66.2*21.5mm


03 Introduction of Product Appearance/Screen/Indicator Light

• Product Appearance


- ① Full-view HD LCD with Backlight
- ② LED Indicator Light
- ③ Power Button
- ④ Function Button
- ⑤ Type-C Charging Port











- ⑥ Charging Contact Point
- ⑦ Anti-slip Pads
- ⑧ Probe Charging Position
- ⑨ Built-in Magnet
- ⑩ Charging Electrode Plate




- ⑪ Charging Contact Point
- ⑫ Zirconia Ceramic Handle
- ⑬ Safe cooking line
- ⑭ Food-grade stainless steel
- ⑮ Ambient temperature sensor (MAX 572°F/300°C)
- ⑯ Food temperature sensor (MAX 212°F/100°C)


















• Screen Information Reference

Battery Icon		
 Big	Current battery level	
 Big	The device is charging.	
 Big	When flashing, the device's battery is low.	
 Small	Current probe's battery level.	
 Small	The probe is charging.	
 Small	When flashing, the probe's battery is low.	

Temperature Icon & Number

 Lights up	The preset temperature (Press the FUNCTION button to switch the display)
MAX	The highest temperature detected by the food sensor.

	The ambient temperature currently detected.
Number flashing	The current temperature has reached the preset temperature.
— H —	The current temperature is outside the temperature range of the probe.
— L —	The current temperature is below the temperature range of the probe.
Connection Icon	
 flashing	The device's Bluetooth pairing is in progress.
 Stay lit	The device's Bluetooth has been connected.
 Disappeared	The device is not connected or is disconnected from Bluetooth.
 Flashing	The device's WiFi is pairing with the network.
 Stay lit	The device's WiFi has been connected.

 Stay lit	The WiFi connection fails.
 disappears	The device is disconnected.
 Stay lit	The probe is connected.
 Dim	The probe is not successfully paired/disconnected.
 flashing	The probe is in the connecting/pairing process.
Sound & Temperature Unit & Timer	
	The device's buzzer is turned on.
	The device's buzzer is turned off.
°C/°F	Temperature unit on the device
	Lights up when the timer is set; disappears when the timer is not set.
 flashing	The timer is reached.

• Indicator Light Definition

Base Charging


When the base is charging, the green light flashes at the respiratory rate and remains lit when fully charged.

Battery Level

- When the battery level is lower than 29%, the yellow indicator light slowly flashes 3 times.
- When the battery level is lower than 9%, the red indicator light stays on.
- When the battery is about to run out, the red indicator light will flash and then the device will switch off.

Ambient Temperature Higher/Lower Than Preset Range

The yellow indicator light flashes until the alarm is manually dismissed or the temperature returns to the preset range.



a Power Button


Press and hold for 3 seconds to switch the device on or off.
Press and hold for 30 seconds to reset the device.

b Function Button

Press and hold for 3 seconds to switch the buzzer on or off.
During cooking, press the FUNCTION button to switch to the preset temperature display and it will return to the real-time temperature display in 2 seconds.

- **Cancel Alarms**

When the device is alarming, press any button to cancel the alarm.




- **Battery Details**

- A fully charged probe can continuously monitor food and ambient temperatures for 25 hours (prolonged exposure to high temperatures may reduce the battery endurance).
- The base has a built-in 1800mAh high-capacity battery. It can work continuously for 100 hours with a Bluetooth connection and 35 hours with a WiFi connection.

• Battery Charging Steps & Methods

Probe

Place the probe that requires charging in the designated charging position on the base.



Base

- 1) Please use the provided charging cable to charge this device. It will take approximately 2-3 hours to fully charge.
- 2) While charging, the indicator light on the base will flash green at the breathing rate and remain lit once fully charged.
- 3) If you need to charge this device with a different cable, please ensure that the cable has a type-C interface and provides 5V 1-2A.

• Use & Maintenance

1. Do not use the probe in environments outside of the specified temperature range. If the temperature in the cooking environment exceeds 300°C (572°F) or falls below -10°C (14°F), it may reduce the probe battery life or damage the battery.

- 2.** When the probe's battery power is low, please clean and dry it before placing it back on the designated charging position on the base for charging. When the base's battery power is low, please use the provided cable to charge it. The LCD screen on the base will display the charging status of both the base and the probe.
- 3.** Please note that the probes are waterproof, but the base is not. Do not use or store this product in harsh weather or high-humidity environments. Do not clean the base with running water or place it in a dishwasher or water sink, as this may cause water seepage and damage to the device.
- 4.** When you turn on the device and leave it unused for a long time, it will automatically enter sleep mode or shut down to conserve power. However, if you will not use the device within an extended period, please charge the battery to 50% capacity to prevent it from entering a deep discharge state. Do not fully charge the device before storing it, as this may shorten the battery lifespan.
- 5.** If the device's battery power is low, the measured temperature results may be inaccurate, the indicator and buzzer may be deactivated, or the device may be disconnected from the smartphone. Please charge it timely. However, do not use any Type-C cable that is not 5V 1-2A to charge the device, as this may cause damage to the product.
- 6.** During use, ensure that the base is not placed on a hot stove, working oven, or grill surface. Do not put it inside an oven or grill, as this could cause damage to the product or personal injury.



APP Installation & Connection

6.1 Search the INKBIRD App from Google Play or App Store to get it for free, or you can scan the QR code below to download it directly.



NOTE:

1. Your iOS devices must be running iOS 12.0 or above to download the app smoothly.
2. Your android devices must be running android 7.1 or above to download the app smoothly.
3. The device supports 5GHz and 2.4GHz Wi-Fi routers.
4. APP Location Permission Requirement: We need to obtain your location information to discover and add nearby devices. INKBIRD promises to keep your location information strictly confidential. And your location information will

only be used for the location function of the App and will not be collected, used, or disclosed to any third party. Your privacy is very important to us. We will abide by relevant laws and regulations and take reasonable security measures to protect your information security.

6.2 Registration

Step1: Registering an account is necessary before using the INKBIRD app for the first time.

Step2: Open the app, select your Country/Region, and a verification code will be sent to you.

Step3: Enter the verification code to confirm your identity, and the registration is complete.

6.3 How To Connect

- Make sure that both Bluetooth and WiFi functions are enabled on your smartphone and turn on the device.
- Open the INKBIRD APP. Allow the app to obtain location information, click "+" in the upper right corner to find this product, then follow the app instructions to complete the connection.
- During the connection process, place the device as close as possible to your smartphone and router. Additionally, when in use, ensure that all probes remain within 19.68 feet (6 meters) of the base.




Cleaning and Maintenance

1. Please note that the probes are waterproof but the base is not. After use, clean the probes under running water or in the dishwasher. Do not use cleaning agents containing alcohol, ammonium, benzene or abrasives as these may damage the device.
2. After cooking, do not place the probes directly in cold water to cool for a long time. Ensure that the probes have cooled to room temperature before cleaning.
3. After cleaning the probes, wait for them to dry before placing them back on the charging positions on the base to avoid device damage caused by rusty electrode plates or water seepage.
4. Please note that the base is not waterproof. Do not rinse or submerge it with water. If necessary, use a slightly damp cloth to wipe the base and prevent water from seeping and causing damage to the product.
5. For storage, please place the probes inside the charging base and store the entire unit in a shady and cool place away from children. Improper storage can result in property damage or personal injury.



Important Notes/Warnings

- 1) The probes are previously paired with the base at the factory. After starting up, take out a probe, the corresponding area will display the detected temperature of the probe and the icon . Set a menu for the probe on the app and then the probe can be used.
- 2) This product is not suitable for use in microwave ovens or pressure cookers. When using the probe, make sure that it is inserted in the center of the food and that the depth of insertion is beyond the safe cooking line engraved on the probe and that any bones are avoided.
- 3) The base can serve as a Bluetooth signal repeater. Place the base as close to the probes as possible. If this is not feasible, make sure that the distance between the base and the probes is no more than 6 to 8 meters and that there are no metal or any other obstacles in between. If there are obstacles between the base and probes, the distance should be shortened for a stable connection.
- 4) Do not use the probe where the temperature exceeds 212°F/100°C, the highest threshold of the internal sensor, or 527°F/300°C, the highest threshold of the ambient sensor. Temperatures above these two maximum points may damage the probes.
- 5) Do not expose the probe directly to fire or burning wood charcoals. If the probe falls into the fire, please immediately stop heating and wait for it to cool down

before removing it. Prolonged exposure to high temperatures can damage the probe.

6) When using, make sure that the base stays away from fire and heat sources. Do not expose it to direct sunlight, nor place or magnetically attach it to the surface of an oven or grill. And, do not put the base inside the oven or grill.

7) After cooking, do not immediately touch the hot probe. Wait for it to cool down. If necessary, use a heat-resistant tool to avoid burns.

8) This product is designed specifically for grilling and cooking. It is not recommended for any other purposes.



Troubleshooting Guide

Issues	Solutions
What if my device cannot connect to Bluetooth?	<ol style="list-style-type: none">1. Make sure that the Bluetooth function is enabled on your smartphone or tablet, that the device battery is fully charged, and that the device model number is correct.2. Make sure that the phone positioning function is enabled and that the APP is allowed to obtain your location information. Without permission, the app cannot establish a connection between the device and your smartphone.

Issues	Solutions
<p>What if my device cannot connect to Bluetooth?</p>	<p>3. Keep the device away from metal or obstacles. Place your smartphone or tablet as close to the base as possible. And, make sure the distance between the probe and the base is no more than 6 meters (19.68 feet).</p> <p>4. Try to restart the device, and turn off any other Bluetooth devices within the connection range or disable their Bluetooth functions.</p> <p>5. If you have paired the device with your smartphone before, remove the device, search for it again and pair it again.</p>
<p>What if my device cannot connect to WiFi?</p>	<p>1. Make sure that your smartphone has Bluetooth and WiFi enabled and connected to the device via Bluetooth. Then, follow the app's instructions to establish a WiFi connection.</p> <p>2. Make sure that you have entered the correct WiFi account name and password and that the WiFi network is stable.</p> <p>3. During the connection process, please keep the device, router and smartphone as close to each other as possible.</p> <p>4. Do not place the device on metal surfaces or near metal objects. Leave it at least 1 meter above the ground.</p>

Issues	Solutions
<p>What if my device cannot connect to WiFi?</p>	<p>5. During the connection process, any VPN or agent proxy servers should be forbidden, otherwise the connection will fail.</p> <p>6. Try to reboot both the device and router. If the device has connected to WiFi before, you can go to the setting page of the app to reset WiFi.</p> <p>7. Press and hold the power button for 30 seconds to force reset the device.</p> <p>8. Please verify if the router is blocking or blacklisting the device.</p> <p>NOTE: If your problem persists, please contact our customer service.</p>
<p>Why is my temperature probe reading incorrectly or not reading?</p>	<p>1. You can calibrate each sensor to the correct temperature using the app (food sensor calibration range: $\pm 18^{\circ}\text{F}/10^{\circ}\text{C}$; ambient sensor calibration range: $\pm 36^{\circ}\text{F}/20^{\circ}\text{C}$).</p> <p>2. Please check if the current temperature just exceeded the specified temperature range or has exceeded before, which may cause damage to the probe.</p> <p>3. Check on the corresponding probe area on the base's screen. If the probe is disconnected, please wait for it to reconnect automatically or reboot the device and wait for the probe to connect.</p>

Issues	Solutions
Why is my temperature probe reading incorrectly or not reading?	<p>4. Do not immerse the probes in water for long periods as this may damage the product.</p> <p>5. If your probe is damaged and needs a replacement, you can select the corresponding probe number on the app and enter the setting page to delete it and pair the new one.</p>
Why can't the probe be charged?	<p>1. The probes can only be charged at the base. To recharge, ensure that they are fully placed on the charging position and successfully connected to the contact points.</p> <p>2. Please check if there are any oil stains covering the contact points and probe tops, as this can cause charging failure.</p> <p>3. Please check if the base's battery power is low and has entered battery protection mode, which cause charging failure.</p>
Why can't the base be charged with fast charging?	<p>1. Please use the provided charging cable to charge the base. If you need to use a different cable, please choose a type-c cable with 5V 1-2A.</p> <p>2. This device does not support fast charging. In general, it can be fully charged in approximately 2-3 hours.</p>



FCC Requirement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.



IC Warning

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

This device must accept any interference, including interference that may cause undesired operation of the device.

The device meets the exemption from the routine evaluation limits in issue 6 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux

CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

L'appareil ne doit pas produire de brouillage;

L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la numéro 6 de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf. Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps

qu'aucune autre antenne ou émetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 20 centimètres entre le radiateur et votre corps.

WIRELESS BBQ THERMOMETER	
Model: INT-31-BW	FCC ID: 2ANDL-WBR3D
FCC ID: 2AYZD-12-BW	FCC ID: 2AYZD-INT-11P
IC: 30368-11PB	IC: 30368-INT11P
PROBE HVIN: INT-11P	BASE HVIN: 11P-B



Customer Service

This item carries a 1-year warranty against defects in either components or workmanship. During this period, products that prove to be defective will, at the discretion of INKBIRD, be either repaired or replaced without charge. For any problems in use, please feel free to contact us at [**support@inkbird.com**](mailto:support@inkbird.com). We will do our best to help you.

Shenzhen Inkbird Technology Co.,Ltd.

support@inkbird.com

Consignor: Shenzhen Inkbird Technology Co., Ltd.

Office Address: Room 1803, Guowei Building, No.68 Guowei Road, Xianhu Community, Liantang, Luohu District, Shenzhen, China

Manufacturer: Shenzhen Inkbird Technology Co., Ltd.

Factory Address: 5th and 6th Floor, Building 138, No. 71, Yiqing Road, Xianhu Community, Liantang Street, Luohu District, Shenzhen, Guangdong, China



V1.0

MADE IN CHINA
DESIGNED BY INKBIRD