

(FRONT)

BATTERY PRECAUTIONS

1. The 6.4V lithium rechargeable battery pack must be charged before use by utilizing the included USB cable adaptor.

2. Do not charge for more than 6 hours.

3. Do not charge the battery pack if it shows leakage, corrosion, or has loose or exposed wires or other damage.

4. Do not cover the battery pack while charging.

5. Do not dismantle the battery or charger, and do not cut the battery or charger cables.

6. The battery pack will be warm after charging. Do not touch the battery pack when it is hot. Wait until the battery pack cools before installing it in the Vehicle and before recharging.

7. The supply terminals are not to be short-circuited.

8. Rechargeable batteries and replacement are only to be made by adults.

9. The USB cable adaptor is not a toy.

10. This charger is intended to be used for charging 6.4V rechargeable battery pack with capacity (700mAh Max.) Other types of batteries may burst
- causing injury to persons and damage. It cannot be used for charging non-rechargeable batteries. Regular examination of battery charger for any damage to their cord, plug, enclosure and other parts, and that, in the event of such damage, it must not be used with the charger or battery pack.

11. Note that the AAA battery is non-rechargeable and is not to be recharged. Only batteries of the same or equivalent type as recommended are to be used. It will need replacement when transmission is poor.

12. Exhausted batteries are to be removed from the product.

13. Different types of batteries or new and used batteries are not to be mixed.

14. Rechargeable batteries are to be removed from the toy before being charged.

15. Batteries are to be inserted with the correct polarity (+/-) as shown inside the battery compartment.

16. Do not dispose of batteries in fire.
- WE RESERVE THE RIGHT TO IMPROVE/AMEND SPECIFICATIONS AND COLORS WITHOUT NOTICE.

Massive Mover RC • 2.4 GHz



CAUTION

- DO NOT RECHARGE BATTERY PACK THAT SHOWS LEAKAGE OR CORROSION.
 - IF BATTERY PACK IS HOT AFTER USE, ALLOW TO COOL BEFORE RECHARGING.
 - DO NOT ATTEMPT TO DISASSEMBLE THE VEHICLE OR CONTROLLER.
 - THE PACKAGING AND INSTRUCTION HAS TO BE KEPT SINCE IT CONTAINS IMPORTANT INFORMATION.
- WARNING!** CHOKING HAZARD. NOT FOR CHILDREN UNDER AGE OF 3.

FCC label compliance statement:

This device complies with part 15 of the FCC rules Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and

2. This device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna


- Increase the separation between the equipment and receiver

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected

- Consult the dealer or an experienced radio/TV technician for help

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CONTENTS



©2020 Caterpillar.
CAT, CATERPILLAR, their respective logos, "Caterpillar Yellow", the "Power Edge" trade dress as well as corporate and product identity used herein, are trademarks of Caterpillar and may not be used without permission.
www.cat.com


Funrise Inc., a licensee of Caterpillar Inc.

Conforms to the safety requirements of ASTM F963
Frequency band : 2408 - 2475 MHz
Maximum radio frequency power transmitted : <10 dBm




(BACK)

OPERATION



BATTERIES



CHARGING


1. Remove the 6.4V lithium rechargeable battery pack from the truck following diagram above, and connect it to included USB cable adaptor.

2. Connect adaptor to computer USB output, or to AC power adaptor with output limit of 6.4V for charging.

3. Full charge is about 3 hours at 5V (Computer USB port).

4. When charging is completed, unplug the USB cable adaptor.

5. Disconnect the rechargeable battery pack from the USB cable adaptor, and re-connect it back to truck. Reinstall battery cover tightly.



TIPS

1. The operating range can be affected by low voltage of batteries or interference from other external sources.

2. Outdoor usage is recommended for optimal control range.

3. Clean battery compartment to make sure it is free from dust to prevent poor contact of batteries.

4. Headlights will automatically turn on when driving.

CHARGING INDICATOR

Power On: Red light
Charging: Blinking Red light
Fully charged: Red light OFF
Battery error: RED light Strobe

For 700 mAh, Please note to disconnect charger when RED light turns OFF.

PARING VEHICLE/CONTROLLER

1. Turn on the vehicle; headlights will flash to indicate Pairing Mode .

2. While headlights are flashing, press any button on the controller; controller light should turn on while pressing.

3. Headlight will stop flashing to indicate successful Pairing.

4. If paring is not completed within 5 minutes, please turn off the vehicle and re-start from step 1.
- NOTE:** After 5 minutes of inactivity, vehicle will enter sleep mode. Turn vehicle OFF and then ON again to resume connection.

OPERATION PRECAUTIONS

1. Do not drive on tall grass, sand, or go thru water.

2. Do not drive in rainy weather.

3. Avoid direct impact with obstacles.

4. Switch OFF power when not in use to prevent damage to vehicle and transmitter from battery leakage.

5. Keep fingers, hair, and loose clothing away from moving parts.