

中文版本

C96
开放式蓝牙耳机

使用说明书
使用前请阅读使用说明书

产品使用简介

(1) 除说明书有特殊标示的操作方式以外,请勿尝试拆卸或更换产品内的任何零件。

(2) 请勿将产品放入水或其他任何液体中,此产品非防水设计。

(3) 如果有任何液体不小心进入产品内部时,请立即断开连接并移开此产品。

(4) 为避免触电,请在安装或拆卸产品时,确保手上没有沾水。

(5) 请勿将此产品放置于热源附近或直接暴露于火源附近。

(6) 请勿将本产品放置在有强大电磁力的环境中,否则会导致产品故障。

包装清单

耳机 X 2

耳机盒 X 1

使用说明书 X 1

充电线 X 1

产品示意图

功能触控区

指示灯

Type-C 充电口

耳机

充电盒

充电盒

产品规格

蓝牙版本: V 6.0
传输距离: ≥ 10米
电池容量: 40mAh
使用时长(50%音量): 约6小时(耳机)

充电时间: 约1.5小时(耳机)
额定输入: 5V = 40mA(耳机)

充电盒规格

电池容量: 300mAh
充电时间: 约1.5小时
额定输入: 5V = 300mA
(所有技术信息以实际性能为准)

给充电盒充电
用Type-C充电线连接充电盒到5V电源适配器。

LED指示灯状态

耳机指示灯

- 耳机开机: 白灯亮1秒
- 耳机关机: 白灯闪烁3次
- 耳机搜索配对时: 主耳白灯闪烁, 副耳灯灭
- 耳机与设备连接时: 灯灭
- 耳机断开连接: 主耳白灯闪烁, 副耳灯灭
- 耳机低电: 每5秒白灯闪烁2次

充电盒指示灯

- 耳机仓低电:电量剩余10%时, 数显屏数字开始闪烁
- 给耳机仓充电:数显屏数字跳动并逐级增大
- 耳机仓充满电:数显电量100
- 耳机仓给耳机充电:数显屏白灯循环闪烁, 耳机白灯亮

产品操作说明

1. 开机
方式一:充电仓开盖,耳机自动开机。
方式二:长按耳机触摸按键3秒-5秒,耳机开机。

2. 关机
方式一:将耳机放回充电仓,关上充电仓上盖,耳机关机。
方式二:耳机开机未连接设备状态下,长按耳机左/右触摸按键3秒-5秒,耳机关机。
(单边耳机操作,左/右耳机同时关机)

3. 配对
步骤一:开盖将耳机取出,主副耳机自动开机并配对;
步骤二:打开智能设备的蓝牙列表,搜索“C96”并连接(支持单耳使用)。

■ 触控按键的操作
音乐播放模式
■ 左/右耳机操作
上一曲:三击左耳机(L) 触摸按键
下一曲:三击右耳机(R) 触摸按键
音量+:单击右耳机(R) 触摸按键
音量-:单击左耳机(L) 触摸按键
暂停/播放:双击左/右耳机触摸按键

电话免提
■ 左/右耳机操作
接听:双击左/右耳机触摸按键
拒接:长按左/右耳机触摸按键2秒
挂断:双击左/右耳机触摸按键 (在通话状态下)

激活语音助手(智能设备支持语音助手)/音乐模式/游戏模式
■ 左/右耳机操作
游戏模式:长按右耳机触摸按键2秒
音乐模式:长按右耳机触摸按键2秒
语音助手:长按左耳机触摸按键2秒

恢复出厂设置

耳机开机后未连接状态下,连续单击5次左耳机和右耳机触摸按键,清除配对记录后关机。

产品中有有害物质名称及含量

部件名称	有害物质					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Cr(VI))	多溴联苯(PBB)	多溴二苯醚(PBDE)
印刷电路组件	○	○	○	○	○	○
外壳等小结构件	○	○	○	○	○	○

本表格依据SJ/T 11364的规定编制。
○:表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572 规定的限量要求以下。
×:表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572 规定的限量要求。
表中标记“×”的部件,皆因全球技术发展水平限制而无法实现有毒物质的替代。

印刷电路板组件*:包括印刷电路板及其零部件,电子元器件等,根据产品型号不同,您所购买的产品可能不会含有以上所有部件

在中华人民共和国境内销售的电器电子产品上将印有“环保使用期”(EPUP)符号,圆圈中的数字代表产品的正常环保使用年限。

保修声明

免责声明:
本使用手册没有任何形式的担保、立场表达或其他暗示,本使用手册所提到的产品、规格及信息仅供参考,内容亦会随时更新于网页,恕不另行通知。

保修声明:
就本文件所附的产品做出保证:如产品在您购买日起十二(12)个月(“保修期”)内,在正常使用情况下因质量问题发生损坏,能修理的,免费修理;经厂家确认无法修理的,免费更换;修理或更换后的产品,在剩余保修期(最短不少于30天)内继续享有保修,购买日以销售发票日期为准;如无法确定购买日,则保修期自产品生产日期起按十三(13)个月计算。如申请保修,请先致电产品服务热线,并按我们指示的方式执行。申请保修时,您需要提供准确、完整和清晰填写的有效销售发票。

以上保证不适用于下列情况:
1.超过三包有效期的;
2.因改修卡、产品编码与产品本体不符;
3.因误用、滥用或不适当的运输、使用、维护或保管而导致的故障或损坏;
4.因不可抗力(如地震、战争、火灾等)或意外导致的故障或损坏;
5.拉锁、搭扣因受力过大而损坏;
6.因承载过重造成的脱线或撕裂;
7.任何因尖锐物体造成的损坏;
8.有磨损或水浸迹象的产品;
9.因擅自拆改导致的损坏;
10.产品在正常使用过程中发生的老化、褪色、磨蚀、破裂和其他损耗。
11.如产品原有标识标签被更改或损毁,本保证将失效。
产品及随附物料的齐备和外观完好不属于保证范围,您应在接收产品时当场检验并对任何不符提出异议,以上保证是我们就产品做出的全部保证,且仅在中国大陆地区境内适用。本文件的任何内容均不影响根据法律规定不能排除或限制的消费者权利。

合格证
产品名称:
生产日期:
检验员:

英文版本

C96
Open-ear BT Headphones

Manual
Please read all instructions carefully
and retain for future use

Usage Instruction

(1) Don't attempt to disassemble the unit and change any part,except there is operation method mentioned in the manual.

(2) Don't expose the unit to liquid, moisture or humidity, since it is not a waterproof product.

(3) Disconnect the unit with your BT device and move it to the safe area if the liquid get inside the unit.

(4) Don't assemble or disassemble the unit to avoid electric shock, if there is water on your hands.

(5) Don't expose the unit to extremely high temperature or dispose of the unit in fire as it will result in an explosion.

(6) Don't place the unit in an electromagnetic interference environment to avoid malfunction.

Packing list

Headphone X 2

Charging case X 1

User manual X 1

Charging cable X 1

Product schematic description

MF button

LED indicator

TYPE-C

Headphone

Charging case

Charging case

Product specification

BT Version: V6.0
Transmission distance: ≥10M
Battery capacity: 40mAh

Playing time : About 6 hours (headphone)
Charging time : About 1.5 hours (headphone)
Rated input: 5V = 40mA

Charging case specification

Battery capacity: 300mAh
Charging time :About 1.5 hours
Rated input : 5V = 300mA
(All technical information is subject to actual performance)

To Charge the case
Connect the Type-C cable to the 5V power adaptor, and another end to the charging port of the Charging Case.

LED Indicator Status

Headset indicator

- Headset on: white light on for 1 second
- Headset off: white light blinks 3 times
- Headset searching for pairing: white light blinks on the main ear, and the vice-ear light goes out
- Headset connecting with a device: light goes out
- Headset disconnecting: white light blinks on the main ear, and the vice-ear light goes out
- Headset low battery: white light blinks 2 times every 5 seconds

Charging case indicator

- Low battery alert: Display flashes when case battery ≤ 10%
- Charging case: Display digits scroll and increment progressively
- Fully charged earphone compartment: 100 digital display power
- Case charging earbuds: White LED cycles on display while earbud light stays on.

Product operating instructions

1. Power on
Method 1: Open the case, the headphones will turn on automatically.
Method 2: Long press the headset touch button for 3 seconds - 5 seconds, the headset turns on.

2. Power off
Way 1: Put the headset back to the charging compartment, close the charging compartment cover, and turn off the headset.
Way 2: When the headset is turned on and not connected to the device, long press the left/right touch button of the headset for 3-5 seconds to turn off the headset. (Single side headset operation, left/right ear turn off at the same time)

3. Pairing to the BT device
Step 1: Open the cover and take out the headset, the main and vice headset will automatically turn on and pair;
Step 2: Open the BT list of your smart device, search for “C96” and connect it (support for single-ear use).

■ Touch control button operating
Music playing mode
■ Left/Right headphone operating
previous song: triple-click the MF button of left headphone.
Next song: triple-click the MF button of right headphone.
Volume +: click the MF button of right headphone.
Volume -: click the MF button of left headphone.
Pause/Play: Double-tap left/right headset touch buttons

Hands free function
■ Left/ Right headphone operating
Answer incoming call: double click the left/right headset function button
Reject: Long press the left/right headset touch buttons for 2 seconds
Hang up: double click the left/right headset function button(in call mode)

Active the voice assistant function (the smart devices support voice assistant function)/Music Mode/Game Mode
■ Left/ Right headphone operating
Game Mode: Long press the right headset touch button for 2 seconds
Music Mode: Long press the right headset touch button for 2 seconds
voice assistant: Long press the left headset touch button for 2 seconds

Restore factory settings

When the earbuds are not connected after powering on, click the touch buttons of the left earphone and the right earphone 5 times in a row to clear the pairing record and turn it off.

Name and content of hazardous substances in products

Part Name	Harmful materials					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Printed circuit assembly	○	○	○	○	○	○
Small structural parts (such as shell)	○	○	○	○	○	○

This form is compiled in accordance with SJ/T 11364.
○: Indicates that the content of the hazardous substance in all homogeneous materials of the part is in Below the limit requirements specified in GB/T 26572.
×: Indicates that the content of the hazardous substance in at least one of the homogeneous materials of the part exceeds The limit requirements specified in GB/T 26572.
The parts marked with "×" on the form are all harmful due to the limitations of global technological development.Substitution of substances.

Printed circuit board components*: including printed circuit boards and their parts, electronic components, etc., Depending on the product model, the product you purchased may not contain all the above components

Electrical and electronic products sold in the People's Republic of China will be printed on the "Environmental protection period of use" (EPUP) symbol, the number in the circle represents the product's normal environmental life.

Warranty statement

Disclaimer
This user manual does not have any form of guarantee, position expression or other implication.The mentioned products, specifications and information are for reference only, and the content will also be updated on the webpage at any time, without additional line notification.

Warranty statement:
The product attached to this document is guaranteed as follows: If the product is twelve (12) months from the date of purchase ("Warranty Period"), under normal conditions of use due to quality defects damaged, can be repaired free; if the manufacturer confirms that it cannot be repaired, free replacement; repaired or replaced product, Continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). Purchase date by sale The ticket date shall prevail; if the purchase date cannot be determined, the warranty period shall be 13 Months calculation.
If you apply for a warranty, please call the product service hotline first and execute it in the manner instructed by us.
When applying for warranty, you need to provide an accurate, complete and clearly filled out valid sales invoice. The above guarantee does not apply to the following situations:
1. The validity period of the three packs is exceeded;
2. Alteration of the warranty card and product code does not match the product body;
3. Causes caused by misuse, abuse or improper transportation, use, maintenance or storage (impaired or damaged);
4. Failure or damage caused by force majeure (such as earthquake, war, fire, etc.) or accident bad;
5. The zipper and buckle are damaged due to excessive force;
6. Disconnection or tearing caused by excessive load;
7. Any damage caused by sharp objects;
8. Products with signs of burning or water immersion;
9. Damage caused by unauthorized disassembly;
10. Aging, discoloration, abrasion, rupture and other losses occurred during normal use of the product.
11. If the original identification label of the product is changed or damaged, this guarantee will become invalid. The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee. You should Check on the spot and raise objections to any discrepancies.
The above guarantees are all guarantees we make regarding the products, and are only applicable in mainland China.
Nothing in this document affects consumer rights that cannot be excluded or restricted under the law profit.

Certificate Of Approval
Product name:
Production date:
QC number:

PDF
MARK

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.