

Line-Powered Oxygen Analyzer Quick Start Guide

First air calibration and measurement

PST-QSG-3002-1.1



Welcome to the Quick Start Guide for first air calibration and first measurement using your line-powered analyzer.


Here, you will find information covering **first air calibration in section A**, and **connecting to your process gas in section B** to make your **first measurement in section C**. Please read the safety information below.

Start here

The GPR-series of line-powered oxygen analyzers is compliant with the following safety approvals and directives:

Safety information





- Avoid covering the vent for the test flow indicator when gas is flowing to the sensor. This can pressurize the sensor causing damage.
- To remove moisture and particulates, open the sensor housing and either blow on the sensing surface or gently wipe the surface with a damp cloth. Ensure ppm sensors have minimal exposure to air.
- You must connect the analog signal output to a recording device in accordance with local safety directives.
- If your analyzer is an AIS or IS model, ensure power to the alarm contacts is 24 V DC (nominal).

 The first calibration is of utmost importance as all subsequent calibrations are based on the initial one.

NOTE: We recommend you use certified span gas for calibration; if this is not available to you, follow these instructions to carry out an air calibration.













User Interface (UI)



Button	Function
	Menu
	Enter
	Previous (decrement)
	Next (increment)

A. First air calibration

The GPR-1800 and GPR-2800 are delivered without the sensor installed to preserve its operational life. To install the sensor:

1. Apply power to your analyzer (refer to Figure 3 on page 5).
2. Using the two latches, open the front window.
3. Use  and  to navigate to **Select Range**.
4. Press  to select **0-25% (Air Cal)**.
5. Open the sensor housing (refer to Figure 2 on page 4 for guidance).
6. Loosen the star wheel then disengage the top sensor housing by turning it 90° counter-clockwise. Refer to 'b' in Figure 2 on page 4.
7. Remove the sensor from its packaging, remove the shorting flags and immediately place in the top sensor housing (refer to Figure 1 on page 4).
8. Hold the sensor in the top sensor housing away from any gas stream. After 2...3 minutes the sensor is stable.
9. On your analyzer, press .
10. Use  and , navigate to **Calibration > Span Calibrate**.
11. Now use  and  to enter the value 20.90 %. Ensure the reading has stabilized before continuing.

NOTE: When a Span or Zero Cal starts, only "Abort" with  is shown until the reading is stable, then "Accept" with  appears.

12. Use  to **Accept**, and  to **Abort**.
13. Now place the sensor into the bottom sensor housing with the gold contact plate facing upwards, (see Figure 1 on page 4 for guidance,) and replace the

top sensor housing by placing it on top of the sensor and turning 90° clockwise.

14. Secure it with the star wheel at the bottom of the housing assembly (refer to 'b' in Figure 2 on page 4).
15. Quickly close your analyzer and continue immediately to section B.







B. Process gas connection

1. Connect your process gas line to the inlet on the flow meter (refer to Figure 4 on page 5).

NOTE: If you have an analyzer with a sample system connect your span gas and sample gas lines to the appropriate ports. Once connected, move the 3-way valve to the desired position for Process gas.

2. Ensure the flow rate is at 1...2 SCFH and allow the span gas to flow for 2...3 minutes. This will purge the system.
3. Continue to **section B**.

C. Making your first measurement

1. Observe the reading on your analyzer to ensure the O_2 concentration is trending downward.
2. When the O_2 reading is in the desired sampling range, press  on your analyzer.
3. Use  and  to navigate to **Select Range** then press .
4. Use  and  to select your required operating range.

E.g. Response time: Sensor exposed to air for 2...3 minutes and installed in <1 ppm_v O_2 sample gas:

Reading	Recovery time (Air to 0 ppm with N_2 purge)
0.1 %	5 minutes
100 ppm	30 minutes
10 ppm	60 minutes
> 1 ppm	6-12 hours

NOTE: Response times are dependent on your analyzer model as well as your sensor.

D. Figures



Figure 1 - Aligning your sensor




Figure 2 - Installing and uninstalling your sensor



 = A and AIS models only

Figure 3 - Wiring your analyzer

E. Useful links

Scan below for more information:



Figure 4 - Gas inlet (analyzer's right side elevation)

