Use Manual

Carego Touch Control TWS



Warranty & Order:

Carego Bluetooth earbuds come $% \left(1\right) =0$ with 1 year warranty. When you meet any quality problem about the item after order, please contact us to get



Customer service:

• Email: tiante06@163.com

WhatsApp: +(86)18638843649



Twin Mode



Step 1

Take two earbuds out of the package



Step 3

Open the charging case, the earbuds will flash blue light slowly after 3-5 seconds (if always flash blue and red light, please double click the right earbuds, wait until it flash blue light slowly.



Step 2

Put two earbuds in the charging case, and charge the case 30 minutes, then go to step 3



Step 4

Turn on the bluetooth on device and search "Y42 Pro" to connect

Single Mode / Functions



Step 1

Take out any one of the earbud from charging case

Step 2

Turn on the bluetooth on device and search Y42 Proto connect

Remark: the earbuds will be connected automatically with mobile if it has been connected before



Long Press

- Long press 2s Voice assistant
- Long press 2s Reject call
- 5 Long press 4s Power on / off

Short Press



* 3 click Last music 2 click Receive / hang up call

* 5 click game/music mode








2 click decrease volume 3 click Next music

2 click Receive / hang up call

5 click game/music mode

Charge



Case charging display Full charge time:1.5-2H



Earbuds Full charge time:1H

Input: 5V 230MA Output: 5V 35MA

Troubleshooting

If any of the following conditions accur while using this product, it can be resolved independently,

1.Left & Right earbud can not pairing with each other

Take out the earbuds from charging case, two earbuds always flash red and blue or there are two bluetooth name of Y42 Pro on the mobile Solution: Turn off both earbuds, delete the connection record Y42 Pro displayed in the connection list of the phone or other bluetooth devices. Then 2 click the right earbud quickly, after 2-3s, both earbuds will flash blue slowly, that means they have paired with each other successfully.

2.Only one earbud working

There is only sound on one side when the headset is connected to the mobile phone, and the lights on the other side do not flash or the red and blue lights flash alternately.

Solution: Delete the connection record Y42 Pro displayed in the connection list of the phone or other bluetooth devices. Put two earbuds back into the case, close the case and then tack out the earbuds. If both earbuds flash red and blue light, pls 2 click the right earbud quickly, after 2–3s, both earbuds will flash blue light slowly, that means they have paired with each other successfully. Then open the mobile bluetooth to search Y42 Pro to connect.

3.Earbuds can not be connected with mobile Solution:

1. Turn off the earbuds and turn off the bluetooth on mobile, then turn on earbuds and turn on bluetooth on mobile, to search the bluetooth name $\,^{\prime}$ $\,^{$

3.Delete the bluetooth list record on mobile, then search Y42 Pro to connect.

Specifications

Earbuds:

Bluetooth version: JL 5.3

Distance: 10M Battery: 35mAh

Full charge time: 1 hours

Play time: 3-4hours

Weight: 8g



Battery: 230mAh

Full charge time: 2 hour Input: 5V 230MA

Output: 5V 35MA

Size: 62*45.2*24mm

Weight: 32g



