



## Z-Wave Protocol Implementation Conformance Statement

### Era Inn Edge S AC ZW BD

#### General Information

<b>Product Identifier:</b>	E EDGE SI 620 AC ZWA BD
<b>Brand Name:</b>	FIBARO
<b>Product Version:</b>	HW: 186 FW: 1.02:01.00
<b>Z-Wave Certification #:</b>	ZC10-20056911

#### Product Features

<b>Firmware Updatable</b>	Updatable by Consumer by RF
<b>Window Covering Control Features</b>	Manual Calibration Position Aware Supports Up/Down Motion
<b>Z-Wave Scene Type</b>	Scene

#### Z-Wave Product Information

Supports Z-Wave Beaming Technology?	Yes
Supports Z-Wave Network Security?	Yes
Supports Z-Wave AES-128 Security S0?	Yes
Supports Security S2?	Yes: S2 Authenticated, S2 Unauthenticated
SmartStart Compatible?	Yes

#### Z-Wave Technical Information

<b>Z-Wave Frequency:</b>	U.S. / Canada / Mexico
<b>Z-Wave Product ID:</b>	0x00BA
<b>Z-Wave Product Type:</b>	0x0103
<b>Z-Wave Hardware Platform:</b>	ZM5101
<b>Z-Wave Development Kit Version:</b>	6.81.06
<b>Z-Wave Library Type:</b>	Enhanced 232 Slave
<b>Z-Wave Device Type / Role Type:</b>	Window Covering - Pos/End Aware / Always On Slave

#### Association Group Information

Group # / Max	Description
---------------	-------------

Z-Wave Protocol Implementation Conformance Statement

(Continued)

Era Inn Edge S AC ZW BD

- 2 / 5
- Retransmit a Basic Set, Multilevel Switch Set, Multilevel Switch Start Level Change, Multilevel Switch Stop Level Change or Scene Activate Set to the nodes associated.
- 3 / 5
- If node receives Configuration Bulk Set or Configuration Set (parameter MUST be in the range from 39 to 43), it will send Configuration Bulk Set with Handshake=0 or Configuration Set to nodes associated.

Supported Command Classes (19):

Application Status	Association Group Info
Association V2	Basic V2
Configuration V2	Device Reset Locally
Firmware Update Meta-Data V4	Manufacturer Specific V2
Notification V8	Powerlevel
Scene Activation	Scene Actuator Conf
Security S0	Security S2
Supervision	Switch Multilevel V4
Transport Service V2	Version V2
Z-Wave Plus Info V2	

Controlled Command Classes (4):

Basic V2	Configuration V2
Scene Activation	Switch Multilevel V4