


MAYFAIR LONDON

The Traditional Kitchen Collection

Installation & User Guide

BRIDGE NUMBER

U.4710L U.4710N



- U.4788X + U.4789L
- U.4790X ■ U.4791L

Fitted with U.6793

Tampa Bay
 11/11/2011
 11/11/2011

Recommended
Worlding Premium
41-43% US per
Min. 500-1000

Equal performance obtained with equal hot & cold pressures.

The Traditional Kitchen Collection Installation & User Guide

Checklist this is an integral part of your product. Please refer to the checklist included and with each delivery. Our product will give you many years of trouble-free service.

IMPORTANT INFORMATION

Before you proceed, we recommend you engage the services of a registered plumber to install this product.



For ease of possible future servicing, we also recommend the fitting of conveniently placed hot/cold water.

In addition to the guide below it is essential that the written information provided is carefully read and understood.

Preparation Check-Box for Installer

☐ Flush the plumbing system before installing the Machine around.

☐ Check on product, remove Base unit and 20litre spray connector ready for installation.




The machine must be in a fixed position, e.g. fixed to a wall or a sink. It should be in a position where it can be easily accessed for any future service. From the top left, below 10-15mm (1/2 inch) from the top of the front body - provide a fixed with a suitable union, if water must be added. Secure it with a suitable union screw.

The kitchen tap with cold spray is supplied with a hose that is provided with a 1/2 inch of the hose. Please be careful not to damage the end of the hose during installation.

If your machine has a cold spray, please follow steps 1, 2 & 3. If not, please refer to the manual.

Ensure all connections are firmly tightened.

2: Install hose through deck opening.



Secure each spray line, socket, to a suitable position using a fixed screw.

Place the hose through the deck opening and secure it with a fixed screw.

3: Rotate hose connector on hose fastener connecting to union.




Small number 20 to 25mm (3/4 inch).

Small number 20 to 25mm (3/4 inch).

Small number 20 to 25mm (3/4 inch).

Small number 20 to 25mm (3/4 inch).

4. Attach Connector



The SHOC spray connector must be installed on the hose, before mounting on the cold water shank.

IMPORTANT - Do not cut brass tubes

With washer in place on the negative air push connector, simply push the hose onto the push connector, which captures the water shank, taking care not to cut the hose.

Tighten the band nut to fully compress the seal with brass tubes.

With washer in place, hold the side hose, screw the flexible hose onto the end of the faucet and place a rubber seal over the nozzle. Make sure the nozzle of side spray is secured.

Ensure all connections are firmly tightened.

Please Note: Caution the usage and limit as mentioned in the manual. Always use a full use of the SHOC spray connector by rotating the handle a quarter turn.

BEFORE USE

- Carefully check the installation of tubes.
- If the installation work is to be carried out in the vicinity, cover the top with a plastic bag to avoid damaging the finish.
- Leave enough clearance around the sample when taking plasma by probe.

CARE & MAINTENANCE

Wipe down after use to avoid water spotting and mineral build up.

Care and cleaning with warm soapy water followed by a polish with a soft cloth is all that is required to keep the spray finish in prime condition.

Do not use proprietary abrasive liquids, powders, or pads to clean the shower. Do not use any products with ammonia bleach or household cleaners. You will damage the polished finish and void your guarantee.