# Set Up With Vicohome App









Download Vicohome App from App Store or Google Play. You can also download the App by scanning the QR code above with the QR code scanner in your smartphone

Note: Before installing your bird feeder and camera, please setup your camera first.

### Set up the camera

#### Step1:


Go to your App Store or Google Play on your smartphone, search for "Vicohome" Or just scan the QR code below to download

the app:



Then please sign up for a new account, please check the screenshot below for your reference:

- 1) Tap "Sign up for a new account"
- 2 Input your user name, your country "the United State", and your E-mail address. And then check on the "Agreement and Privacy policy Let's go to "Next Step".







# Pair the Camera to your Phone App

- 3 You will receive the Verification Code from your E-mail, put it in and then go to "Next Step".
- 4 Set password for your account, and then go to "Done".
- (5) Congratulations! You have already registered successfully. Let's tap the "+" icon to add the camera now!



#### Step2:

Hold the power button to power up the camera, the indicator light will keep blue. And finally you will hear the pairing sound from the camera (if not, double press the power button, then you will hear the pairing sound) which means that the camera is ready for connection.



# Pair the Camera to your Phone App

- 1) If you hear the sound from the camera, please go to "Next Step".
- ② The device is found, please tap the device at this page.





- ③ Connect WIFI to the camera, select your network and input your WIFI password.
- ④ Tap "Join", please.







# Pair the Camera to your Phone App

- § Wait for a second, you will see this page and the camera would say "WIFI connected". You're almost done.
- 6 Set a name for the device and go to "Next Step".



- ⑦ Check your WIFI signal strength, tap "Done".
- Here we go! tap the "play" icon, you will see the camera image.







# About Cloud Storage and Bird Fans Plan

## How to get 30 days of free cloud storage

For new register we have 30 days free cloud storage

- ① Please go to Vicohome app, then tap try it free.
- ② Please go to "Bird Fans Plan" get it free.
- 3 After one month this service needs to be subscribed.





### Step1:


The invitee needs to download the Vicohome APP on her/his smartphone.

#### Step2:

After installing and registering a new account to login, just go to the app homepage, tap on the "+" sign in the upper right corner, and then select "Add friend's device". Then please scan the OR code of device admin.

How to find the device admin OR code? See the screenshot below. Just go to the administrator's Vicohome app. Go to the settings icon > Share > Device Sharing







A bird came to the bird feeder and triggered the camera recording and Al Identification.







# How to Connect charging cable and waterproof rubber stopper

When you connect the camera to the solar panel, please confirm that the charging cable plug is in good contact with camera.





 Prepare the solar panel with charging cable, take the rubber stopper out.





Thread the charging cable through the rubber plug.





3. Insert the charging cable and firm the rubber stopper.

#### **Incorrect Connection**



PLEASE DON'T insert the charging cable directly with the rubber on the plug.

### Q1: Why doesn't the Wi-Fi name appear when I connect to Wi-Fi?

A1: You need to turn on the "location permission" for the app in the system settings and change it to "allow when using"

### Q2: Will the camera show red lights when night vision is activated?

A2: The built-in infrared lamp beads make the camera only show some dim red lightswhen night vision is activated, but the image quality is still clear under no lightenvironment.

#### Q3: What are the requirements for Wi-Fi?

A3: Please use a 2.4GHz wireless network. The device does not support the 5GHzwireless network. Meanwhile, please set the Wi-Fi authentication method to wpa2-pskor other lower level of the security method. A password is required.

### Q4: How far should the camera be placed from the router?

A4: After testing, the WiFi connection distance can normally reach up to 100 meters in the open area. However, the actual situation depends on the strength of Wi-Fi and its surrounding environment.

#### Q5: What is the maximum length of recording time?

A5: You can choose the recording time in the app, The camera record for a fixed time or "auto" mode, when depending on whether there is a person, the maximum length of avideo is 3 minutes.

#### Q6: What should I do when the device is malfunctioning?

A6: Long press the power button to restart the camera.