


ELECTRONIC CONTROL TOWER FAN JTF-803B  
OWNER'S MANUAL  
Model No.JTF-803B



PLEASE READ AND SAVE THESE INSTRUCTIONS  
This fan is for residential use only. It is not intended to be used in commercial or industrial settings  
If service is required for this fan, please E-mail us at Aftermarket311@gmail.com  
MADE IN CHINA

Thank you for using this product, with proper care, this product will provide years of service. Carefully follow the instructions to ensure that this product functions safely and properly for years to come.

PLEASE SAVE THESE INSTRUCTIONS

SAFETY INFORMATION  
READ AND SAVE THESE IMPORTANT SAFETY  
INSTRUCTIONS BEFORE USING THIS FAN.



When using electrical appliances basic safety precautions should always be followed, including the following:

WARNING:

1. To reduce the risk of fire or electrical shock, do not use this product with any solid-state speed control device. To reduce the risk of fire or electric shock and injury to anyone, do not use in a window.
2. This product employs overload protection (blown fuse) which could indicate an overload situation. If the fuse blows, unplug the product from the outlet. Replace the fuse as per the user servicing instructions (follow marking for proper fuse rating) and check the product. If the replaced fuse blows, a short-circuit may be present and the product should be discarded or returned to an authorized service facility for examination and/or repair.
3. USE this fan only as described in this manual. Other uses are not recommended as they may cause fire or electric shock.
4. To protect against electrical shock, do not place the fan in the window, plug or cord it in water or spray with liquids.
5. Unplug the fan from the outlet when not in use, when moving the fan from one location to another and before cleaning.
6. Do not operate the fan in the presence of explosive and/or flammable fumes.


7. Avoid contact with moving fan parts.
8. To disconnect, grip the plug and pull it from the wall outlet. Never yank the cord. Always use on a dry surface.
9. Do not operate any fan with a damaged cord or plug. discard fan or return to an authorized service facility for examination and/or repair.
10. Arrange cord away from traffic area and where it will not be tripped over.
11. The appliance is not to be used by children or persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.
12. Close supervision is necessary when any appliance is used by or near children Children should not play with the appliance.
13. If the power cord is damaged, it is strongly recommended to request a specialist to handle it.
14. Do not leave the fan running unattended.

SAVE THESE INSTRUCTIONS

USER SERVICING INSTRUCTIONS

Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on the cord.  
(A)Open fuse which is covered by sliding access cover on top of attachment plug toward blades.

- (B)Remove the fuse carefully by gently pulling out the ends of the fuse from the receptacle. Replace fuse only with 5 Amp, 125-volt fuse.
- (C)Install replacement fuse by first placing the end of the fuse receptacle which is opposite of the blades of the plug, then carefully push in the other end. Only push against the metal end of the fuse, not the glass center portion.
- (D)Close fuse cover by sliding the cover back into the plug until it is completely closed and latches.



To prevent the risk of fire, do not replace the attachment plug. Contains a safety device(fuse)that should not be removed. Discard the product if the attachment plug is damaged

THIS PRODUCT IS EQUIPPED WITH A POLARIZED PLUG(a plug having one blade wider than the other).To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. DO NOT OVERRIDE THE SAFETY PURPOSE OF THIS POLARIZED PLUG

TECHNICAL SPECIFICATION  
Rating power: 45W  
Power: 120V~60Hz

INTHE BOX


- FAN
- BASE
- SCREWS (4 pieces)
- INSTRUCTION MANUAL
- Remote control

PREPARATION

Before beginning the installation of the product, make sure all parts are present. Compare parts with package content list and hardware contents list. If any part is missing or damaged, do not attempt to assemble, install or operate the product.


ASSEMBLY INSTRUCTION

1. Assemble left and right base.
- Note: Let the power cord through the hole of the base when assembling.
- 2.Drive 4 screws in the accessories bag into the hole on the base and fix the base on the main body.
  3. Put the product on the stable, smooth ground before using it.



OPERATION INSTRUCTIONS


Intended Use:  
This product is intended for indoor residential and office use only, not for industrial or other commercial applications, use only with electrical wiring that is in good working order and that meets applicable codes and regulations. If you have any questions about whether your wiring is adequate, consult a qualified electrician.



1. : ON/OFF of the fan
2. : Setting timer from 0.5-7.5 hours
3. : COOL/REFRESH/SLEEP mode for selection
4. : Low, Med, High wind speed for selection
5. : Oscillation function

REMOTE CONTROL VIEW:

1. Remote control, please use Lithium battery CR2025 3V.
2. The remote control power button is labeled as such.



1. "ON/OFF" Main power button
2. "SPEED" Low, Med, High wind speed for selection
3. "Mode" Natural mode and sleep mode for selection
4. "Timer" Setting timer from 0.5-7.5 hours
5. "OSC" Oscillation function

Battery

Before first use: Pull the protective film to remove it. The remote control is now ready for use.  
To replace the battery: open the battery compartment on the back of the remote control and replace the used battery with a new one. Battery type: CR2025

MAINTENANCE

1. Be sure to unplug the power cord from the outlet before cleaning.
2. Plastic parts should be cleaned with mild soap and a damp cloth or sponge. Do not submerge the unit in water to clean it. Thoroughly remove soap with clean water.
3. Be sure not to get water or other liquid inside the fan motor.
4. Dry all parts completely before reassembling and reconnecting to a power source.

STORAGE

Store the fan in a cool, dry location when not in use. To prevent dust and dirt build-up, use the original packaging to repack the unit.