

# Book



## BookEN

Quick Start Guide

### 1/ Warning ⚠

\* There may be noise when playing some songs with strong bass when the battery is low.This is normal phenomenon.Please ensure that the SINO BAND Book has enough power to maintain performance.

\* Longly use the machine with high volume may cause damage to your hearing.



\* SINO BAND Book built-in lithium battery,don't use any kind of fast charger exceeding 5V/3A,such as PD fast charger, mobile phone fast charger,Qualcomm fast charger,gallium nitride fast charger etc. The voltage of these chargers can't be recognized and compatible with the motherboard.

\* Do not expose to sunlight/fire or similar overheating environment

### 2/ What is TWS?

TWS means true wireless stereo.Let's say two Bluetooth speakers are able to be paired and playing music synchronously.








How to pair your device?

- 1: Please make sure these two speakers to be disconnected from other Bluetooth devices before you turn them on.Then please turn them on.
- 2: Select one of the speakers, Short press  to enter the TWS pairing mode, and the Yellow light is flashing.
- 3: After the pairing is successful, the Yellow light of the master/slave device is always on.
- 4: Turn on the Bluetooth of the device(mobile phone) at this time, find out "SINO BAND Book" on your device,select and connect it.
- 5: For speakers that have been successfully paired with TWS, they will be quickly connected and paired automatically later once they turn on.
- 6: In TWS mode,Short press  to disconnect pairing mode.

## BookEN

Quick Start Guide



### 3/ Key Function

Key	Operation	Instruction
	Short press	Short press 1s to switch on
	Long press	Long press 2s to switch off
	Short press	Switching modes (BT/TF/U disk/AUX)
	Long press	1. Long press 2s to disconnect Bluetooth 2. Long press 6s to restore factory settings
	Short press	Entering/Disconnecting TWS
	Short press	Switch EQ (full range/3D/Deep bass)
	Short press	1. Short press in Bluetooth/TF/AUX mode to pause/play 2. Short press to answer a call 3. Short press during a call to end the call 4. Bluetooth connection to mobile phone, double click to replay the last call
	Long press	Incoming call status long press 2s to reject the call
	Short press	Vol -
	Long press	Preceding track
	Short press	Vol +
	Long press	Next track

## BookEN

Quick Start Guide










### 4/ Overview



## BookEN

Quick Start Guide

### 5/ LED Indication

Status	Light	
 Bluetooth pairing	Blue light	Blink
 Bluetooth connected	Blue light	On
 Full frequency	Blue light*1	On
 3D	Blue light*2	On
 Deep bass	Green light	On
 Charging	Red light	On
 Full charge	Red light	Off
 TWS mode	Yellow light	Blink
 TWS connected	Yellow light	On

### 6/ Bluetooth Connection

The will blink blue when the speaker is on.

Find out the "SINO BAND Book"Bluetooth name on your device ,select and connect it.

### 7/ Power Bank Function

When turned on, plugging the charging cable into the USB interface of the speaker can perform emergency charging on your device.

## BookEN

Quick Start Guide

### 8/ Specifications

- Bluetooth Version : 5.3
- Frequency Response : 20Hz—20KHz
- Signal-to-noise Ratio : ≥80dB
- Charging Time : About 5 hours
- Input Power : Type-C 5V/3A
- Playing Time : About 18 hours  
(varies by volume level and audio content)
- Size(L\*W\*H) : 245\*130\*75(mm)
- Weight : 1650g

### 9/ Performance Optimization

\* The usage time of speaker will vary depending on the volume and songs.

\* Playing loudest or deep bass songs will speed up battery consumption.

\* When the SINO BAND Book is adjusted to the maximum sound, it will protect the speaker components,including the optimization of battery durability and play time.That is ,in order to play longer and reduce battery consumption,the balance of the tone will be adjusted appropriately, including the adjustment of the bass, treble and vocal parts. Therefore, there is a difference in the level of deep bass between loudest and medium volumes.

\* SINO BAND recommends that the Book be adjusted to a medium volume for listening,this will maintain the best sound and battery performance.

# SINO BAND

## Electroacoustic Laboratory

### Tips

After 18 years of audio technology accumulation and development in xdob, based on the theoretical power of the speaker, XDOBO Electroacoustic Laboratory enhances the actual power effect of the entire speaker unit by optimizing the sound structure, such as designing a cavity structure that is more in line with acoustic principles, creating more effective amplification resonance channels, reducing sound transmission losses, optimizing circuit structures, such as reducing internal resistance and increasing the power of the driving circuit.

In short, the power of the XDOBO speaker is not only equal to the volume and sound performance reflected by the physical hardware power, but also integrates the overall system acoustics and physics principles of software engineering, speaker cavity, material structure, power amplifier drive, battery efficiency, speaker tuning, etc., driving the performance of the entire speaker unit to significantly improve, achieving the ideal design power of XDOBO laboratory \* W.

SINO BAND Book Basic Physical Hardware Power: 60W

SINO BAND Book support power: 80W