

Smart Wake-Up Light Guide

APP Function

- Four Alarm Clocks
- Remote Control
- Automatic network timing
- Smart alarm Settings-can set alarm mode, alarm duration and working day
- Intelligent Snooze Setting-can set Snooze mode and Snooze duration
- Practical Sleeping mode Settings

Voice control

- Support for Amazon Alexa, Google Home

Thank you for choosing our product.

Version ACA-003 2.0

WARNING/STORAGE.....01

Quick-start Guide.....02

Overview/Quick Installation and Removal.....03

1.Time & 12/24H Setting.....04

2.Display Brightness.....05

3.Alarm Function.....06

3.1 Alarm Groups.....05

3.2 Alarm Switch.....06

3.3 Alarm Setting.....06

4.Snooze and Stop.....08

5.Light Function.....09

5.1 Night Light.....09

5.2 Sunrise Light.....09

5.3 Colored Light.....10

6.FM Radio.....11

6.1 Radio Switch.....11

6.2 Auto Scan.....11

6.3 FM Tuning.....11

6.4 FM Volume.....11

7.Fall Asleep Function.....12

7.1 Fall Asleep Switch.....12

7.2 Fall Asleep Setting.....12

7.3 Fall Asleep Adjustment.....13

8.CONNECTING YOUR MOBILE DEVICE.....15

9.HOW TO CONNECT WITH AMAZON ALEXA.....19

10.HOW TO CONNECT WITH GOOGLE HOME.....22

Specification.....24

WARNING

To reduce the risk of Fire, Electric Shock, or Injury to Persons:
1. This appliance is only intended for household use, including similar use in hotels.
2. Place this appliance on a stable level and non-slippery surface.
3. Do not use this appliance in wet surroundings (e.g. in the bathroom or near a shower or swimming pool).
4. Make sure the adapter does not get wet.
5. Do not let water run into the appliance or spill water onto the appliance.
6. Only use the original adapter. Do not use the other adapter if they are damaged.
7. This appliance has no on/off switch. To disconnect the appliance from the power source, remove the plug from the wall outlet.
8. Do not use this appliance as a means to reduce your hours of sleep. The purpose of this appliance is to help you wake up more easily. It does not diminish your need for sleep.

STORAGE

1. Clean the appliance with a soft cloth.
2. Do not use abrasive cleaning agents, pads or cleaning solvents like alcohol, acetone, etc., as this might damage the surface of the appliance.
3. If the appliance will not be used for an extended period of time, remove the power cord from the wall outlet and store the appliance in a safe, dry surroundings where it will not be crushed, banged, or subject to damage.

Quick-start Guide

Alarm

1 Press: turn on/off the alarm;
2 Press and hold: set the alarm with pressing: to adjust.

Fall Asleep

1 Press: turn on/off the fall asleep function;
2 Press and hold: set the fall asleep mode, with pressing to adjust.

Display Brightness & Time Setting

1 Press: adjust the time display brightness;
2 Press and hold: set the time with pressing: to adjust.

Light

1 Press: to turn on/off sunrise light;
2 Press: to adjust the brightness;
3 Press: twice to turn on/off the colored light;
4 Press: to adjust the light color.

FM Radio

1 Press: to turn on/off the FM;
2 Press: twice to scan radio frequencies auto matically;
3 Press and hold: to adjust the channel.

Overview

1 Light Brightness Adjustment

2 Light Switch

3 Alarm 1/Alarm 2

4 Setting "*/Volume "*/

5 Snooze/Night Light Switch

6 Setting "*/Volume "*/

7 Fall Asleep

8 Display Brightness/Time Setting

9 FM Tuning

10 FM Switch

11 USB Output

12 Micro USB Input

13 Reset

14 Button Battery

Quick Installation and Removal

1. Install the stand: Insert the stand directly into the mounting hole until it is securely attached. (as shown in Fig. 1)

2. Remove the stand: Hold the stand gently press down to remove it. (as shown in Fig. 2)

1 Time & 12/24H Setting

1. Press and hold for 2s, the icon will illuminate and the hour indication will start to flash; press: to adjust the hour.
2. Press to confirm the setting, the minute indication will start to flash; press: to adjust the minute.
3. Press to confirm the setting, the 12H indication will start to flash; press: to choose between a 12-hour and a 24-hour clock.
Press to complete the time setting.

2 Display Brightness

Press: to adjust the display brightness. 3 Levels: Bright - Auto - OFF. Default Brightness: Bright.

Bright Mode

Auto Mode

OFF Mode

3 Alarm Function

3.1 Alarm Groups

Allow users to program 2 alarms based on individual needs. For example, set Alarm 1 for weekdays and Alarm 2 for weekend. Note: the setting of 2 alarms is the same.

3.2 Alarm Switch (Alarm 1 as the example)

Press: to turn on/off the alarm; When Alarm 1 is turned on, the icon will illuminate on the display.

3.3 Alarm Setting

1. Press and hold for 2s, the icon will start to flash; press: to adjust the hour;
2. Press to confirm the setting, the minute indication will start to flash; press: to adjust the minute.

3. Press: to confirm the setting, the wake-up light brightness indication will start to flash; press: to adjust the wake-up light brightness (L-00, L-01 to L-20).
Note: The light will reach the maximum brightness when the alarm goes off. L-00: the light is turned off.

4. Press: to confirm the setting, the "light up prior to alarm" indication will start to flash; press: to adjust the duration (10-60 min).
Press: to confirm and complete the alarm setting.

4 Snooze and Stop

The wake-up light can simulate sunrise to gradually increase the brightness. The alarm will go off at set time as the wake-up light reaches the set brightness. When the alarm goes off, you can tap to snooze, adjust the alarm volume or stop the alarm.
1. Press: to snooze. After 9 minutes, the light will automatically come on and the sound will play again (5 times at most).
2. Press: to adjust the current volume when the alarm is ringing. Note: Adjust the volume only when this alarm sounds.
3. Press: to stop the alarm. Note: If the alarm is turned on, it will still go off next time.
4. If the alarm is ignored for 30 minutes, it will stop automatically. Note: If the alarm is turned on, it will still go off next time.

5 Light Function

5.1 Night Light

Press: to turn on/off the night light. Note: Night light is dim; it is recommended to use at night.

5.2 Sunrise Light

1. Press: to turn on the sunrise light; the icon will illuminate.
2. Press: to adjust the brightness. Press: again to turn it off.

5.3 Colored Light

1. Press: twice to turn on the colored light; the icon will illuminate and the light will activate auto color-change mode.
2. Press: to manually adjust the light color. Press and hold: to quickly adjust the light color and the light will activate auto color-change mode. Press: to turn it off.

6 FM Radio

6.1 Radio Switch

1. Press: to turn on/off FM. The icon will illuminate on the display when the FM mode is turned on.

6.2 Auto Scan

2. Press: twice to scan radio channel automatically; the icon will start to flash. It broadcasts the first channel after the search is complete.

6.3 FM Tuning

3. When the FM mode is turned on, Press: to adjust the frequency (0.1 MHz); Press and hold: to adjust channels.

6.4 FM Volume

4. When the FM mode is turned on, press: to adjust the volume.

7 Fall Asleep Function

7.1 Fall Asleep Switch

Press: to turn on/off the fall asleep mode. The icon will illuminate on the display when the fall asleep mode is turned on.

Fall asleep mode: ON

1. Press and hold for 2s to start the setting, the icon will illuminate and the time indication will start to flash; press: to adjust the fall asleep time (10~120 min).

2. Press: to confirm the setting, the fall asleep volume indication will start to flash; press: to adjust the fall asleep volume (L-00~L-20). Note: the fall asleep brightness is the initial brightness when fall asleep mode is turned on. L-00: the light is turned off.

7.2 Fall Asleep Setting

3. Press: to confirm the setting, the fall asleep volume indication will start to flash; press: to adjust the fall asleep sound. (5-00~5-03, XX MHz); Note: 5-00: the sound is turned off. 5-01~5-03: natural sounds, XX MHz; the last FM radio frequency you listened to.

4. Press: to confirm the setting, the fall asleep volume indication will start to flash; Press: to adjust the volume (L-01~L-20). Press: to confirm the completion and activation of fall asleep mode.

7.3 Fall Asleep Adjustment

Sunset simulation for peaceful bedtime: when the fall asleep mode is turned on, the light will dim until it goes out and the sound will gradually decrease until there is no sound.

1. Press: to adjust the brightness.
2. Press: to adjust the volume.

8 CONNECTING YOUR MOBILE DEVICE

1. Download Smart Life into your mobile device from App Store/ Google Play or by scanning QR code.

• Download APP

Android/iOS

2. Create an Account and Log in

3. Add Device & Connect WIFI

1. Turn the device on and long press the Snooze button (about 10 seconds) until the Wi-Fi icon begins to flash rapidly.

Select your own Wi-Fi and enter correct password

Wait for connecting

Create a name for your wake-up light.

4. How to Operate the Light via Smart Life APP Operation Panel

A. Click: to set the four alarm clocks.

B. Click: to choose the light display type and adjust the light intensity.

C. Click: to set the snoozing pattern.

D. Click: to turn on/off the FM radio, and choose the frequency you want.

E. Click: to set the sleep timer and create your Sleep Aid.

F. Click: to set the time of the wake-up light and time display brightness.

9 HOW TO CONNECT WITH AMAZON ALEXA

1. Download Amazon Alexa and sign in your Amazon account.

2. —Select Skills & Games, search Smart Life, and ENABLE TO USE it.

3. Discover Devices

This wake-up light works with Alexa, through this skill, Amazon Alexa will find and list devices you originally added in Smart Life App.

10 HOW TO CONNECT WITH GOOGLE HOME

1. Download Google Home and sign in your google account.

2. Login your "Smart Life" account, then Authorize and close the Accounts now linked page after it is connected successfully to enter Choose Device page. Then you can control the wake-up light via Google Home after complete setting.

Specification

Product Name	Wake-up Light
Brightness Adjustment	20 Levels
Light Color	7
Volume Adjustment	16 Levels
Display Brightness	3 Levels
Alarm Groups	4
Type of Alarm Sound	7 Natural Sounds & FM Radio
Sunrise Simulating Time	Adjustable 10-60 Minutes
Alarm Mode	Light & Sound; Sound Only; Light Only
Alarm Time	30MIN
Snooze Time	8-15MIN
Number of Snooze Times	5
Fall Asleep Sound	3 Natural Sounds & FM Radio
Sunset Simulating Time	10-120 Min
Fall Asleep Mode	Light & Sound, Sound Only, Light Only
Frequency	76.0-108MHz
Material	Light-proof ABS + PC + Silicone
Operating Temperature	0°C~40°C (32°F~104°F)
Type of Battery	Button Cell CR2032
Input Voltage	100~240V
USB Output	5V/2A

1