

## T59 User Manual


TRUE WIRELESS EARBUDS

### Customer Service

✉ Email: [support@golrex.net](mailto:support@golrex.net)

🌐 Web: [www.golrex.net](http://www.golrex.net)


### Package Accessories



Charging Case x1



Earbuds x2



Type-C  
Charging Cable x1





Ear Tips Set x3  
(Size M has been  
preinstalled on earbuds)



User Manual x1

01

### Overview



02

### Product Parameters

1. Supports: HSP/HFP/A2DP/AVRCP
2. Charging Interface: Point-Contact
3. Charging Cord Type: Type-C
4. Battery Capacity (Li-ion battery inside): Earbud: 45mAh
5. Battery Life: Actual battery life changes with the song types and volume requirements
6. Standby Time: Up to 100hrs
7. Charging Time: 1-1.5hrs for earbuds/2hrs for charging case
8. Transmission Range: 33 feet (without obstacles)

### First-Use


1. Before the first use, please tear off the isolating film on the earbuds. Put the earbuds into the case, then charge both earbuds and charging case via supplied Type-C charging cable for at least 10mins (or after not use for a long time); do not take out the earbuds during this period.
2. The earbuds are installed with a pair of size M ear tips by default. You can select other suitable sizes for a secure fit.

03

### How to Wear?

#### Step 1:

Adjust earbuds downwards to a proper position and push earbuds into your ears.



#### Step 2:

Slightly adjust earbuds to fit you best.




04

### How to Pair?

#### Method 1:

1. Pick up two earbuds from the charging case. They will auto power on and pair with each other in 10s.

\* If the earbuds are not connected to your device over 5 minutes, the earbuds will power off automatically. Turn on the earbuds manually by pressing the MFB button for about 2 seconds to hear the prompt "power on".




2. The white indicator light of dual earbuds flash to enter pairing mode.

3. On phone, search for "T59" and tap to connect.

\* You will hear "connected" from both earbuds. Then the indicator lights will turn off after the earbuds are connected.

#### Method 2:


In the unconnected state, double click the MFB of two earbuds to enter pairing mode.



05

### How to Reset?

1. Take the earbuds out for 5-10 minutes to consume some battery of both buds. (Can't be reset if the earbuds are fully charged)
2. Put the earbuds back into the case and make sure both earbuds blink Red.
3. Press and hold the buttons on both earbuds for 8 seconds. Close the case.
4. Take the earbuds out. Try to connect with the designated device.



Hold 8 seconds

### Maintenance

After a period of use, the charging metal contacts of the earbuds may be contaminated with sweat and dirt, resulting in the earbuds aren't able to power on, charge, or having connection issues, and the protective grille of both earbuds may accumulate earwax and dust, resulting in muffled volume. Please use the cleaning swab to remove dust or earwax from the charging contacts and the protective grille.



06

### Indicator status of the earphone

Power-on: White light for 1s;  
Power-off: Red light for 1s;  
Pairing mode of the earphones: White light of dual earbuds flash;  
Device to be connected mode: White light of the main earphone flashes;  
Connected to the standby state: White light on the L/R earphone for 1s after connected, then goes out;  
Phone state: White light goes out.

### Indicator status of the battery case

1. Charge the case: After plugging in the USB charging cable, the LED bar on the front will flash slowly during the charging process.
2. Charge the earphone with charging case (without external charger): Put the earphone into the charging case, the earbuds will be charged immediately and the red indicator flashes.
3. Charging case is fully charged (plug cable): LED indicator bar is steady on (flash slowly during charging).

07

### Button Operation tips

#### Power on:

Pick up the earbud from charging case/Preass and hold the MFB for 2s in power-off state

#### Power off:

Standby/Non-playing music, press and hold the MFB for 5s. Put into the charging case/Not connected to any devices over 5 minutes

#### Activate/Stop the voice assistant:

Triple click the MFB on L/R earbud

#### Reject call:

Press and hold the MFB on L/R earbud for 2s

**Previous song:**  
Double click MFB on L earbud

**Volume -:**  
Long press L earbud

**Answer/End call:**  
Click MFB once

**Play/Pause:**  
Click MFB once

**Next track:**  
Double click MFB on R earbud

**Volume +:**  
Long press R earbud


08

### How to Charge?

#### Type-C USB Charging


There is a Type-C USB charging cable in the package, please use it to charge the case directly. During charging, the digital display will flash and show the battery in real-time. After being fully charged, the number is displayed as 100.

The right display panel indicates the charging status per headset. There are separated power consumption indicators by 4 grids in total, the indicator light will always flash during Charging.



#### Wireless Charging

Charge the case easily without cables, just put your charging case on the wireless charging pad. If the charging case is not being charged, please try to reposition it. (Wireless Charging Pad Not Included)



09

### Troubleshooting Guide

**Q1:** What should I do when the earbuds can't be paired with my mobile device?

**A1:** Reset your earbuds and pair the earbuds with your mobile device again.

**Q2:** What to do when the earbuds can't be charged?

**A2:** The Charging Case may run out of power. Please charge it for at least one hour, then put the earbuds into it to charge.

Try to take out the earbuds and clean the Charging Pins, then put the earbuds into the Charging Case to see if the display panels on the case light up or not. There may be some malfunction with your Charging Case. If your Charging Case can't charge for earbuds after many attempts, please contact us.

**Q3:** What should I do if there is no sound from one earbud?

**A3:** Turn off Bluetooth on the device and turn it on, then pair your earbuds with the mobile device again.

For Android devices, if there is no sound from one earbud after connecting, you need to check whether the phone volume is too low. If the phone volume is normal, it may be that the volume of the earbud has been turned to the minimum. Please try to adjust the volume of the earbud.

10

**Q4:** What device can the earbuds be connected to?

**A4:** Devices with BT version over 5.0

**Q5:** Can my earbuds be paired with multiple devices?

**A5:** The earbuds don't support this feature currently.

**Q6:** Can I use one earbud at a time?

**A6:** Yes. After connecting the earbuds to your mobile device, you can use them together or just use one earbud alone.

**Q7:** Can I activate voice assistant through my earbuds?

**A7:** Yes. You can wake up the voice assistant by tapping the Touchpad of either earbud 3 times after pairing the earbud with your mobile device.

**Q8:** How to contact customer service?

**A8:** ✉ **Email:** [support@golrex.net](mailto:support@golrex.net)

🌐 **Web:** [www.golrex.net](http://www.golrex.net)



support@golrex.net www.golrex.net

Thank you for purchasing the authentic product.  
For more latest products, parts and accessories, please visit: [www.golrex.net](http://www.golrex.net)  
For any assistance please contact Email: [support@golrex.net](mailto:support@golrex.net)



11