


Loft Desk Grey/White

Stock number: 816 21402



H95 W105 D52-75cm

Thank you for purchasing the Loft Desk. Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.

At John Lewis, we are committed to making great products possible.

From our in-house Design Team, to our Buyers, we work together to bring great designs to life.


Our expert Product Technologists work collaboratively with our buyers and suppliers to assure the legality, safety and quality of the product we sell.

We are all committed to designing and developing products to the highest industry standards.

We hope you are happy with your product and welcome any feedback or comments you may have.

The John Lewis Team


Tools required



Time to assemble

1 hour

People to assemble



Important safety information

Warnings







- ⚠ The product should only be used on firm, level ground.
- ⚠ Keep small parts out of reach of children.
- ⚠ Ensure the product is fully assembled as illustrated before use.

Do's


- ✓ Check the pack and make sure you have all the parts listed.
- ✓ Check all screws or bolts are tightened and inspect regularly.
- ✓ Make sure the legs remain in contact with the ground at all times.

Don'ts

- ✗ Do not over tighten screws or bolts.
- ✗ Do not stand on the product.
- ✗ Do not use power tools to construct as overtightening and panel failure may occur.




Your desk










Ref	Description	Dimensions	Qty
1	Left side leg	520x40x695mm	1
2	Right side leg	520x40x695mm	1
3	Back panel	970x15x140mm	1
4	Bottom rail	970x25x40mm	1
5	Desk hutch	1050x520x255mm	1
6	Pull out worktop	1007x500x68mm	1



Fixtures and fittings



Fixtures and fittings
supplied (actual size)

Ref	Description	Dimension	Qty	mm
				0 10 20 30 40 50 60 70
A	Confirmat screw	7x50mm	4	
B	Cam	11x15mm	6	
C	Cam Stud	M6X40mm	6	
D	Dowel	8X30mm	3	
E	Leg Bolt	6x45mm	4	
F	Washer	8x13mm	4	
G	Wall fixing bracket bolt	M6x12mm	2	

Fixtures and fittings
supplied (not actual size)

Ref	Description	Dimension	Qty	
H	Allen Key M4	4mm	1	
I	Wall fixing bracket	20x84x18x2mm	2	


Product assembly

Loft Desk
816 21402


Step 1

Parts, fittings and tools

1 D C




Cam studs C are tightened clockwise with a screwdriver. Do not use power tool and do not overtighten.



Step 2

Parts, fittings and tools


2 D C




Step 3

Parts, fittings and tools

1 2 3 4 B




Connect the two sides 1+2 to the back panel and the bottom rail. Insert cams B into the allocated holes and tighten gently clockwise. Do not overturn, as this can damage the fixings.



Step 4

Parts, fittings and tools

5 A D H




Connect the desk hutch to the legs as shown, using one wooden dowel D and four confirmat screws A. Tighten bolts clockwise using Allen key H. Do not over tighten.

Step 5

Parts

6


Gently slide the pull-out top into place as shown.
Be careful not to scratch the top while sliding it into place.




Step 6

Parts, fittings and tools

H F E



Tighten all fixings clockwise with allen key H provided, and stand the unit up with 2 people.






Step 7 – Wall Fixing

Fittings and tools


G H I



Attach the desk to the wall using the correct wall fixings (See page 11).




Step 8 – Wall Fixing



Warning

Serious or fatal injuries can occur from furniture tipping over.

To prevent this furniture from tipping over, it must be permanently fixed to the wall.



A guide to wall mounting and fixings







Warning



In order to prevent overturning this product must be used with the wall attachment device provided. Wall fixing screws are not included, since different wall materials require different types of screws / fixings. Please ensure you use the correct screws / fixings for your type of walls and seek professional advice if you are not sure.

Installation shall be carried out exactly according to the instructions provided – otherwise a safety risk can occur if incorrectly installed. Failure of the product due to incorrect fixings is the responsibility of the installer.

Important: When drilling into the walls always check that there are no hidden wires or pipes etc.



Types of walls

You can use one of the following types of wall plug if your wall is made of brick, breezeblock, concrete, stone or wood.

1. General purpose wall plug

Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general – purpose wall plugs can be used.

2. Plasterboard wall plugs

For use when attaching light loads on to a plasterboard partitions.

3. Cavity Fixing wall plug

For use with plasterboard partitions or hollow wooden doors.

4. Cavity fixing – Heavy Duty wall plug

For use when fixing or supporting heavy loads such as shelving, wall cabinets and coat racks.

5. Hammer fixing wall plug

For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

6. Shield Anchor wall plug – Heavy Loads

For use with heavier loads such as TV and Hi-Fi speakers and satellite dishes etc.



Care and maintenance

Safety: Periodically check all fittings and wall fixings to ensure they have not come loose and retighten as necessary.

Care guide

Care and maintenance

Wood Furniture

Wood displays different grain patterns depending on which way they cut - for example, the 'medullary ray' which can appear on oak furniture is a mark of good quality timber - these are just characteristics of the natural beauty of the wood. Some furniture is also deliberately aged and rustic.

Wood veneers also allow distinctive patterns to be created on flat surfaces, such as table tops and drawer fronts by the way the slivers are arranged.

All timber surfaces will change colour and mellow over time. New furniture will initially vary in shade from items that have been previously purchased.

How to care for your wood furniture

Furniture with a hard lacquer or paint should be dusted with a dry cloth.

Spray polishes are best avoided as they contain silicones which may spoil the furniture's surface by building up over time.

Make sure all surfaces are protected from heat and liquids by mats and coasters. Wipe up spills immediately and ensure that a mat or pad is placed under paper if you are writing.

Our furniture will endure most temperatures in the home, but it is best to avoid placing furniture next to heat sources such as radiators or fires. Be particularly careful with solid wood as the lack of humidity caused by central heating can cause damage such as warping

Use a mild soapy water for cleaning, do not use anything abrasive as this may damage the surface of the product. Protect surfaces from scratches and marks by using mats and coasters.

Safety instructions

Never drag furniture when moving it, always lift it.

Periodically check all fixings to ensure none have come loose and re-tighten where necessary.

Please take care when handling or moving the furniture as careless handling may cause damage or injury.

Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person. No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture.

Retain these instructions for future reference.

Your feedback is very important to us and we would love to hear your comments on your new furniture. Please visit our website to leave a review. Thank you.