

User Manual of Product 1:

Buffalo 1.95kW Commercial Non-Stick Rice Cooker 6 Litre |
Rice Capacity: 13 Litre Cooked / 6 Litre Dry | 345(H) x 460(W) x
400(D)mm | J300



Rice Cooker

Instruction manual



Model :
J300-A

Safety Tips

- Position on a flat, stable surface.
- A service agent/qualified technician should carry out installation and any repairs if required. Do not remove any components on this product.
- Consult Local and National Standards to comply with the following:
 - Health and Safety at Work Legislation
 - BS EN Codes of Practice
 - Fire Precautions
 - IEE Wiring Regulations
 - Building Regulations
- DO NOT immerse the appliance in water.
- Do not touch hot surfaces with bare hands. Always use protective gloves.
- Use extreme caution when moving or handling appliances containing hot oil or any other hot liquid.
- Never fill the inner bowl above the top water line.
- Never allow water or any liquid into the outer pot.
- Only use utensils provided with this appliance when using the rice cooker. Sharp objects may damage the non-stick coating of the inner bowl.
- Do not use the appliance for anything other than its intended use.
- Do not plug in the cable until ready to cook. The rice cooker's power will remain ON unless unplugged.
- Always switch off and disconnect the power supply to the appliance when not in use.
- Not suitable for outdoor use.
- Keep all packaging away from children. Dispose of the packaging in accordance to the regulations of local authorities.
- If the power cord is damaged, it must be replaced by an BUFFALO agent or a recommended qualified technician in order to avoid a hazard.

Introduction

Please take a few moments to carefully read through this manual. Correct maintenance and operation of this machine will provide the best possible performance from your BUFFALO product.

Pack Contents

The following is included:

- | | |
|-----------------------|----------------------|
| • BUFFALO Rice cooker | • Fork |
| • Measuring cup x 2 | • Instruction manual |
| • Spoon | |

BUFFALO prides itself on quality and service, ensuring that at the time of packaging the contents are supplied fully functional and free of damage.

Should you find any damage as a result of transit, please contact your BUFFALO dealer immediately.

Operation

Cooking Tips

Wash the rice thoroughly before cooking. This helps to stop rice grains sticking together.

- A small amount of vegetable oil in the rice can help separate grains.
- Brown or wild rice may require additional water.

Using the Rice Cooker

The inner bowl features measurement lines inside as a guide. The cup provided is designed to measure the rice and water.

1. Measure the desired amount of rice using the measuring cup supplied.



Note: One cup of rice will produce approximately two cups of cooked rice.

2. Rinse the rice in a sieve under running water to remove excess bran and starch.
3. Pour the rice into the inner bowl. To achieve evenly cooked rice, spread evenly around the bowl.
4. Add the correct amount of water by using the measuring cup, or by filling the inner bowl to the appropriate level.



Note: Slightly reduce the amount of water for firmer rice, and increase the amount for softer rice.

5. Place the inner bowl into the rice cooker.



Note: Ensure there is no rice or moisture on the outside of the inner bowl.

6. Close the lid and press down until the latch snaps shut.
7. Connect the rice cooker to the power.
8. Depress the lever to the COOK position. The Cook light turns on.
9. Once cooking is finished the switch automatically moves to the WARM position. The Warm light turns on.
10. Keep the lid closed for 10 - 15 minutes for best results.
11. Carefully open the lid, allowing any steam and condensation to run back into the rice cooker.




WARNING: Always take care to avoid the expulsion of steam when removing the lid. Always use heat proof gloves when removing the inner bowl after cooking.

12. Stir the rice and serve as quickly as possible.
13. Disconnect the appliance from the power supply.

Cook light

Keep Warm light

Lever




Rice/Water Measurements

As a general guide, use one full cup of water to each full cup of rice.

Add slightly more water for softer rice, or slightly less water for firmer rice.

Cleaning, Care & Maintenance

**Note: Always switch off and disconnect the appliance from the power supply before cleaning.**

Always allow the appliance to cool before cleaning.

1. Remove the inner bowl and wash in warm, soapy water. Do not use harsh abrasive cleaners or products that are not recommended for use on non-stick coatings.
2. Rinse and dry thoroughly.
3. Clean the exterior of the rice cooker with a damp cloth.
4. Ensure the heating plate is clean and free of food or other debris that could interfere with the cooking process.
5. Dry the heating plate thoroughly before use.
6. Remove the water collector from below the lid hinge by pulling outwards [Fig. 1]. Discard the water collected after each use.
7. Clean and replace the water collector.




Fig. 1

Troubleshooting

| Fault | Probable Cause | Action |
|-------------------------------|---|--|
| The unit is not working | The unit is not switched on | Check the unit is plugged in correctly and switched on |
| | Plug and lead are damaged | Call BUFFALO agent or qualified technician |
| | Fuse in the plug has blown | Replace the plug fuse |
| | Power supply | Check power supply |
| | Internal wiring fault | Call BUFFALO agent or qualified technician |
| | The bowl is not in contact with the heating plate | Realign bowl |
| Rice is not thoroughly cooked | The bowl is not in contact with the heating plate | Reposition bowl |
| | The bowl has become deformed | Replace bowl |
| | Not enough water | Increase the amount of water used |
| Rice is overcooked | Too Much water | Decrease the amount of water used |

Technical Specifications

| Model | Voltage | Power | Current | Capacity | | Weight | Dimensions h x w x d mm |
|--------|-----------|-------|---------|----------|-----------|--------|----------------------------|
| | | | | Uncooked | Cooked | | |
| J300-A | 240V 50Hz | 1950W | 8.5A | 6 litres | 13 litres | 10.2kg | 335 x 420 x 420 |

Electrical Wiring

The plug is to be connected to a suitable mains socket.

This appliance is wired as follows:

- Live wire (coloured brown) to terminal marked L
- Neutral wire (coloured blue) to terminal marked N
- Earth wire (coloured green/yellow) to terminal marked E

This appliance must be earthed, using a dedicated earthing circuit.

If in doubt consult a qualified electrician.


Electrical isolation points must be kept clear of any obstructions. In the event of any emergency disconnection being required they must be readily accessible.

Compliance

The WEEE logo on this product or its documentation indicates that the product must not be disposed of as household waste. To help prevent possible harm to human health and/or the environment, the product must be disposed of in an approved and environmentally safe recycling process. For further information on how to dispose of this product correctly, contact the product supplier, or the local authority responsible for waste disposal in your area.

BUFFALO parts have undergone strict product testing in order to comply with regulatory standards and specifications set by international, independent, and federal authorities.

BUFFALO products have been approved to carry the following symbol:




All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of BUFFALO. Every effort is made to ensure all details are correct at the time of going to press, however, BUFFALO reserve the right to change specifications without notice.

DECLARATION OF CONFORMITY

| | |
|-------------------------|--|
| Equipment Type | Rice Cooker |
| Model | J300-A |
| Legislation | C-Tick AS/NZ 3820 Essential Safety Requirements for Low Voltage Electrical Equipment |
| Standards | EN 55014-1:2006 EN 55014-2:1997+A1 EN 61000-3-2:2006 EN 61000-3-3:1995+A1+A2 EN 60335.2.15:2002+A4 Annex ZZ of AS/NZS60335.1:2002+A2+A3 |
| Producer Name | Buffalo |
| Producer Address | Unit 2, 34-38 Anzac Ave, Smeaton Grange, NSW 2567 |

I, the undersigned, hereby declare that the equipment specified above conforms to the above Legislation and Standard(s).

| | |
|------------------|---|
| Date | 09/03/11 |
| Signature |  |
| Full Name | Richard Cromwell |
| Position | Marketing Director |

• Notes •

