















<div> <div> <div>htc</div> <div>无线蓝牙耳机36</div> </div> <div>  <div>快速入门指南 使用前请阅读使用说明书 HTC NE36</div> </div> </div> <div> <div>1</div> </div>	<div> <div> <div>产品规格</div> <div>型号: HTC NE36</div> </div> <div> <div>蓝牙</div> <div>范围: ≈10m 版本: 6.0</div> </div> <div> <div>喇叭</div> <div>直径: 14mm 阻抗: 16Ω</div> </div> <div> <div>耳机功率</div> <div>输入: 5V=300mA 电池容量: 50mAh 使用时间: ≈6小时 充电时间: ≈1.5小时</div> </div> <div> <div>充电仓功率</div> <div>输入: 5V=300mA 输出: 5V=100mA 电池容量: 300mAh 充电时间: ≈1.5小时 充电仓充满电时, 能给耳机充电约2次</div> </div> </div> <div> <div>2</div> </div>	<div> <div>物品清单</div> <div>  <div>充电仓</div> </div> <div>  <div>2 耳机</div> </div> <div>  <div>快速入门指南 USB-C充电线 挂绳</div> </div> </div> <div> <div>3</div> </div>	<div> <div>部件</div> <div>  <div>耳机指示灯 多功能触摸键</div> </div> <div>  <div>充电触点 耳机喇叭</div> </div> <div>  <div>Type-c 充电口 充电仓指示灯</div> </div> </div> <div> <div>4</div> </div>	<div> <div>取出耳机并配对</div> <div>  </div> </div> <div> <div>5</div> </div>	<div> <div>如何佩戴耳机</div> <div>  </div> </div> <div> <div>6</div> </div>	<div> <div>1</div> </div>	<div> <div>2</div> </div>	<div> <div>3</div> </div>	<div> <div>开机和关机</div> <div>  </div> </div> <div> <div>10</div> </div>	<div> <div>连接到蓝牙设备</div> <div>  <div>在您的设备上, 打开蓝牙并选择连接则“HTC NE36”。</div> </div> </div> <div> <div>11</div> </div>	<div> <div>基本操作</div> <div>  </div> </div> <div> <div>12</div> </div>	<div> <div>功能操作</div> <div> <ul style="list-style-type: none"> 暂停/播放: 轻触任一耳机一次 音量加: 轻触右耳机二次 音量减: 轻触左耳机二次 上一曲: 轻触左耳机三次 下一曲: 轻触右耳机三次 接听/挂断电话: 轻触任一耳机一次 通话拒接: 按任一耳机2秒 启动语音助手: 轻触左耳机四次 游戏模式/音乐模式切换: 轻触右耳机四次切换 <div>注: 出厂设置默认为音乐模式</div> <div>注: 通知声音较大的是游戏模式</div> <div>耳机夜跑灯: 按任一耳机2秒可打开/关闭</div> </div> <div> <div>指示灯显示</div> <table> <tr> <th>耳机指示灯</th><th>状态</th></tr> <tr> <td>白灯和红灯交替闪烁</td><td>两个耳机-开机 单耳机: 未配对</td></tr> <tr> <td>白灯常亮</td><td>耳机充电中</td></tr> <tr> <td>灭灯</td><td>配对成功或充满电</td></tr> <tr> <th>充电仓指示灯</th><th>状态</th></tr> <tr> <td>红灯闪烁</td><td>充电仓充电中</td></tr> <tr> <td>红灯常亮</td><td>充电仓充满电</td></tr> </table> </div> </div> <div> <div>13</div> </div>	耳机指示灯	状态	白灯和红灯交替闪烁	两个耳机-开机 单耳机: 未配对	白灯常亮	耳机充电中	灭灯	配对成功或充满电	充电仓指示灯	状态	红灯闪烁	充电仓充电中	红灯常亮	充电仓充满电	<div> <div>如何清除蓝牙配对历史记录</div> <div>  </div> </div> <div> <div>14</div> </div>	<div> <div>产品中有害物质名称及含量</div> <table> <tr> <th rowspan="2">部件名称</th><th colspan="6">产品中有害物质的名称及含量</th></tr> <tr> <th>铅(Pb)</th><th>汞(Hg)</th><th>铜(Cu)</th><th>六价铬</th><th>多溴联苯</th><th>多溴二苯醚</th></tr> <tr> <td>印刷电路组件</td><td>○</td><td>○</td><td>○</td><td>○</td><td>○</td><td>○</td></tr> <tr> <td>外壳等小结构件</td><td>○</td><td>○</td><td>○</td><td>○</td><td>○</td><td>○</td></tr> </table> <p> 本表格依据SJ/T 11364的规定编制。 ○: 表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。 ×: 表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。 表单标记“X”的部件, 因全球技术发展水平限制而无法实现有害物质的替代。 </p> <p>印刷电路板组件: 包括印刷电路板及其零部件, 电子元件等, 根据产品型号不同, 您所购买的产品可能不会含有以上所有部件。</p> </div> <div> <div>15</div> </div>	部件名称	产品中有害物质的名称及含量						铅(Pb)	汞(Hg)	铜(Cu)	六价铬	多溴联苯	多溴二苯醚	印刷电路组件	○	○	○	○	○	○	外壳等小结构件	○	○	○	○	○	○	<div> <div>重要安全说明</div> <p>在使用本产品之前, 请仔细阅读本说明书中的所有安全说明。</p> <div> <div>常规安全说明</div> <ul style="list-style-type: none"> 小心使用本产品, 并将其存放在没有极端温度、高压和潮湿的清洁环境中, 确保产品存放在不易弯曲或挤压的地方。 维修和更换只能由授权的售后服务人员进行。 请勿自行拆卸或更换产品的任何部件, 以防受伤或损坏设备。 对产品的任何未经授权的修改都将使保修无效。 仅在允许蓝牙传输的环境中使用本产品。 </div> <div> <div>个人安全说明</div> <ul style="list-style-type: none"> 如果产品有明显缺陷或出现磨损或温度过高等异常, 请勿使用。 执行需要全神贯注的高风险任务时, 请勿使用本产品。 为了保护您的听力, 请勿长时间用高音量收听。 请将产品及其包装放在儿童和宠物接触不到的地方, 以防发生吞咽和窒息等事故。 </div> <div> <div>电池安全说明</div> <p>该产品内置可充电电池, 请阅读以下说明, 确保安全使用和处置。</p> <ul style="list-style-type: none"> 请勿将产品长时间暴露在热源中, 如火或阳光直射。 仅将产品存放在环境温度在 0°C 至 35°C (32°F 至 95°F) 的环境中。 请勿在产品产生灰尘、烟雾、高温、高压或高温度的环境中使用或存放本产品。 保持产品干燥, 远离液体或湿气。 只能使用经 FCC 或 CCC 认证、输出电压为 DC 5V/1A 的充电器。 充电时不要使用产品。 产品充电时间不要超过 8 小时。 按照当地固体废物管理规定负责处理本产品。 </div> </div> <div> <div>16</div> </div>	<div> <div>售后服务电话: 4009933981</div> </div> <div> <div>17</div> </div>	<div> <div>htc</div> </div> <div> <div>18</div> </div>
耳机指示灯	状态																																																									
白灯和红灯交替闪烁	两个耳机-开机 单耳机: 未配对																																																									
白灯常亮	耳机充电中																																																									
灭灯	配对成功或充满电																																																									
充电仓指示灯	状态																																																									
红灯闪烁	充电仓充电中																																																									
红灯常亮	充电仓充满电																																																									
部件名称	产品中有害物质的名称及含量																																																									
	铅(Pb)	汞(Hg)	铜(Cu)	六价铬	多溴联苯	多溴二苯醚																																																				
印刷电路组件	○	○	○	○	○	○																																																				
外壳等小结构件	○	○	○	○	○	○																																																				

HTC

Wireless Earphones 36



Quick Start Guide

HTC NE36

Product Specifications

Model: HTC NE36


Bluetooth
Range: ≈10 m
Version: 6.0

Speaker
Diameter: 14 mm
Impedance: 16 Ω


Earphone power
Input: 5 V≈50 mA
Battery capacity: 50 mAh
Battery life: ≈ 6 hrs
Charging time: ≈ 1.5 hrs

Charging case power
Input: 5 V≈300 mA
Output: 5 V≈100 mA
Battery capacity: 300 mAh
Charging time: ≈ 1.5 hrs
Earphone recharges: 2 charges (when case is fully charged)


What's in the box




Charging case




2 Earphones



Quick Start Guide




USB-C cable




Lanyard

Components



Take out and pair the earphones




If you're using the earphones for the first time, remove both from the charging case. The LED on one earphone will blink white and red alternately, indicating that they are in pairing mode.



Note:

- If the earphones have not been paired with each other, they will automatically enter pairing mode when turned on. You'll hear two beeps when pairing is successful.
- If the earphones have been paired before, they will automatically reconnect to each other when turned on. You'll hear a beep when they connect.

How to put on the earphones



Power on and off




Power on
Taking the earphones out of the charging case will automatically turn them on.
To manually turn on each earphone, press and hold the touchpad for three seconds.


Power off
Placing the earphones in the charging case will automatically turn them off.
To manually turn off each earphone, press and hold the touchpad for five seconds.

Note: If the earphones are not paired with a Bluetooth device within three minutes after powering on, they will automatically power off. They will also power off after three minutes if the paired Bluetooth device moves out of the effective connection range and has not reconnected.


Connect to Bluetooth device



On your device, turn on Bluetooth and choose to connect to "HTC NE36".



Basic operations



Key functions

- Play/Pause: Tap either earphone once.
- Volume up: Tap the right earphone twice.
- Volume down: Tap the left earphone twice.
- Play previous track: Tap the left earphone three times.
- Play next track: Tap the right earphone three times.
- Answer/end call: Tap either earphone once.
- Reject call: Press and hold either earphone for two seconds.
- Activate voice assistant: Tap the left earphone four times.
- Switch between Game and Music modes: Music mode is the default mode. Tap the right earphone four times to switch between modes. (The louder notification sound indicates Game mode.)
- Earphone running light: Press and hold either earphone for two seconds to turn on or off.


Indicator LEDs

Earphone LED	Status
Blinking white and red	Both earphones: Powered on Single earphone: Unpaired
Solid white	Earphone charging
Off	Paired or fully charged

Charging case LED	Status
Blinking red	Case charging
Solid red	Case fully charged

How to reset the earphones

If the earphones fail to pair or reconnect to each other, reset them by tapping both earphones five times simultaneously. Note: Resetting the earphones will clear the Bluetooth pairing history.



Important Safety Instructions

Carefully read all the safety instructions in this document before using the product.

General safety instructions

- Use the product with care and store it in a clean environment that is free from extreme temperature, pressure, and humidity. Make sure that the product is stored in a location where it cannot be bent or squeezed.
- Repairs and replacements should only be performed by authorized after-sales service staff. Do not attempt to disassemble or replace any part of the product yourself to prevent injuries or damage to the device. Any unauthorized modification to the product voids the warranty.
- Only use the product in environments where Bluetooth transmission is permitted.

Personal safety instructions

- Do not use the product if it is obviously defective or exhibits abnormalities such as bulging or excessive heating.
- Do not use the product when performing high-risk tasks that require your full attention.
- For your hearing protection, do not listen at high volume for long periods.
- Keep the product and its packaging out of reach of children and pets to prevent accidents such as swallowing and choking.

Battery safety instructions

The product has a built-in rechargeable battery. Read the following instructions to ensure safe use and disposal.

- Keep the product away from prolonged exposure to heat sources such as open fires or direct sunlight.
- Only store the product in environments with ambient temperatures of 0°C to 35°C (32°F to 95°F).
- Do not use or store the product in dusty, prone, smoke-prone, high-temperature, high-pressure, or highly humid environments.
- Keep the product dry and away from liquids or moisture.
- Only use an FCC or CCC-certified charger with an output voltage of 5 V/1 A DC.
- Do not use the product while charging.
- Do not leave the product charging for longer than eight hours.
- Dispose of the product responsibly according to your local waste management guidelines.

FCC ID: 2BXHR-NE36

FCC Caution:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

*Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

US REP

Company name:	MIRAMONT SOLUTIONS LLC
Company address:	19 GEORGETOWN, IRVINE, CA 92612 United States
FRN:	0036313369
Agent name:	Wenyi Wang
Title:	CEO
Email:	wenyiwang@miramontsolutions.com
Phone:	951 401 3633

Legal notice

Trademarks and permissions:
HTC and the HTC logo are trademarks of HTC Corporation and used under license by Shenzhen Brands World Technology Co., Ltd. Copyright © 2025 Shenzhen Brands World Technology Co., Ltd. All rights reserved.
THIS DOCUMENT IS FOR INFORMATION PURPOSES ONLY AND DOES NOT CONSTITUTE ANY KIND OF WARRANTY.