


Buttons and functions



① Short press to decrease volume, long press to previous track.


② Long press to turn on/off; Short press to play/pause.

③ Short press to increase volume, long press to make a song.

④ Short press mode switching, Long press light switch.

Shutdown: When the speaker is not in use, press and hold the "⏻" button to shut down to prevent power loss. Low battery alarm and automatic shutdown function: When the battery level is below 10%, the speaker will emit a prompt sound. At this time, the speaker should be charged in a timely manner. When the battery level is below 3%, the machine will automatically shut down.

Back Interface Description



① DC 5V Type-C charging port.

② TF card socket, insert TF card to automatically play music (supports TF card playback, up to 256G (supports MP3, WAV music formats).

③ AUX audio input ports, insert a 3.5mm cable to automatically enter AUX mode.

Microphone operation instructions

⊕ Short press the microphone to increase the volume; Long press and reverb.

⊖ Short press the microphone to reduce the volume; Long press to reduce reverb.

⏻ Long press the power button to turn on/off (the blue light remains on after successful pairing); Short press the power button to select three sound effects modes: KTV mode Shoumai mode, professional mode.

🎤 Short press the microphone button to cancel the original sound; Long press to switch between six magic sound modes: It's female to male, male to female, doll sound, monster sound, machine sound, and original sound.

Operation Instruction

1. Bluetooth mode

(1) Bluetooth connection: When turned on, the default setting is Bluetooth. Enter Bluetooth mode or press the "🔗" button to switch to Bluetooth mode. Open the Bluetooth scan on your phone, search for "ZZA-K1" and click pairing. After successful connection, there will be a prompt sound indicating that Bluetooth is connected.

(2) Play music: Open Bluetooth on your phone or other device,download and play your favorite songs.

(3) After connecting the machine to the phone once, Bluetooth has a memory function, which can be automatically or manually connected when turned on; If you need to disconnect, you can use your mobile Bluetooth device to disconnect or double-click the "🔗" button to forcibly disconnect Bluetooth.

2. TF card mode

(1) Insert the TF card, and the machine will automatically perform a priority playback with a prompt sound. When all TF cards are inserted, you can switch by briefly pressing the "🔗" button.

3. AUX (external audio input) mode

(1) Insert the AUX external audio cable, and the audio system will automatically play back with priority and a prompt tone.

(2) When both AUX and TF cards are inserted simultaneously, you can switch by briefly pressing the "🔗" button.

4. Four indicator light states

(1) Charging indicator: The charging red light is on, and the fully charged red light is off.

5. Music Lamp Description

(1) This product has six music light modes, namely: color running, gradient breathing (alternating red, blue, and green gradient breathing, red breathing, blue breathing, green breathing, and turn off the light effect; press and hold the "🔗" button once to switch between one light effect.

6. Wireless microphone usage

(1) The speaker and microphone are turned on simultaneously, and the 2.4G wireless signal is automatically paired. At this point, users can start shouting and adjust the buttons to their preferred style according to their preferences.

Common problems and solutions

Malfunction	Solution
Unsuccessful pairing	Turn off the speaker and turn it on again or turn off Bluetooth on the phone and turn it on
Staccato	Whether the connection distance is out of range or there is an obstacle between the speaker and the phone
Play silently	Check if the speaker is the smallest
Can not boot	Whether the built-in battery of the speaker is charged
Power light is not on	Check whether the charging port is plugged in

第一页

第二页

第三页

第四页

Products specifications

Speaker specifications:

BT Version : V5.3

Transmission distance : 10m

Power : 16W

Rated input : 5V=1A

Battery capacity : 2400mAh

Playing time : About 5 hours

Charging time : About 3 hours

File format : Support MP3、WAV

External audio source : 3.5mm audio input

Charging port : Type-C

Microphone specifications:

Transport Protocol : 2.4G

Transmission distance : 10m

Mickey type : Capacitive type

Charging Voltage : 5V=0.5A

Directional feature : Unidirectionality

Battery capacity : 400mAh

Playing time : About 6 hours

Charging time : About 1 hours

Charging port : Type-C

Packing list

Speaker x 1                      Charging Cable x 1

Audio Cable x 1                Manual x 1

Single/dual Microphone (optional)

Warranty statement

Disclaimer

This user manual does not have any form of guarantee, position expression or other implication.

The mentioned products, specifications and information are for reference only, and the content will also be updated on the webpage at any time, without additional line notification.

Warranty statement:

The product attached to this document is guaranteed as follows: If the product is twelve (12) months from the date of purchase ("Warranty Period"), under normal conditions of use due to quality defects damaged, can be repaired free; if the manufacturer confirms that it cannot be repaired, free replacement; repaired or replaced product, Continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). Purchase date by sale The ticket date shall prevail; if the purchase date cannot be determined, the warranty period shall be 13 Months calculation. If you apply for a warranty, please call the product service hotline first and execute it in the manner instructed by us. When applying for warranty, you need to provide an accurate, complete and clearly filled out valid sales invoice.

The above guarantee does not apply to the following situations:

1. The validity period of the three packs is exceeded;

2. Alteration of the warranty card and product code does not match the product body;

3. Causes caused by misuse, abuse or improper transportation, use, maintenance or storageimpaired or damaged;

4. Failure or damage caused by force majeure (such as earthquake, war, fire, etc.) or accident bad;

5. The zipper and buckle are damaged due to excessive force;

Warranty statement

6. Disconnection or tearing caused by excessive load;

7. Any damage caused by sharp objects;

8. Products with signs of burning or water immersion;

9. Damage caused by unauthorized disassembly;

10. Aging, discoloration, abrasion, rupture and other losses occurred during normal use of the product.

11. If the original identification label of the product is changed or damaged, this guarantee will become invalid.

The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee. You should Check on the spot and raise objections to any discrepancies.

Precautions for product use

(1) Don't attempt to disassemble the unit and change any part, except there is operation method mentioned in the manual.

(2) Don't expose the unit to liquid, moisture or humidity, since it is not a waterproof product.

(3) Disconnect the unit with your Bluetooth device and move it to the safe area if the liquid get inside the unit.


(4) Don't assemble or disassemble the unit to avoid electric shock, if there is water on your hands.

(5) Don't expose the unit to extremely high temperature or dispose of the unit in fire as it will result in an explosion.

(6) Don't place the unit in an electromagnetic interference environment to avoid malfunction.

ZZA®

WIRELESS KARAOKE MICROPHONE & SPEAKER



User manual

Please read all instructions carefully and retain for future use

封底

第五页

第六页

封面



FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.