

Quick Start Guide

*Cell Pro(Add-on Camera)
*Cell Pro Kit(Hub+Camera)



DE


ES

FR

IT

NL

PT



www.imoulife.com

Welcome

Thank you for choosing IMOU.

We are devoted to providing you easy smart home products. If you have problems using the product, please contact our service team before returning your product.


Our service mail: service.global@imoulife.com

Frequently asked questions can be found at imoulife.com/support/help






Package content



Note: Press the SYNC button to pair with the base station.

Press and hold the SYNC button for 8s to reset the camera.


Installing Battery




The pattern of the LED indicator is included in the following table.


LED Indicator Status	Device Status
off	Sleeping modeRun out of battery
Green light on	Alarm is triggeredInstructed to wake
Green light flashing	Reconnecting Wi-Fi
Green light quick flashing	 Waiting for pairing with the base station
Green light stay on for 10 s, then off	 Pairing succeeded
Red light stay on for 10 s, then off	Pairing timeout
Red light stay on for 1 s, then off	Reset completed

Hub





1















i Tips



To ensure the best possible wireless performance, please make sure there are no obstacles and electromagnetic interference between the camera and hub.

2



Pairing with the Hub




- 1 Press the SYNC button, and then the indicator on the base station flashes with white light.
- 2 Press the SYNC button, and then the indicator on the camera flashes with green light.




- 3 The system indicator on the Hub stays on with white light for 10 s, and then off.
 - The indicator on the camera stays on with green light for 10 s, and then off.

Note: You can pair six cameras at most with one Hub, and pair one camera at a time. Keep the distance of the Hub and the camera within 30 cm (12 inches)during pairing.

Installing Camera



3 Pairing mit dem Hub



Troubleshooting

Problem	Solution
Cannot set up camera	 Ensure your mobile device and the camera are within range of your Wi-Fi router. Ensure the LED indicator on the camera isflashing green before beginning setup.
The APP says "Failed to configure device network"	Reset your Camera and connect it again. Some cameras only support 2.4GHz, while some routers have dual band, 2.4G/5G. Make sure you are connecting 2.4GHz only.
The app says "Failed to bind"	The camera is already connected to Wi-Fi, but the router is: Not connected to Internet Poor network status The Wi-Fi signal is not stable due to obstacles or electronic interference
No picture / signal	 Ensure the LED indicator on the camera is flashing steady green. See 'LED Status' section for details if otherwise. Ensure the camera is properly connected to power using the included USB power adapter. Try repositioning the camera, router, or both to improve signal strength.
Picture is not clear	Check the camera lens for dirt, dust, spider webs. Clean the lens with a soft, clean cloth. Remove the vinyl cover on the camera lens.
No audio	Ensure audio function on camera is turned on. Ensure audio is turned up on viewing device.
Phone is not reading QR code	 Clean the camera lens of your Smartphone Ensure that there is enough light on the QR code Don't hold the QR code too close to the camera









