

### Introduction- Front



### Back




### Charging your device



- Please charge your device for at least 1 hour before using.
- When placing magnetic USB cable to device charging contacts make sure it is positioned correctly.
- The LED should blink when charging and solid when fully charged.
- When the battery level falls below 20% it will send low battery warning message to people on the contact list via text message or APP.

### Turning on and off device



- To turn the device on- press the power button 1 second. The LED will flash rapidly. The device can also be turned on automatically by charging the battery.



To turn the device off- press the power button 15 seconds

### Download mobile app



IOS Download



Andorid Download

- Or search smart locator from APP store or Google play

### Create a smart locator account



- Create a login ID and password for this application

### Add device from APP



**TIP** The IMEI number must be entered correctly.

### How to set contact numbers



- Select the right country code and put the numbers you want to contact.

**TIP** It is not mandatory for all numbers to be set, however a minimum of one must always be set.

[www.eviewgps.com](http://www.eviewgps.com)

## Location update (Automatic)



- Select working mode and you can choose how often the map will refresh the device's location by change reporting time, default working mode is 4 and refresh location every 1 hour.

**TIP** Different working mode with different power consumptions, remember that more frequent location updates will reduce battery life.

## Location update (Manual)



**TIP** You can only use this function when device in working mode 1,2 or 3.



③ Continuous locate from APP

- Default continuous locate time is every 10 seconds to refresh location and last 10 minutes, you can change the time from APP.

**TIP** You can only use this function when device in working mode 1,2 or 3.

## Creating a geofence



- A geofence is a virtual boundary around a particular location. If you have set a geofence, you will receive a notification when your device leaves or enters the boundary of geofence zone.

## Activity monitoring



- Use Activity Tracking to easily find out if your pet is getting enough exercise.

## History playback



## Specifications

Dimension: 61mm*35mm*16mm
Weight: 39g
Battery: Rechargeable, 3.7V,850mAh
Charging voltage: 5V DC
Battery life: Up to 5 days under normal use.
Waterproof: IP67

### Very Important

We strongly recommend you to set unique password for text message to protect your own privacy.

Keep the IMEI and SIM in confidential, or your privacy may expose.

## GPS Pet Tracking System



— QUICK START GUIDE —

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This Product meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 0mm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.