

# TIPS + TRICKS

Minimum input = 2 cups (16 oz) Maximum input = 8 cups (64 oz)



For easy dispensing, ensure the unit is running on a program and the auger is turning.



**DO NOT** add ice or hot or solid ingredients like fruit, ice cream, or frozen fruit.



For best results, chill liquid(s) or blended ingredients before adding to the unit.



For your ideal frozen drink texture, use the thickness control setting to adjust.



All inputs must include at least 6% sugar.\*



When using the SPIKED SLUSH program, all inputs must be between 2.8% and 16% alcohol.

\*Refer to the Required Sugar Content section in the Inspiration Guide for more information.

## USING THE SLUSHi

1. Add chilled liquid(s) or blended ingredients.
2. Press the power button to turn on.
3. Select a program to start.
4. If desired, adjust default temperature.
5. Unit will beep when drink is complete.
6. Dispense and enjoy.

### ! WHAT TO AVOID

**DO NOT** use diet or low-sugar beverages in this unit. these beverages will freeze solid and can cause damage to the unit.

**EXAMPLES:** diet soda, seltzer, sugar-free juice, black coffee, energy water

Refer to the Required Sugar Content section in the Inspiration Guide for more information.



## PRESET SETTINGS

5 unique programs that use **Instant Cooling Technology** to determine the perfect temperature for your ideal frozen drink.

SLUSH	SPIKED SLUSH	FRAPPEÉ	MILKSHAKE	FROZEN JUICE
Designed to transform your everyday beverages.	Designed for beverages with alcohol content.	Designed for coffee shop lovers to make frozen treats.	Designed for dairy and creamier-based beverages.	Designed for naturally sweetened beverages.



SLUSH



SPIKED  
SLUSH

# COLA SLUSH

KID FRIENDLY

## KICKSTARTER

RECIPE LEVEL: BEGINNER | PREP: 5 MINUTES | TOTAL TIME: < 1 HOUR

<b>MAKES:</b>	2-3 SERVINGS	4-6 SERVINGS	6-8 SERVINGS
<b>INGREDIENTS:</b>	2 (12-oz) cans (or 3 cups) cola, chilled	4 (12-oz) cans (or 6 cups) cola, chilled	5 (12-oz) cans (or 7 1/2 cups) cola, chilled

**NOTE: DO NOT** use diet or low sugar beverages in this unit.

## DIRECTIONS:

- 1 Pour cola into the vessel.
- 2 Turn on the unit using the power button.
- 3 Press **SLUSH** program to start.
- 4 If desired, adjust temperature. Program will start at recommended temperature for ideal thickness.
- 5 Once frozen drink reaches desired texture, unit will beep.
- 6 When slush is complete, dispense and enjoy.

**NOTE: DO NOT** turn program off until all frozen drink has been dispensed for easy cleaning.

# FROZEN MANGO MARGARITA

## KICKSTARTER

RECIPE LEVEL: BEGINNER | PREP: 5 MINUTES | TOTAL TIME: < 1 HOUR

<b>MAKES:</b>	2-3 SERVINGS	4-6 SERVINGS	6-8 SERVINGS
<b>INGREDIENTS:</b>	2 cups mango margarita mix 1/3 cup water, chilled 1/3 cup lime juice, chilled 1/3 cup tequila	4 cups mango margarita mix 2/3 cup water, chilled 2/3 cup lime juice, chilled 2/3 cup tequila	5 cups mango margarita mix 3/4 cup water, chilled 3/4 cup lime juice, chilled 3/4 cup tequila

## DIRECTIONS:

- 1 Pour all ingredients into the vessel.
- 2 Turn on the unit using the power button.
- 3 Press **SPIKED SLUSH** program to start.
- 4 If desired, adjust temperature. Program will start at recommended temperature for ideal thickness.
- 5 Once frozen drink reaches desired texture, unit will beep.
- 6 When margarita is complete, dispense and enjoy.

**NOTE: DO NOT** turn program off until all frozen drink has been dispensed for easy cleaning.