

# DAS.4

## SU20 | User Manual



Thank you for choosing our smart watch. You can fully understand the use and operation of the equipment by reading this manual.

The company reserves the right to modify the contents of this manual without any prior notice.

The product contains: a packing box, a manual, a smart-watch, and a USB cable.

### **Watch function description**

Button description:



#### **Up button:**

Turn on and off the screen; one press to return to the main interface; long press to restart the watch.

#### **Middle button**

Press the middle button to open the main menu. Press 2 times to change the navigation style of the main menu.


Button down

Short press to enter multi-sport mode.

In addition, when the watch has the screen off, the watch can turn on the screen by pressing the button.

### **Charging instructions:**

Magnetic charging, as shown in the figure below.



### **1.1 Shortcut function:**

- 1) Swipe to the left to display the “+” icon, click the icon to add part of the menu as a shortcut.
- 2) Slide down to display, Bluetooth connection status, time, power, brightness adjustment and other functions.
- 3) Swipe to the right to display, time/date/week, the latest message (enter to view multiple messages)/turn on or off Bluetooth for calls and display some of the recently used menu functions.
- 4) Swipe up to enter the menu interface, and slide up and down to find the corresponding function.
- 5) Long press the watch face interface and slide to switch the watch face, select a new one to set it successfully.

### **1.2 Push message**

- 1) When the watch is bound to the APP, and the notification permission is turned on, the new messages received in the notification bar of the mobile phone will be pushed to the watch, and a total of 10 messages can be saved. After 10 messages the new ones will overwrite the old ones.
- 2) Swipe to the bottom to press the delete icon to clear all message records.

### **1.3 Drop-down menu**

From dial interface slide down to open the drop-down menu interface.

- 1) Bluetooth connection status; time display, power display;
- 2) The first icon, about
- 3) Settings; enter the settings

4) Adjustable screen brightness

5) Stopwatch

Click the stopwatch to enter the interface, and you can record the time

### **1.4 Phone/Call History**

1. Swipe left, tap the call icon to turn on / off Bluetooth, turn on Bluetooth, search for your mobile Bluetooth devices, find the name and MAC address of your watch (Select 'Information' on the watch) and select it to connect. Once connected to Bluetooth successfully, you can make and reject phone calls on your watch.

2. Call history, calls made and received can be saved. More than 50 calls can be saved and will be automatically replaced with new ones if they exceed 128. Press any saved number to make a call.

3. You can dial any number via the keypad.

### **1.5 Messages**

Once the smartwatch and application are successfully connected, you can activate the corresponding applications to receive notifications from your mobile phone and synchronize with the smartwatch.

#### **1.5.1. Incoming call notification:**

Activate the call reminder in the app. When the phone receives the call reminder, the smartwatch will light up and vibrate.

#### **1.5.2. SMS notification:**

Enable SMS notification in the application. When you receive one or more SMS messages on your mobile phone, the watch will receive one or more SMS reminders.

### 1.5.3. Other application message notifications:

Turn on the corresponding messaging switch for your applications, such as Outlook, Facebook, and other applications. When the mobile receives message notifications for single / multiple applications, the watch will receive the corresponding notifications respectively.

### 1.6 Frequently used contacts

Through the application, you can synchronize up to 20 contacts with the watch for shortcut.

## 1.7 Fitness data

Exercise data are activated from the factory. To view fitness data, swipe from bottom to top to display the current number of steps, distance, and calories recorded by the watch. The data will be deleted at 12 in the morning every day.

## 1.8 Sports modes (strike, running, cycling, skipping rope, badminton, basketball, football)

1.8.1 Select the corresponding exercise mode. Click the start button on the screen to enter the corresponding exercise mode. click calculated to stop the exercise, click the end button to end the exercise and save the data.

1.8.2 When the exercise time is longer than 1 minute, the exercise data can be saved. When the exercise lasts less than 1 minute, a message "Too little data to save" will appear.

## 1.9 Heart rate

Position the watch correctly on your wrist, enter the heart rate menu and you can measure the heart rate value each time.

## **1.10 ECG**

Position the watch correctly on your wrist, enter the ECG menu (you must open the “ECG monitor” from the application), you can measure the ECG value and the ECG data will be stored in the application at the same time. For this function, the watch must be connected to the application for its use.

## **2.0 QR code**

Scan the QR code with your mobile phone to download the watch application.

## **2.1 Calculator**

You can do simple operations with a calculator

## **2.2 Remote music**

You can control the music of your mobile after connecting to the watch.

## **2.3 Sleep**

Sleep recording from 18:00 to 10:00. The data is synchronized with the application.

## **2.4 Stopwatch**

You can measure time

## **2.5 Weather**

After the smartwatch is connected to the application and the data is synchronized, select the weather to see the weather conditions of the day.

## **2.6 Find mobile phone**

Once the watch is connected to the app, you can search for your mobile by selecting find the device mode and your mobile will start vibrating.

## **2.7 Meteorology**

Through the weather function, you can see the indicators of ultraviolet (UV) radiation and the air pressure condi-

tions of the day.

## **2.8 Breathing**

There are 3 breathing techniques: slow, moderate, and fast where they can be selected. Adjust your breathing according to the rhythm you have chosen.

## **2.9 Menu style**

There are a variety of menu styles to choose from.

## **3.0 Settings**

- 1) Through the settings you can change the language, connect the application, and synchronize the data. The watch automatically connects to the default language after connecting to the mobile.
- 2) Change the smartwatch face, drag to the right to select the next smartwatch face, select a face by pressing once.
- 3) Screen Waiting. You can select a specific time that the screen will remain open.
- 4) Vibration intensity. You can set the reminder vibration volume.
- 5) Bluetooth for calls. Bluetooth for calls can be turned on / off
- 6) Password. a 4-digit password can be set (if you forget the password, enter 8762, which can restore access)
- 7) Reset to factory settings. Click V to enable factory reset and click X to cancel factory reset.


## **Bind APP**

### **1. APP download method**

#### **1.1 Scan the QR code to download**



## 1.2 Application market search and download

Android side: 

On Google play app market search WearPro to download it

IOS side: 

On App Store search WearPro to download it

Android phones: When WearPro is installed the application icon is as shown in the figure

Apple phones: When WearPro is installed the application icon is shown in the figure:

## 2.Bind Bluetooth


2.1 Not connected: 

After turning on the watch, Bluetooth is always on in the device. After opening the application, go to the "Device" option and click on "Connect now", select and click on the corresponding watch device name, to successfully connect the watch to the application.

2. Connected: 

The smartwatch was successfully connected to the application and the time / date were synchronized at the same time.

### 2.3 Bind audio call

On the Home screen, swipe from left to right and tap the phone icon to change the source of the call. On the Home screen, drag downwards to open the quick settings and press . You can see the Bluetooth name and MAC address of the device. Turn on Bluetooth on your mobile phone to search for the device name and tap connect.



### **3. Find the device**

Once your watch is successfully connected to the app, you can select the find mode and the watch will start vibrating to locate it.

### **4. Camera**

Select the camera mode, tap the icon to take a photo remotely and the photo will be automatically saved in the mobile photo album.

### **5. Data synchronization**

When the smartwatch is connected to the application, the watch data can be synchronized with the application.

### **6. Raise your hand to brighten the screen**

Wear the watch properly on your wrist. When you select the option, you can see the time simply by raising your hand.

### **7. Do not disturb mode**

In the application you can set a specific time of day, not to receive calls and notifications on your watch.

### **8. Daily alarm clock**

You can set a specific time in the app to notify you.

### **9. Sedentary reminder**

Set the start-end time and idle time (minutes) in the app, click to enter the repeat setting only once, or select the idle reminder date (week). When the device detects a sedentary state, the smartwatch will vibrate and a sedentary life alert icon will be displayed.

### **10. Drink water reminder**

Warns you about water consumption at a specific time.

### **11. Dial push**

There is a selection of dials from the collection

Log in to the application, go to "Device" -> "Call" ->

Select the dial you want.

## **12. Firmware version**

The watch version is displayed and the user can choose to upgrade the firmware version. Bind APP

### **Disclaimer**

- 1) Please ensure that Bluetooth and mobile GPS are turned on. When searching for the device via Bluetooth, make sure that no other device is connected. When searching for the device via Bluetooth, keep a close distance between your mobile and smartwatch.
- 2) If the Bluetooth connection is unstable during operation, try restarting the watch and connecting it to the mobile again. Be sure to turn on the automatic start for the smartwatch application, in the settings of your mobile phone. Also turn off the battery optimization (without restrictions) for the specific application, so that the continuous application-smartwatch communication is not interrupted.
- 3) If there is a problem with the watch or its use, please contact the store where you purchased it.
- 4) The measurements of the watch are for reference only and not for medical use. Please follow your doctor's instructions and do not use the measurements to make your own diagnosis.
- 5) The watch is waterproof with IP67 certification which means that it can withstand accidental contact with water. However, it can not be used for diving or being under water for a long time. In addition, the watch should not come in contact with hot water, as steam can penetrate the seal and cause internal damage.
- 6) The company has the right to modify the contents of

this user manual without prior notice. Some functions differ depending on the software they carry.

7) CAUTION: Do not use a power adapter that gives more than 5v == 1A to charge the device. If you use a charger larger than 1A for charging, the circuit and / or battery may be damaged.

8) Once the watch is charging, disconnect the cable from the power supply to prevent a short circuit if it comes in contact with conducting objects.

9) Do not leave the peripherals and accessories in areas where the temperature is too high or too low. Otherwise the device may malfunction.

10) Avoid hitting the device to reduce the risk of damage.

**The warranty terms that cover the product are mentioned in details on the official website [www.das-4.com](http://www.das-4.com).**

**IP67: Dust resistant!  
Seawater is prohibited.**

**[www.das-4.com](http://www.das-4.com)**