


Installation Instructions

V1.0



PIMF2

Thank you for choosing our product! We strive to provide the best quality and services for our customers. Would you kindly share your experience on Amazon if you are satisfied? Should you have any issues, please don't hesitate to contact us.

Telephone: 800-556-9829 Mon-Fri 10am – 6pm (PST) (USA) (CAN)

Email: supportus@pipishell.net (US/CA/DE/UK/FR/IT/ES/JP/AU)

IMPORTANT SAFETY INFORMATION

- Check package contents against Supplied Parts and Hardware Lists to assure that all components were received undamaged. Do not use damaged or defective parts.If you require replacement parts, contact customer service at supportus@pipishell.net
- Not all parts and hardware included will be used.
- Carefully read all instructions before attempting installation.If you do not understand the instructions or have any concerns or questions, please contact customer service at supportus@pipishell.net
- This product may contain moving parts. Use with caution.
- Do not use this product for any purpose or in any configuration not explicitly specified in this instruction. We hereby disclaims any liability for injury or damage arising from incorrect assembly, incorrect mounting, or incorrect use of this product.
- DO NOT INSTALL INTO DRYWALL ALONE.

Tools Needed (Not Included)




Stud Finder




Tape measure



Pencil



Drill



Hammer



1/8 in.(3 mm)
Wood Drill



25/64 in.(10mm)
Concrete Drill




25/64 in.(10 mm)
Socket Wrench




Screw Driver

Supplied Parts




TV Bracket

02 X1



Wall plate and Arm

01 X1







Extender Brackets











03 X4

Supplied Hardware

Hardware for Attaching Wall Plate to Wall


<p>Lag Bolts M6X60</p>  <p>x3 A1</p>	<p>Washers Ø6mm</p>  <p>x3 A2</p>	<p>Wall Anchor</p>  <p>x3 A3</p>	<div>CAUTION!</div> <p>These anchors are for concrete or brick walls ONLY. DO NOT use them in drywall or wood studs.</p>
---	--	---	--

Hardware for Attaching TV Bracket to TV

<p>Washers Ø6mm M4–5–6</p>  <p>x4 B1</p>	<p>Spacers L10mm</p>  <p>x8 B2</p>	<p>Spacers L5mm</p>  <p>x8 C</p>	<p>Philips Screws M6 x 15mm M6 x 30mm</p>   <p>x4 x4 D1 D2</p>	<p>Philips Screws M8 x 15mm M8 x 45mm</p>   <p>x4 x4 E1 E2</p>	<p>Philips Screws M4 x 30mm</p>  <p>x4 F</p>
 <p>G X4</p>			 <p>H X4</p>		


Step 1 Measure VESA

Measure the distance between the holes located at the back of your TV (these measures may form the shape of a square, or a rectangle) and check that these taken measures are within the VESA (*) range for this wall mount. (*) VESA: International standard established by the TV manufacturers used to determine if LCD/LED TVs are compatible with wall mounts.




Step 2-1 Choose the combination that applies to your VESA


Determine which TV bracket option A, B, or C, to use based on your TV hole pattern measurements from STEP 1.



for VESA hole pattern:
75 mm X 75 mm
100mm X 100mm
200mm X 200mm




for VESA hole pattern:
300 mm X 300 mm
400 mm X 400 mm




for VESA hole pattern:
300 mm X 200 mm
400 mm X 200 mm

Step 2-2 Select TV hardware


- 1 Bolt diameter: hand thread bolts into threaded inserts on the back of TV to determine the correct bolt diameter(M4, M6, M8)
- 2 Bolt length: verify adequate thread engagement with bolts or bolts/spacers combination. We recommend thread engagement by at least 5 turns.
 - Too short will not hold the TV.
 - Too long will damage the TV.




Too Short



Too Long



Correct





Correct




Step 2-2 Select TV Hardware


- 3** Bolt and spacer combination: spacers sometimes are needed to combine with bolts for several situations as below:




Add distance to wall



Irregular back




Insert






Cables

Step 2-3 Attach the TV Bracket






for VESA hole pattern:
75 mm X 75 mm
100mm X 100mm
200mm X 200mm



for VESA hole pattern:
300 mm X 300 mm
400 mm X 400 mm

or

for VESA hole pattern:
300 mm X 200 mm
400 mm X 200 mm



Step 3A Wall Plate Install (Concrete Wall)


⚠ CAUTION :

Ensure the wall plate is securely fastened to the wall before continuing on to the next step. These anchors are for concrete or brick walls ONLY. DO NOT use them in drywall or wood studs. Drywall covering the wall must not exceed 5/8in. (16mm)




Anchor
A3

3A-1




Position the wall plate at your desired height, level the wall plate and mark the pilot hole locations.

3A-2




Drill 3 pilot holes using a 25/64 in. (10 mm) diameter drill bit. Make sure the depth is not less than 65mm.


Drill pilot holes



3A-3



Install wall plate using lag bolts [A1], washers [A2] and anchors [A3]. Be sure the anchors [A3] are seated flush with the concrete surface. Tighten the lag bolts [A1] only until the washers [A2] are pulled firmly against the wall plate. DO NOT over-tighten the lag bolts [A1].



25/64 in. (10 mm)
Socket Wrench


Step 3B Wall Plate Install (Wood stud)

⚠ CAUTION :

Ensure the wall plate is securely fastened to the wall before continuing on to the next step. These anchors are for concrete or brick walls ONLY. DO NOT use them in drywall or wood studs. Drywall covering the wall must not exceed 5/8in.(16mm)




3B-1





Use a stud finder(not included)to locate wood studs. Mark the edge and center locations.

3B-2



Position the wall plate at your desired height and lineup the holes with your stud center line. Level the wall plate and mark the holes.

3B-3




Drill 3 pilot holes using a 1/8 in.(3 mm) diameter drill bit. Make sure the depth is not less than 2.36in.(60mm)

3B-4


Install the wall plate [01] using lag bolts [A1] and washer [A2]. Tighten the lag bolts [A1] only until the washers [A2] are pulled firmly against the wall plate [01] .




25/64 in.(10 mm)
Socket Wrench



Step 4 Hang the TV onto the wall plate



Take this apart.



Mounting your TV to the brackets and lock it.

If needed, the TV can be tilted.

