



## 8015 Installation Instructions

**Customer Service: 1-877-671-7011**  
**[www.allegion.com/us](http://www.allegion.com/us)**

**⚠ Caution:** Edges of aluminum parts may be sharp. Wear gloves and handle with care.

1. **Measure Door Width:** Measure the butt face of the door (hinge side) and note the width for cutting.
2. **Cut Brush and Retainer:** Slide the brush out of the retainer. Cut the brush to size using **wire cutters or pliers**. Then cut the retainer to the same length. Reinsert the brush and peen both ends to keep it secure.
3. **Close the Door:** Use a self-closing mechanism or manually shut the door before positioning the sweep.
4. **Position the Sweep:** Hold the sweep against the butt face, resting lightly on the floor or threshold bevel to ensure a proper seal.
5. **Attach with Screws:** Use the provided screws in the center of the slotted holes. This allows for adjustment. Don't tighten fully until all gasketing is in place.
6. **Test Operation:** Open and close the door several times to ensure smooth closing and latching. Adjust if needed.



Positive Pressure Tested Gasketing Materials for Fire Doors. Intended for Application to/ with listed steel frames and/or classified steel covered composite, hollow metal type fire doors rated up to 3 hours, wood and plastic covered composite type fire doors rated up to 1-1/2 hours, and wood core type fire doors rated up to 20 minutes. Meets UL10B, UL10C and CAN4-S104-2010 Category J .17L5 9903