

Smart Watch User Manual



Please make a full charge before using it.
APP:FitCloudPro

English

Please make a full charge before using it.
APP:FitCloudPro

1. Download & Pairing

- 1.1 Long press the upper button over 6 seconds for turning on
1.2 Scan the QR code and install the FitCloudPro App or
download the FitCloudPro App from App Store, Google Player and install it



Scan the QR code to get the
instruction video

Compatible system version: Android 5.0 and above, iOS 10.0 and above

- 1.3 Open the FitCloudPro App, allow all the permission and add device

- Step 1: Turn on the Bluetooth of your mobile phone
Step 2: Open FitCloudPro App
Step 3: Click "Add A device" and pair it



Step4: Check "watch menu" about "MAC address last four number like "5994", then go
mobile phone "setting-bluetooth" to search the same bluetooth name with last 4
numbers "5994" to finish BT connection as below operation.



2. Functions on Smart Watch

2.1 Time interface

- 2.1.1 Power on: Long press the upper button over 6 seconds
2.1.2 Power off: Long press the upper button over 5 seconds
2.1.3 Change watch face: Long press the screen over
3 seconds, there are 6 built-in watch faces for choosing



2.1.4 Menu interface, short press the button twice to switch the menu style (6 menu
styles)



2.2 Function menu

- 2.2.1 Steps counter
2.2.2 Heart rate detection
2.2.3 Sleep tracker (21:30 PM to 12:00 AM)



2.2.4 Weather



2.2.5 Music control



2.2.6 Message Notification

The smart notification function of the smart watch relies on the notification bar of the
mobile phone to work, please make sure you have allowed all permissions and the
FitCloudPro App is running in the background

2.3 Password function

Device universal password: 1819, which can be used to unlock the forgotten
password and reset the password to close the password

3. Functions on FitCloudPro App

3.1 Data sync

All the measured data from smart watch will be sync on FitCloudPro App automatically
(including steps, sleep, heart rate, blood oxygen, training)

3.2 Watch faces

Over 100 watch faces for choosing, you could download and custom watch face on
FitCloudPro App

3.3 Notifications

Turn on the switch to sync related information to smartwatch (Phone, Messages,
Facebook, Twitter, WhatsApp, WaChat, Instagram, Skype, KakaoTalk, Line, Others)

Frequently Asked Questions

1. What should I do if there is a problem with the Smartwatch

- Contact customer service personnel
- Select factory settings in the settings and reconnect for use
- Open the tutorial in the settings, scan the QR code to find the answer

2. How to solve the problem of repeated disconnection of devices after Bluetooth connection?

- Keep the FitCloudPro app running continuously in the background to avoid the
system automatically cleaning up the backend apps
- The optimal connection distance is within ten meters
- Avoid connecting multiple devices simultaneously

3. How to get SMS messages and other social notifications?

Note: This Smartwatch can not send message. Get Notifications

Steps:-In the App: Turn on all apps that need push notifications

On the Phone: Allow all permissions for the app and any apps that need
notifications, including pop-ups, alerts, and landscape mode.

Please Note: Why is there no alert popup when the watch receives a message?

This is following the phone. The watch will only have the message alert popup when
the phone also has it.

4. About data synchronization

All the measurement data of your smartwatch (including steps, sleep, blood oxygen,
training) will be automatically synchronized to FitCloudPro App

5. How to avoid excessive power consumption?

- Reduce screen brightness/enable power-saving mode
- Turn off AOD clock/turn on silent mode
- Shorten the duration of screen brightness/turn off full day heartrate monitoring

6. Can't get all contacts in the watch?

If the contact cannot have emoticons as well as symbols, in addition, the phone
number must be preceded by a i in the contact, and there can be no brackets in the
area code.

7. How to get SMS messages and other social notifications?

Note: This Smartwatch can not send messages.


Get Notifications Steps:

In the App: Turn on all apps that need push notifications.

On the Phone: Allow all permissions for the app and any apps that need notifications,
including pop-ups, alerts, and landscape mode.

8. How to set call audio & media audio?

Scroll down on the homepage of the watch and a circle of function icons appears. Tap
on the call icon, call audio and media audio will appear. turn off media audio, the watch
will not receive the sound of music/video/voice playing from your cell phone.



9. How to adjust the call volume?

On the call page, click on the volume marker in the upper right corner of your avatar to
increase or decrease the volume.



10. Watch does not consistently stay connected to your phone?

Repeated connection and disconnection? A: This watch connects via Bluetooth.

Please keep within a 10m range when using it.

For Android, enable background permissions and keep the app open. For iOS, ensure
the app is running in the background. If issues persist, feel free email anytime.

11. Why Step count is not accurate at all? Pushing a stroller it doesn't count any of your
steps?

The smart watch determines activity levels using its gravity sensor and heart rate
monitoring features. However, since pushing a stroller doesn't involve arm movement,
the smartwatch is unable to accurately track the final step count in such cases.

Note: This equipment has been tested and found to comply with the limits for a
Class B digital device, pursuant to part 15 of the FCC rules. These limits are
designed to provide reasonable protection against harmful interference in a
residential installation. This equipment generates, uses and can radiate radio
frequency energy and, if not installed and used in accordance with the
instructions, may cause harmful interference to radio communications. However,
there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television
reception, which can be determined by turning the equipment off and on, the
user is encouraged to try to correct the interference by one or more of the
following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which
the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Important: Change or modifications not expressly approved by the manufacturer
responsible for compliance could void the user's authority to operate the
equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the
following two conditions: (1) This device may not cause harmful interference,
and (2) This device must accept any interference received, including interference
that may cause undesired operation.

RF warning statement: The device has been evaluated to meet general RF exposure
requirement. The device can be used in portable exposure condition without
restriction.