


# MUSICAL BOXING PRO



Please read the instruction before using

## Introduction:

Boxing is a combat sport in which two opponents of equal size and ability cover their fists with gloves, Fighting each other, it is both an usually used to train the speed and strength of the players during amateur and a professional sport. In boxing, boxing targets are boxing training. Since the opponent's gap in boxing matches is so short, speed is more important than strength training. hand offensive and defensive reflexes, the product uses electronically controlled light guidance to train people's ability to respond by sound signals to accurately hit the target point, thus efficient forging exercise one's overall coordination and sensitivity.

## Technical Data:


Input: DC 5V      Power: 5W      Working Voltage: 3.7V  
Carton: 43.5\*43\*9 cm      N.W./G.W.: 2 kg/2.5 kg  
Battery: NO ☐ 2000mA ☐

## Power supply or Charging (If Battery preset):

Use the power supply or charger (5V/1A-2A) to connect Type C USB cable. Insert the USB into the port of the Musical Boxing Pro. Mounting Boxing Pro should be considered close to the wall socket position.



## Operation:




- On/off : Long press to Power on and Power off.
- ✱ : Bluetooth, press On/Off button to power on or power off bluetooth.
- Speed : Press it to adjust the speed, displaying H01-H09, Flashing faster accordingly. Default speed level H01. It has boxing counter, displaying C00-C99.
- Mode : Press it to adjust mode, displaying P01-P09. Each mode has different speed and difficulty level.

## Gloves Operation (If included):



## Assembly:



- Option 1. Peel off the transparent film behind the black adhesive tape and paste it to the back of the Boxing Pro. (Figure 1). Tear off the transparent film on the other side of the black adhesive tape, paste the whole Boxing Pro on the wall or door. (Figure 2).
- Option 2. Paste the 2 velcros together and peel off covers of both sides, paste one side to the back of Musical Boxing Pro and other side to the wall.

## Caution:

1. Don't use until 30 minutes after a meal.
2. It should not be used during pregnancy or menstruation.
3. Electronic products can not be washed, can be wiped with a rag.
4. The machine battery is out of power after timely charging, to prevent battery loss.
5. Stop using immediately if you feel that your body is not used to it.
6. It is recommended to wear boxing gloves when using.
7. It is prohibited to disassemble the product without permission.