CRMXGOAT





Blizzard Lighting, LLC http://www.blizzardpro.com Waukesha, WI USA Copyright (c) 2024



1. GETTING STARTED

What's In The Box?

- LightCaster™ CRMX GOAT
- AC Power Cord
- · Mounting Hardware
- · This Lovely User Manual

Getting It Out Of The Box

Congratulations on choosing the LightCaster™ CRMX GOAT! Before you begin, please take a moment to verify that all components are included and in good condition. If you notice any damage during transit, notify the shipper immediately and keep all packing materials for inspection. If the unit ever needs to be returned, it must be shipped in its original factory packaging.

Need Help?

We're here for you. If you have questions or run into issues, visit www.blizzardpro.com/support to open a support ticket. We'll be happy to assist!

Disclaimer

We strive to provide accurate, up-to-date information and reserve the right to update or correct this manual as needed. For the latest version, visit www.blizzardpro.com.

2. INTRODUCTION

General Overview

The LightCaster™ CRMX GOAT is a high-performance wireless DMX transceiver designed for reliable operation across a wide range of professional lighting environments. Using advanced CRMX® technology, this device ensures seamless DMX and RDM communication over long distances with ultra-low latency and exceptional signal stability. Its compact and durable design, combined with a 1,000-meter range, makes it a dependable choice for both small and large-scale productions.

Setting up a CRMX wireless system is simple and provides highly reliable wireless DMX. This unit works as either a receiver or transmitter.

Main Features


- 2.4GHz CRMX wireless DMX transceiver
- Compatible with CRMX and W-DMX protocols
- Switchable TX/RX modes with dedicated button
- Adaptive frequency hopping (AFHSS)
- 1,000-meter range (line of sight)
- Supports RDM in RX mode

Specifications

- Frequency/Protocols: 2.4GHz, CRMX®/DMX/RDM
- Transmitter Power/Receiver Sensitivity: 100mW / 98dBm
- Latency/Antenna: < 5ms, 2dBi high-performance
- Universes: 1 per transmitter (up to 16)
- Connections: 5-pin DMX I/O, powerCON® TRUE1-compatible
- Size/Weight: 5.7 x 4 x 2.3 in (14.5 x 10 x 5.8 cm), 1.7 lbs (0.7 kg)

Author:	Date:	Last Edited:	Date:
J. Thomas	12/3/2024	J. Thomas	12/3/2024

3. OPERATION



Before You Begin

- 1. Decide whether each unit will act as a Transmitter (TX) or Receiver (RX) by pressing the Mode (TX/RX) button to toggle the mode.
- 2. For a Transmitter, you will need to connect a DMX controller to the DMX input, and for Receivers connect the unit's DMX output to the receiving fixture's input.
- 3. Check the LINK Status LED on the Receiver. If it is on, the Receiver is already paired with a Transmitter. Unpair it before pairing with a new Transmitter (see below).

Pairing Process

- 1. Ensure the Receiver is set to RX mode and the Transmitter is set to TX mode.
- On the **Transmitter**, press the **Function (Bah!)** button.
 The **LINK** LEDs on the Transmitter and Receiver(s) will flash rapidly during pairing.
- 4. Once pairing is complete, the LINK status LEDs on all units will remain solidly lit.

Unpairing A Single Receiver

- 1. On the Receiver, press and hold the Function (Bah!) button for 6 seconds.
- 2. The LINK status LED on the Receiver will turn off, indicating it is disconnected.

Unpairing All Receivers

- 1. On the Transmitter, press and hold the Function (Bah!) button for 6 seconds.
- 2. The **LINK** status LEDs on all paired Receivers will turn off to indicate disconnection.

Status LED Overview

LED	Mode	Off	Flashing	Solid
Link	TX	No paired Receivers	Pairing/searching	Paired with Receivers
	RX	Not paired	Pairing/searching	Paired with Transmitter
Data	TX	No DMX signal	N/A	Transmitting DMX
	RX	No DMX signal	N/A	Receiving DMX
RDM	TX	No RDM detected	RDM active	N/A
	RX	No RDM detected	RDM active	N/A
Power	TX/RX	Not powered	N/A	Powered and operational



Enjoy your product!
Our sincerest thanks for your purchase!
--The team @ Blizzard Lighting