



WHAT'S IN THE BOX



ColorFit Pulse 2 Pro Smartwatch x 1



Charging cable x 1

TABLE OF CONTENTS

• Activity

• Heart Rate

• Sleep

• Blood Oxygen

• Sports

• Messages

• Noise Buzz

• Weather

• Camera

• Music

• Stopwatch

• Alarm

• App

• Find phone

• Breathe

• Setting

• Games

• AI Voice

POWER ON

Press and hold the side button for 3 seconds or plug in the charger to turn on the watch.



Press & hold

POWER OFF

Long press the button and confirm to power off.

WAKING UP THE WATCH

To turn the screen back on, you can wake up the watch by pressing the side button.

CHARGING

Before using your ColorFit Pulse 2 Pro for the first time, charge the battery to its full capacity. Use the charging cable provided with the watch to charge. On a full charge, ColorFit Pulse 2 Pro can last up to 5 days.

Note: The battery life and time to fully charge your device may vary as per usage and other factors.

**To Charge ColorFit Pulse 2 Pro**

• Plug the USB cable into a power adaptor.

• Plug the power adaptor into an electrical socket. (Power adaptor not included).

• Place the magnetic charger on the magnetic charging points of watch.

• While your watch is charging, the screen will show the charging progress.

• Once the battery is fully charged, remove the charger.

SETUP

Before pairing, make sure that your smartphone and smartwatch are next to each other. The app will ask for personal information such as height, weight and sex to calculate your stride length, distance covered, calorie burn rate and metabolic rate.

Turn on Bluetooth and the location on your mobile device.

In your smartphone, download the Noise app from the Play store or the App store and install it.

Note: Ensure that your smartphone is running on Android 5.1+ or iOS 8.0 + and is connected to mobile data or a Wi-Fi network.

**PAIR THE WATCH**

Scan the QR code from the watch and download Noise app.

For iOS, select APP store, search Noise, download and install the app.

For Android, select Google Play to download and install Noise app.

Note: The smartwatch support Android 5.1 or above and iOS 8.0 or above and Bluetooth 4.0 or above.

Open the Noise app and allow the Bluetooth and GPS positioning to be turned on.

Feed in your personal information and health goals in the app.

Go to 'Add Device' page in the app, select the device type and link the watch.







PAIRING SMART WATCH

Select Add Device. Choose your device from the range of devices.

On iOS: Choose Bluetooth pairing when you receive a pairing prompt.

On Android: Connect it directly.

BT CALL CONNECTIVITY

Go to phone Bluetooth settings, search for "Noise Pulse 2 Pro\_Phone" and pair it. Now you can attend your calls from the watch.

BT CALL CONNECTIVITY REMOVAL

To remove the Bluetooth connection, you can unpair from the app and the phone BT settings.

SETTING

**Dial**

You can switch between different watch faces in the watch, choose and download cloud-based or you can create your own watch faces in the App.



**Changing the Watch Face**

Give your screen a personalised style by changing or customising the watch face from the App or the watch.

**On the Watch**

Touch and hold the home screen. Swipe and choose from the watch faces.

**In the App**

Go to device, select watch faces and choose the watch face of your choice and tap save to change.

**Brightness**

You can set the watch brightness on the watch.

**App**

Scan the QR code via your smartphone to download the Noise app.



ABOUT

You can know about the watch from the About section.



**Power off**

**Reset**









WATCH FEATURES

**NOISE HEALTH**

**Activity**

You can check your daily activity progress in terms of the steps taken, distance covered, calories burned and active time.



**Sleep**

You can view your most recent sleep record and a display of your sleep quality in various sleep stages in the Noise app.



**Heart Rate**

ColorFit Pulse 2 Pro supports 24/7 heart rate tracking. You can select the measurement frequency in the app settings.

To measure your heart rate in real time, go to the Heart Rate monitor and tap to measure. You can view the all-day data on the watch and app.

Note: Make sure your arms and wrists are still and there is no space between your watch and the wrist.



**Blood Oxygen**

ColorFit Pulse 2 Pro supports the viewing of highest and lowest blood oxygen level of the day.

To measure your blood oxygen level in real time, go to the Blood Oxygen monitor and let it measure.

Note: Make sure your arms and wrists are still, and there is no space between your watch and the wrist.




ColorFit Pulse 2 Pro

Please refer to this manual before using the product

**Breathe**


The Breathe feature helps you adjust your breathing rhythm as per your convenience. Go to the Breathe feature, choose the time duration and tap on start to enter the cycles of breathing.

Note: During this period, if you swipe right or press a button, breathing is interrupted and you can choose to practice again or complete the cycle.




**Sports**

Choose the sports you want to play and track the progress in terms of calories burned, heart rate, distance covered and steps taken.



**Weather**


ColorFit Pulse 2 Pro supports 7-day weather viewing in a location of your choice. You can view today's current weather and for the next six days. Open the Weather app on your watch and change the location to see the weather of your current location.



**Noise Buzz**


You can use this feature to manage calls from the watch. Make sure your watch is connected with your smartphone via Bluetooth. Go to Noise Buzz. Choose to dial from the dial pad or from the contact list and make calls. Note: If the watch is connected to your smartphone via Bluetooth, all calls will be directed to the watch.

During an active call, touch the call switching icon on the watch to switch from the watch to phone and attend the call from your phone.




**Messages**

Go to messages to read the smart notifications on your watch.



**Camera**


Control your camera remotely from the watch. Turn on the feature on the app



**Music**


You can control your favourite songs and podcasts that play from your phone, right on your wrist as long as the watch is connected with the Noise Track app in your phone.

You can play/pause music and go to next/previous track.




**Stopwatch**

A stopwatch can be set on the watch.




**Alarm**

You can set up to 3 alarms in the Noise app and they'll sync with the watch.



**Find Phone**

You can make your phone ring using the watch when the watch is connected to the app. Click the icon to stop the ringing.



**Device Information**

The ColorFit Pulse 2 Pro Watch contains the following:

• TFT Display

• IP67 waterproof

• 60Sports Modes

• 22 mm Strap

Activity data includes your steps, distance, calories, active minutes, heart rate, sleep duration and workout data. We recommend syncing the watch to the app daily.

**Tips**

**How do I update my ColorFit Pulse 2 Pro?**

You can update your ColorFit Pulse 2 Pro via the Noise app. Go to Device and select Check for updates.

**How do I change my activity goals?**

You can do it through the Noise app. Go to My Profile. Go to Setup and select My Objectives. Change your goals and confirm.

**How do I log my weight?**

You can log in your weight the first time you setup your Noise app. However, you can update the weight later via Noise app. Go to My Profile, select Personal Information and change or update your weight. You can update Birthday, height, step length and email id as well.

**Disposal and Recycling Information**

Electrical and electronic devices may not be disposed of with domestic waste. Consumers are obliged by law to return the electrical and electronic device at the end of their service lives to the public collecting points set up for this purpose or point of sale. Details to this are defined by the national law of the respective country. By recycling, reusing the materials or other forms of utilising old devices, you are making an important contribution to protecting our environment.

**How do I save battery?**

Follow these simple steps to save ColorFit Pulse 2 Pro Battery

• Minimise the screen brightness

• Limit the notification you receive from the Noise app.

**How does the watch estimate how many calories have been burned?**

ColorFit Pulse 2 Pro estimates how many calories you've burned based on the physical data you entered when you set up your account.

**Regulatory and Safety Information**

USA: Federal Communications Commission (FCC) Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

This device may cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this 76 equipment does cause harmful interference to radio or television reception, which could be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna

• Increase the separation between the equipment and receiver

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected

• Consult the dealer or an experienced radio/TV technician for help

In some cases, prolonged use of products may cause skin irritation. Prolonged contact may contribute to skin irritation or allergies in some users. To reduce the possibility of irritation, keep the watch and watch band clean and dry. Don't wear it too tight and give your wrist a rest by removing the watch after an extended period of wear. If you feel soreness, tingling, numbness, burning or stiffness in your hands or wrists while or after wearing the watch, please immediately discontinue use.

**SAFETY INSTRUCTIONS**

• Do not disassemble the battery on your own.

• Do not expose ColorFit Pulse 2 Pro to extremely high or low temperatures.

• The excessive temperature during charging could cause heat, smoke, fire or deformation of the battery or even explosion.

• Charge the battery in a cool, ventilated room.

• Do not open, crush, bend, deform, puncture or shred secondary cells or batteries. In the event of a battery break or leak, prevent battery liquid contact with skin or eyes. If this happens, immediately flush the areas with water (DO NOT RUB THE EYE) or seek medical help.

• Keep the batteries out of children's reach and in a safe place to prevent danger.

• Do not place the batteries in the water.

• Do not short-circuit. Short-circuiting may damage the battery. Short-circuiting can occur when a metallic object, such as coins, causes the direct connection of positive and negative terminals of the battery.

• Do not use your product in a sauna or steam room.

• Do not dispose of batteries in the fire as that may cause an explosion. Dispose of used batteries in accordance with your local regulations. Do not dispose it as household waste.

• Use only the charging cable supplied to charge the battery. Do not charge for more than 24 hours.

• Do not attempt to repair or maintain the watch yourself, service and maintenance should be performed by authorised technicians only. Any device failure should be referred to our after-sales service personnel.

• To prevent device damage, accessory damage and device failure, always protect the device against strong impact or shock.

**CUSTOMER SUPPORT**

If you experience any problem with the watch, it may be fixed by restarting your watch. For any assistance, please reach out to us at [link.support.gonoise.com](mailto:link.support.gonoise.com)

100 GSM